



**Tsunami MP.11
Model 5012-SUI
Installation and Management**



Copyright

©2006 Proxim Wireless Corporation, San Jose, CA. All rights reserved. Covered by one or more of the following U.S. patents: 5,231,634; 5,875,179; 6,006,090; 5,809,060; 6,075,812; 5,077,753. This manual and the software described herein are copyrighted with all rights reserved. No part of this publication may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language in any form by any means without the written permission of Proxim Wireless Corporation.

Trademarks

Tsunami, Proxim, and the Proxim logo are trademarks of Proxim Wireless Corporation. All other trademarks mentioned herein are the property of their respective owners.

FCC Compliance

This document provides regulatory information for the following wireless indoor products:

- 5012-SUI

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference
2. This device must accept any interference received, including interference that may cause undesired operation.

This device must be professionally installed.

Changes or modifications not expressly approved by Proxim Wireless Corporation could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception (which can be determined by turning the equipment off and on), you are encouraged to attempt to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
 - Increase the separation between the equipment and receiver.
 - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio or television technician for help.

This device must be professionally installed. Antennas used for the 5012-SUI product must be fix-mounted on permanent structures.

Contents

1	Introduction	8
	About This Book	8
	Reference Manual	8
	Wireless Network Topologies	10
	Point-to-Point Link	10
	Point-to-Multipoint Network	10
	Power-over-Ethernet	12
	Identifying Network Topology and Equipment	13
	Finding a Suitable Location	14
2	Installation	15
	Introduction	15
	Installation Procedure	16
	Verify Package Contents	16
	Attach Cables	16
	Install the Security Cover (Optional)	17
	Mount the Unit	17
	Power On the Unit	18
	Install Documentation and Software	19
	Connect the Pigtail Cable	20
	Align the Antenna	21
3	Management Overview	22
	Introduction	22
	IP Address	24
	Setting the IP Address	24
	Starting the Web Interface	26
	Changing Basic Configuration Information	27
	Country and Related Settings	27
	Dynamic Frequency Selection (DFS)	27
	Transmit Power Control	29
	SU Registration	30
	Dynamic Data Rate Selection (DDRS)	31
	Virtual Local Area Networks (VLANs)	32
	Quality of Service (QoS)	33
	Concepts and Definitions	33
4	Basic Management	37
	Navigation	37

Rebooting and Resetting	38
Rebooting	38
Resetting Hardware	38
Soft Reset to Factory Default	38
General Configuration Settings	39
Monitoring Settings	40
Security Settings	41
Encryption	41
Passwords	41
Default Settings	42
Upgrading the Unit	44
5 System Status	45
View System Status	45
System Status	45
Systems Traps	45
View the Event Log Contents	46
6 Configuration	47
System Parameters	47
Bridge and Routing Modes	48
Network Parameters	51
Change IP Parameters	51
Configure Spanning Tree Options	51
Enable or Disable Roaming	54
Enable and Configure the DHCP Server	57
Enable the DHCP Relay Agent (Routing mode only)	59
Interface Parameters	61
Configure the Wireless Interface	61
Configure the Ethernet Interface	68
SNMP Parameters	70
Add Entries to the Trap Host Table	70
Edit/Delete Entries to the Trap Host Table	70
RIP Parameters	72
RIP Example	73
RIP Notes	74
Management Parameters	75
Configure Passwords	75
Configure Service Parameters	75
Security Parameters	78
Configure MAC Authentication	78

Configure Encryption Parameters	79
Configure RADIUS Authentication	79
Configure Packet Filtering	80
Increasing Available Bandwidth	80
Increasing Network Security	80
Sample Use and Validation	80
Setting the ARP Filter	81
Configure Ethernet Protocol Filtering	81
Add Entries to the Ethernet Protocol Filter Table	82
Configure Static MAC Pair Filtering	82
Configure Storm Threshold Filtering	86
Configure Broadcast Protocol Filtering	86
Configure IP Access Table Filtering	87
Intra-Cell Blocking (Base Station Unit only)	89
Enable Intra-Cell Blocking	89
Configure Intra-Cell Blocking Groups	89
Assign MAC Addresses	90
Block Traffic Between SUs (Security Gateway)	91
Intra-Cell Blocking Group Rules	92
Example of Intra-Cell Blocking Groups	92
Achieving Communication Between Two SUs	92
VLAN Parameters	93
VLAN Modes	93
VLAN Forwarding	93
VLAN Relaying	93
Management VLAN	93
BSU and SU in Transparent Mode	93
BSU in Trunk Mode and SU in Trunk/Access Mode	94
BSU VLAN Configuration	95
SU VLAN Configuration	97
Typical User VLAN Configurations	99
QoS (Quality of Service) Parameters	100
QoS PIR Configuration	100
QoS SFC Configuration	101
QoS Class Configuration	103
QoS SU Configuration	107
SU Access to the Public Network (NAT)	109
NAT Feature Interactions	109
NAT Static Port Mapping Table	109
Supported Session Protocols	110
7 Monitoring	112
Monitor the Wireless Settings	113

General Performance	113
WORP Interface Performance	113
View Number of ICMP Messages	114
View Per Station Statistics	115
View Features Supported	116
Test Link Quality	117
Monitor Interfaces	118
View the Mapping of IP and MAC Addresses	119
View Active IP Routes	120
View All Detected MAC Addresses (Learn Table)	121
View RIP Data	122
View RADIUS Traffic Information	123
View Quality of Service (QoS) Information	124
8 Commands	125
Download Files	125
Upload Files	126
Reboot the Unit	127
Reset the Unit to Factory Default	128
Set the Help Link Location	129
9 Procedures	130
TFTP Server Setup	131
Web Interface Image File Download	132
Configuration Backup	133
Configuration Restore	134
Soft Reset to Factory Default	135
Hard Reset to Factory Default	136
Forced Reload	137
Image File Download with the Bootloader	138
Download with ScanTool	138
10 Troubleshooting	139
Connectivity Issues	139
5012 Does Not Boot	139
Ethernet Link Does Not Work	139
Cannot use the Web Interface	139
Communication Issues	141
Two Units Are Unable to Communicate Wirelessly	141

Setup and Configuration Issues	142
Lost Password	142
The 5012 Responds Slowly	142
TFTP Server Does Not Work	142
Online Help Is Not Available	142
Changes Do Not Take Effect	142
VLAN Operation Issues	143
Link Problems	144
General Check	144
Statistics Check	144
Analyzing the Spectrum	145
Avoiding Interference	145
Conclusion	145
A Country Codes and Channels	146
Model 5012 (5.8 GHz) Channels/Frequencies by Country	146
B Technical Services and Support	165
Obtaining Technical Services and Support	165
Support Options	166
Proxim eService Web Site Support	166
Telephone Support	166
ServPak Support	166
C Statement of Warranty	167
Warranty Coverage	167
Repair or Replacement	167
Limitations of Warranty	167
Support Procedures	167
Other Information	168
Search Knowledgebase	168
Ask a Question or Open an Issue	168
Other Adapter Cards	168

Introduction

The Tsunami MP.11 Model 5012-SUI is a flexible wireless indoor client that let you design solutions for point-to-point links and point-to-multipoint networks. It is the client or satellite side in a wireless link.

The 5012-SUI is part of the Tsunami MP.11 product family, which is comprised of several addition products, including the 5054 Base Station (BSU) and the 5054 Subscriber Unit (SU) for indoor installation, and the 5054-R and 2454-R for outdoor installation. Some of the key features of the product family are:

- The use of a highly optimized protocol for outdoor applications
- Routing and bridging capability
- Asymmetric bandwidth management
- Management through a Web Interface, a Command Line Interface (CLI), or Simple Network Management Protocol (SNMP)
- Software and configuration upgrade through file transfer (TFTP)
- VLAN support

About This Book

Before installing and using the 5012, Proxim recommends you review the following chapters of this manual:

- **Chapter 1 “Introduction” (this chapter):** Provides an overview of the content of this manual as well as wireless network topologies and combinations that can be built with the 5012.
- **Chapter 2 “Installation”:** Provides detailed installation instructions for the 5012.
- **Chapter 3 “Management Overview”:** Explains how to access the 5012 for configuration and maintenance.
- **Chapter 4 “Basic Management”:** Explains the most common settings used to manage the 5012.
- **Chapter 5 “System Status”:** Explains how to access system information and event logs.
- **Chapter 6 “Configuration”:** Depicts the Web Interface’s “Configure” options in a hierarchical manner, so you can easily find details about each item.
- **Chapter 7 “Monitoring”:** Depicts the Web Interface’s “Monitor” options in a hierarchical manner, so you can easily find details about each item
- **Chapter 8 “Commands”:** Depicts the Web Interface’s “Commands” options in a hierarchical manner, so you can easily find details about each item
- **Chapter 9 “Procedures”:** This chapter provides a set of procedures, including TFTP Server Setup, Configuration Backup, Restore, and Download, Forced Reload, and Reset to Factory Defaults.
- **Chapter 10 “Troubleshooting”:** This chapter helps you to isolate and solve problems with your radio unit.

The appendixes contain supplementary information you may not need immediately, including Country Code Tables and Technical Support information.

NOTE: *If you are already familiar with this type of product, you can use the Quick Install Guide to install the unit.*

Reference Manual

As a companion to the *Installation and Management* manual, the *Tsunami MP.11 Reference Manual* provides the following supplemental information:

- **Command Line Interface:** Documents the text-based configuration utility’s keyboard commands and parameters.
- **Event Log Error Messages:** Documents the error messages that you may see in your Event Log.

- **Alarm Traps:** Documents the alarm traps that can be set.
- **Microsoft Windows IAS Radius Server Configuration:** Provides information to assist you in setting up the IAS Radius Server.
- **Addition of Units to a Routed Network:** Describes how to add more units to your routed network.
- **Glossary:** Describes terms used in the Tsunami MP.11 documentation and in the wireless industry.

Wireless Network Topologies

The unit can be used in various network topologies and combinations. The required equipment depends upon the wireless network topology you want to build. Make sure all required equipment is available before installing the unit.


You can set up the following types of topologies:

- Point-to-Point Link
- Point-to-Multipoint Network

Each unit is set up as either a Base Station Unit (BSU) or a Subscriber Unit (SU). A link between two locations always consists of a BSU and an SU. A BSU can, depending upon its configuration, connect to one or more SUs. An SU, however, can connect only to one BSU. **The 5012-SUI can be configured only as an SU.**

Point-to-Point Link

With a BSU and an SU, it is easy to set up a wireless point-to-point link as depicted in the following figure.




A point-to-point link lets you set up a connection between two locations as an alternative to:

- Leased lines in building-to-building connections
- Wired Ethernet backbones between wireless access points in difficult-to-wire environments

Point-to-Multipoint Network

If you want to connect more than two buildings, you can set up a single point-to-multipoint network with a single BSU and multiple SUs, as depicted in the following figure.



Up to 250 SUs can be connected to a BSU. If a BSU already has 250 SU, a new SU cannot be connected to the BSU. In this figure, the system is designed as follows:

- The central building **B** is equipped with a BSU, connected to either an omni-directional, or a wide angle antenna.
- The two other buildings **A** and **C** are both equipped with an SU connected to a directional antenna.

Power-over-Ethernet

The 5012-SUI comes with a 110/220 VAC Power Supply that has a barrel plug for the power jack in the back of the unit. The 5012-SUI is equipped with an Active Ethernet module so it can also be powered through an Active Ethernet adapter such as the ORiNOCO 1-Port Active Ethernet DC Injector (ordered separately). Using Power-over-Ethernet (PoE), you can provide electricity and wired connectivity to the unit over a single Category 5 cable. If you use Active Ethernet, there is no difference in operation; the only difference is the power source.

- The Active Ethernet integrated module receives –48 VDC over a standard Cat5 Ethernet cable.
- Maximum power supplied to the 5012-SUI is 11 Watts. The units typically draw less than 9 Watts.
- You must have an Active Ethernet DC Injector connected to the network to use Active Ethernet. The DC Injector is not a repeater and does not amplify the Ethernet data signal.
- If connected to an Active Ethernet DC Injector and an AC power supply simultaneously, the radio draws power from Active Ethernet.
- The cable length between the Active Ethernet DC Injector and the radio should not exceed 100 meters (approximately 325 feet).

NOTE: *Cable length affects range by inserting loss in the signal path between the radio and the antenna. The amount of loss depends on the type and length of cable and type of connectors. Proxim offers standard low loss cables in the following lengths with RTNC connectors, the connector type on the Stratum MP: 5 feet (0.6 dB loss), 10 feet (0.9 dB loss), 20 feet (1.5 dB loss), and 50 feet (3.5 dB loss). Custom cables can address longer cable runs.*

Identifying Network Topology and Equipment

The 5012 can be used in various network topologies and combinations. The required equipment depends upon the wireless network topology you want to build. Make sure all required equipment is available before installing the 5012.

You can connect the 5012 to an outdoor/indoor antenna installation with an optional antenna kit. See the *Tsunami MP.11 Antenna Installation Guide* for details.

WARNING: *If you want to connect the 5012 to an outdoor antenna system, consult the appropriate manufacturers' documentation for additional regulatory information, safety instructions, and installation requirements.*

Finding a Suitable Location

To make optimal use of the 5012, you must find a suitable location for the hardware. The range of the unit largely depends upon the position of the antenna. Proxim recommends you do a site survey, observing the following requirements, before mounting the 5012 hardware.

- The location must allow easy disconnection of the unit from the power outlet if necessary.
- The unit must not be covered and the air must be able to flow freely around the unit.
- The unit must be kept away from vibration, excessive heat, and humidity, and kept free from dust buildup.
- The installation must conform to local regulations at all times.

NOTES:

- *The **Configure System** window provides a selectable **Country** field that automatically provides the allowed bandwidth and frequencies for the selected country as well as, where applicable, Dynamic Frequency Selection (DFS) and Transmit Power Control (TPC).*
- *Non-US installers should not add an antenna system until the **Country** is selected, the unit is rebooted, and the proper power level is configured. The output power level of the final channel selected by DFS scan can be found in the Event Log.*

Installation

This chapter describes the steps required to install and mount the 5012-SUI, including installing, mounting, and aligning the antenna. The installation procedure does not include the mounting and connection of antennas. See the *Tsunami MP.11 Antenna Installation Guide* for this information.

If you are already familiar with this type of product, you can use the *Quick Install Guide* for streamlined installation procedures.

IMPORTANT! Before installing this product, see the important regulatory compliance and safety information in [FCC Compliance](#).

See the following sections:

- [Introduction](#)
- [Installation Procedure](#)

Introduction

The following installation procedure provides instructions for attaching both the power and Ethernet connectors. In situations without an external antenna (for example, during a desk tryout), the antenna cable is not required.

The 5012-SUI uses a 110/220 VAC Power Supply that is directly plugged in the power jack on the back of the unit (see figure). The 5012-SUI is equipped with an Active Ethernet module so it can also be powered through an Active Ethernet adapter such as the ORiNOCO 1-Port Active Ethernet DC Injector (ordered separately). Using Power-over-Ethernet (PoE), you can provide electricity and wired connectivity through the Ethernet cable plugged in the LAN port on the back of the unit (see figure). The RS-232 serial port is for factory use only.




Figure 2-1 5012-SUI Rear Panel

WARNING: For your own safety, use only the power cord supplied with the unit. The metal case of the unit must be grounded through the ground connection that is provided on the metal case. The antenna grounding, the surge arrester, and the 5012 unit housing must be bonded together and grounded in one location to avoid ground current loops.

Installation Procedure

Verify Package Contents

Unpack the unit and accessories from the shipping box. Each shipment comes with the following:

- One Tsunami 5012-SUI unit
- One metal plate for ceiling or wall mounting (includes two screws)
- One power supply
- One security cover
- One pigtail cable, SMA to N-type connector (for external antenna)
- One Tsunami MP.11 Model 5012-SUI Installation CD


The shipment also includes the *Tsunami 5012 Quick Install Guide*.

NOTE: All software CDs that come with your Tsunami products include a **Release Notes** file. This file contains information about the software version and drivers. You are advised to print and read the **Release Notes** file prior to installing your Tsunami products, as it may contain additional information that was not available when this document was printed.

Attach Cables

Cabling without Power Over Ethernet (PoE)



1. Plug the barrel of the power cable from the power supply into the power jack (the leftmost port in the back of the unit, see figure).
2. Connect one end of an Ethernet cable (not supplied) to the unit's LAN port (see figure). The other end of the cable should not be connected to another device until after installation is complete:
 - Use a straight-through Ethernet cable if you intend to connect the 5012 to a switch, hub, or patch panel.
 - Use a cross-over Ethernet cable or adapter if you intend to connect the 5012 to a single computer.



3. Continue with [Install the Security Cover \(Optional\)](#).

Cabling with Power Over Ethernet (PoE)

1. You must use an Active Ethernet adapter such as the ORiNOCO 1-Port Active Ethernet DC Injector (ordered separately). Connect one end of an Ethernet cable (not supplied) to the unit's LAN port. Connect the other end to the **Data and Power Out** port of the DC Injector (see figure).
2. Connect one end of a second Ethernet cable (not supplied) to the **Data In** port of the DC Injector (see figure). The other end of the cable should not be connected to another device until after installation is complete:
 - Use a straight-through Ethernet cable if you intend to connect the 5012-SUI to a switch, hub, or patch panel.
 - Use a cross-over Ethernet cable or adapter if you intend to connect the 5012-SUI to a single computer.




3. Continue with [Install the Security Cover \(Optional\)](#) below.

Install the Security Cover (Optional)

You can optionally install a security cover to deter unauthorized access to the 5012. The security cover is a plastic enclosure that prevents access to the cabling and the Reset and Reload buttons.

1. Open the split end of the security cover just enough to slide the power cable (if not using PoE) and the Ethernet cable through the opening until they fit inside the straight clamping portion of the cover. Exercise care as you slide the cable(s) so you do not accidentally break the cover (see figure).
2. Slide the hinging end of the security cover into the hole on the rear panel of the 5012 to the left of the connectors. Once in place, pivot the right side of the cover to bring it close to the rear panel of the 5012.
3. Use the two attached screws to fasten the security cover onto the rear panel of the 5012.



Mount the Unit

The following are the mounting options for the 5012:


- [Wall Mounting](#)
- [Ceiling Mounting](#)

Wall Mounting

Follow these steps to mount the unit on a wall:

1. If the unit's power supply is plugged in, unplug it.
2. Identify the location at which you intend to mount the unit.

3. Put the mounting plate up to the wall so that the embossed letter “L” is on top (see figure). If the plate is correctly oriented, the circular tab that is vertically aligned with the square hole should be on top.
4. Fasten the mounting plate with two screws through the circular holes of the plate. Depending on the type of wall you may need to use the two fasteners provided.
5. Holding the 5012 so that the connectors on the rear are facing left, align the two holes on the bottom of the unit with the two tabs on the mounting plate. Press the unit down so it is flushed with the plate.
6. Carefully slide the unit to your right until the tabs snap securely onto the narrow holes of the unit. If the 5012 is mounted correctly no portion of the mounting plate should protrude from any of the sides of the unit.



Ceiling Mounting


Follow these steps to mount the 5012 to a ceiling:

1. If the unit's power supply is plugged in, unplug it.
2. Identify the location at which you intend to mount the unit.
3. Snap the rectangular tabs on the back of the mounting plate onto a ceiling T-bar. You may need to slightly rotate the plate until it securely snaps onto the T-bar.
4. Fasten the mounting plate to the ceiling tile with two screws through the circular holes of the plate.
5. Position yourself so that the embossed letter “L” on the mounting plate is facing up (see previous figure). Holding the 5012 so that the connectors on the rear are facing to your left, align the two holes on the bottom of the unit with the two tabs on the mounting plate. Press the unit up so it is flushed with the plate.
6. Carefully slide the unit to your right until the tabs snap securely onto the narrow holes of the unit. If the 5012 is mounted correctly no portion of the mounting plate should protrude from any of the sides of the unit.

Power On the Unit

The 5012 can be powered by a power supply (just plug the power cord of the power supply into an AC power outlet), or by Active Ethernet (connect an Active Ethernet DC injector to the Ethernet cable).

When the unit is powered on, the 5012 performs startup diagnostics. When startup is completed, the LEDs show the operational state of the 5012 (see the following figure).



The following table shows the status of the LEDs when the 5012 is operational.

Status	Ethernet Link	Wireless Link	Power
Starting up	N/A	N/A	Solid Amber
Radio scanning	N/A	N/A	Blinking Green
WORP link is up	N/A	N/A	Solid Green
No WORP link	N/A	N/A	Blinking Amber/Green
System failure	N/A	N/A	Solid Red

NOTE: The Ethernet Link and Wireless Link LEDs blink according to traffic in their corresponding interfaces.

Install Documentation and Software

The 5012 also comes with documentation and software on a CD.

To install the documentation and software on a computer or network:

1. Place the CD in a CD-ROM drive. The installer normally starts automatically. You can also start the installer manually by running the **setup.exe** program from the **\Setup** directory on the CD.
2. Click the **Install Software and Documentation** button and follow the instructions displayed on the installer windows.
3. In addition to the software installation utility, the CD contains the following documentation and software:
 - **Online help:** This is the help for the Web Interface. It is also stored on your computer or network during the installation process, so it is always available (see **C:\Program Files\Tsunami\MP.11**). You can also find the help in the **\Help** folder of the product CD.
 - **Documentation:** Documentation is provided in PDF format, including:
 - Release Notes
 - Tsunami MP.11 5012-SUI Quick Install Guide
 - Tsunami MP.11 5012-SUI Installation and Management
 - Tsunami MP.11 Reference Manual
 - Tsunami MP.11 5012-SUI Antenna Installation
 - Tsunami MP.11 Recommended 5 GHz and 2.4 GHz Antennas
 - Safety and Regulatory Information


You can find this documentation in the **\Docs** folder of the product CD. This documentation also is installed at: **C:\Program Files\Tsunami\MP.11**.

- **ScanTool:** ScanTool lets you find the IP address of a Tsunami MP.11 5012 by referencing the MAC address in a Scan List, and lets you assign an IP address if one has not been assigned. The tool automatically detects the units installed on your network, regardless of IP address, and lets you configure each unit's IP settings. In addition, you can use ScanTool to download new software to a unit that does not have a valid software image installed. See [Setting the IP Address](#). You can find ScanTool in the **\Xtras** directory of the product CD. It is installed at **C:\Program Files\Tsunami\MP.11**.
- **TFTP Server:** The TFTP (Trivial File Transfer Protocol) server lets you transfer files across the network. You can download configuration files, as well as image files for embedded software upgrades, and you can upload files from the 5012 for backup. Here *downloading* means transferring files to the 5012 and *uploading* means

transferring files in the opposite direction. See [TFTP Server Setup](#) for more information. You can find the SolarWinds TFTP Server in the **IXtras** directory of the product CD. It is installed at **C:\Program Files\Tsunami\MP.11**.


Connect the Pigtail Cable

The pigtail cable has a sub-miniature A-type (SMA) connector on one end and an N-type connector on the other. It is used to connect an external antenna to the 5012 (see figure).




To install the pigtail cable:

1. Place the 5012 on a table. The compartment cover closer to the LED panel contains the antenna connector. Press down near the center of the compartment cover and slide it forward to open the antenna compartment. The two small plastic caps on the front will fall out at the same time (see figure).



2. Plug the SMA connector end of the pigtail cable onto the antenna jack inside the compartment (see figure). Exercise caution when pressing down the connector to avoid breaking it accidentally. Make sure the cable rests on the notch across the jack so you will be able to close the cover.



3. Replace the cover by aligning the two bottom tabs inside the holes (A) on each side of the compartment. Ensure that the cable will not get pinched by the cover. Slide the cover towards the center of the unit until it snaps on place. Replace one of the small plastic caps onto the remaining open hole on the front.

4. Refer to the *Tsunami MP.11 Antenna Installation Guide* for information on how to cable the pigtail to the antenna, as well as for the mounting and connection of antennas.

Align the Antenna

Antenna Alignment Display (AAD) provides a measurement of signal quality in an easy-to-interpret manner—a numeric printed signal value at the CLI. The SNR is numerically displayed on the CLI by two decimal characters representing a number from 00 to 99.

To start the display, you must enable AAD and a wireless link must be established between the BSU and the SU.

Aiming is complete if moving in any direction results in a falling SNR value.

Antenna Alignment Commands

set aad enable local: Enables display of the local SNR. Local SNR is the SNR measured by the receiver at the near end.

set aad enable remote: Enables display of the remote SNR. Remote SNR is the SNR as measured by the receiver at the far end.

set aad enable average: Enables display of the average SNR. The average SNR is the average of the local and remote SNR.

set aad disable: Disables Antenna Alignment Display (Ctrl-C also disables AAD).

Management Overview

This chapter describes how to gain access to the 5012 for configuration and management, and provides an overview of the system.

See the following sections:

- [Introduction](#)
- [IP Address](#)
- [Starting the Web Interface](#)
- [Changing Basic Configuration Information](#)
- [SU Registration](#)
- [Dynamic Data Rate Selection \(DDRS\)](#)
- [Quality of Service \(QoS\)](#)

Introduction

Three interfaces are provided for viewing or changing the unit's settings:

- **Web Interface:** The Web interface (HTTP) provides easy access to configuration settings and network statistics from any computer on the network. You can access the Web interface over your network, over the Internet, or with a crossover Ethernet cable connected directly to your computer's Ethernet port.
- **Command Line Interface:** The Command Line Interface (CLI) is a text-based configuration utility that supports a set of keyboard commands and parameters to configure and manage the 5012 unit. You enter command statements, composed of CLI commands and their associated parameters. You can issue commands from the keyboard for real-time control or from scripts that automate configuration. See "Command Line Interface" in the *Tsunami MP.11 Reference Manual* for more information.
- **SNMP:** In addition to the Web interface and the CLI, you also can manage and configure your unit using the Simple Network Management Protocol (SNMP). Note that this requires an SNMP manager program, such as Hewlett Packard's OpenView or Castelfrock's SNMPc. The 5012 supports several Management Information Base (MIB) files that describe the parameters that can be viewed and configured using SNMP:
 - mib802.mib
 - orinoco.mib
 - rfc1213.mib
 - rfc1493.mib
 - rfc1643.mib

Proxim provides these MIB files on the CD included with your unit. You must compile one or more of these MIB files into your SNMP program's database before you can manage your unit using SNMP. See the documentation that came with your SNMP manager for instructions about how to compile MIBs.

NOTE: *When you update the software in the unit, you must also update the MIBs to the same release. Because the parameters in the MIB may have changed, you will not otherwise have full control over the features in the new release.*

The enterprise MIB (orinoco.mib) defines the read and read/write objects you can view or configure using SNMP. These objects correspond to most of the settings and statistics that are available with the other management interfaces. See the enterprise MIB for more information; the MIB can be opened with any text editor, such as Microsoft Word, Notepad, and WordPad. See [SNMP Parameters](#) for setup procedures.

Connecting to the 5012 requires a direct physical connection with an Ethernet cross-over cable or a connection through the network. You may use the Web Interface, SNMP, or the CLI, and you require to know the IP address of the 5012. See [IP Address](#) for more information.

IP Address

Because each network is different, an IP address suitable for your network must be assigned to the unit. You must know this IP address to configure and manage the unit through its Web Interface, SNMP, or the CLI. You can manage other basic parameters as well. ScanTool is included on the documentation and software CD to assist you in finding and changing the unit's IP address.

The unit can use either a **static** or **dynamic** IP address. The unit either obtains its IP address automatically through DHCP (dynamic IP address) or it must be set manually (static IP address).

With ScanTool (a software utility that is included on the product installation CD), you can find out the current IP address of the unit and, if necessary, change it so that is appropriate for your network. The units are shipped with the static IP address 10.0.0.1 configured.


ScanTool lets you find the IP address of a Tsunami MP.11 5012 by referencing the MAC address in a Scan List, or to assign an IP address if the correct one has not been assigned. The tool automatically detects the units installed on your network segment, regardless of IP address, and lets you configure each unit's IP settings. In addition, you can use ScanTool to download new software to a unit that does not have a valid software image installed.

Setting the IP Address

If you want to set the IP address:

1. Run ScanTool on a computer connected to the same LAN subnet as the unit, or a computer directly connected to the unit with a cross-over Ethernet cable. ScanTool (scantool.exe) has been installed on your computer at the following location: **C:\Program Files\Tsunami\MP.11**

ScanTool scans the subnet for 5012 units and displays a list of the units it finds in the main window. The following figure is an example of the main window. If necessary, click **Rescan** to re-scan the subnet and update the display. You can assign a new IP address to one unit, even if more than one unit has the same (default) IP address 10.0.0.1, but the new IP address must be unique to allow use of the management interfaces.



2. Select the unit for which you want to set the IP address and click **Change**. The **Change** dialog window is displayed, as shown in the following window.

The screenshot shows a 'Change' dialog box with the following fields and values:

Field	Value
MAC Address	00-20-a6-56-9e-9b
Name	Tsunami MP.11
IP Address Type	Static (selected), Dynamic
IP Address	10.0.0.1
Subnet Mask	255.255.255.0
Gateway IP Address	10.0.0.1
TFTP Server IP Address	10.0.0.100
Image File Name	SignedBuild_000159.bin
Read/Write Password	

- To set the IP address **manually**, ensure that **Static** is selected as the **IP Address Type** and fill in the **IP Address** and **Subnet Mask** suitable for the LAN subnet to which the unit is connected.
To set the IP address **dynamically**, ensure that **Dynamic** is selected as the **IP Address Type**. The unit will request its IP address from a DHCP server on your network.
- Enter the **Read/Write Password** (the default value is **public**) and click **OK** to confirm your changes. The respective unit reboots to make the changes effective.

NOTE: The number of asterisks displayed after you enter the password does not necessarily equal the number of characters in the actual password string. This is done for added security.


Starting the Web Interface

The Web Interface provides a graphical user interface through which you can easily configure and manage the 5012. This section describes only how to access the Web Interface; the Web Interface itself described in [Basic Management](#).

To use the Web Interface, you need only the IP address of the 5012. (See [IP Address](#) for details).

NOTE: *If the connection is slow or you are not able to connect, use the Internet Explorer Tools option to ensure you are not using a proxy server for the connection with your Web browser.*

To access the 5012 with a Web browser, start your Web browser and enter the IP address of the unit. The Web address must appear as **http://<ip address>** (for example, **http://10.0.0.1**). A window such as the following is displayed.



Do not fill in the **User Name**, enter only the password and click **OK**. The default password is **public**.

The **System Status** window is displayed. You now have access to the unit's Web Interface. To find out more about the information presented in this window, see [View System Status](#).



Changing Basic Configuration Information

To view or change basic system information, click the **Configure** button on the left side of the Web interface window, then click the **System** tab. See [System Parameters](#) for detailed information about the fields and selections in this window.

NOTE: System Name by default contains the actual model number. The following screenshot is for information only.

The screenshot shows the 'System' configuration page in a web interface. The page has a navigation menu on the left with buttons for Status, Configure, Monitor, Commands, Help, and Exit. The main content area is titled 'Information' and contains the following fields:

- System Name: Tsunami MP.11
- Note: Configure Satellite to use this Base Station System Name if you want Satellite to register only with this Base Station. Otherwise, leave the Base Station System Name blank on the Satellite.
- Country: UNITED STATES (US)
- Location: Contact Location
- Contact Name: Contact Name
- Contact Email: Name@Organization.com
- Contact Phone: Contact Phone Number
- Object ID: 1.3.6.1.4.1.11000.2.4.9
- Ethernet MAC Address: 00:30:F1:E8:82:96
- Descriptor: Tsunami MP.11 SN-05UT10710022
- Up Time (DD:HH:MM:SS): 00:00:13:09
- Note: Change in Mode of Operation requires a device reboot and appropriate changes to IP Configuration.
- Mode of Operation: Bridge
- Note: Changes in Logging Interval take effect immediately after clicking OK Button.
- Temperature Logging Interval: 60 Minutes

At the bottom of the form are 'OK' and 'Cancel' buttons.

Country and Related Settings

The unit's **Configure System** window provides a selectable **Country** field that automatically provides the allowed bandwidth and frequencies for the selected country.

Units sold in the United States are pre-configured to scan and display only the outdoor frequencies permitted by the FCC. No other **Country** can be configured. Units sold outside of the United States support the selection of a **Country** by the professional installer.

NOTE: Non-US installers should not add an antenna system until the **Country** is selected, the unit is rebooted, and the proper power level is configured. The output power level of the final channel selected by DFS scan can be found in the Event Log.

The Dynamic Frequency Selection (DFS) feature is enabled automatically when you choose a country with a regulatory domain that requires it. The Transmit Power Control (TPC) feature is always available.

Click the **Configure** button and the **System** tab; then select the appropriate country for your regulatory domain from the **Country** drop-down box.

Continue configuring settings as desired; then click the **Commands** button and the **Reboot** tab to save and activate the settings. Alternatively, if you want to save the configuration settings to the flash memory but not activate the settings, use the **save config** CLI command.

Dynamic Frequency Selection (DFS)

The Tsunami MP.11 5012 supports Dynamic Frequency Selection (DFS) for European Telecommunications Standard Institute (ETSI) domains per EN 301-893 regulations. The ETSI requires that 802.11a devices use DFS to prevent interference with radar systems and other devices that already occupy the 5 GHz band.

During boot-up, the unit scans the available frequency and selects a channel that is quiet and free of radar interference. If the unit subsequently detects radar interference on its channel, it rescans to find a better channel. Upon finding a new channel, the unit waits 60 seconds to detect radar interference; if it finds no interference, it switches to the new channel.

If you are using a 5012 unit in Europe or other applicable countries, keep in mind the following:

- DFS is not a configurable parameter; it is always enabled and cannot be disabled.
- You cannot manually select the device's operating channel; you must let the unit select the channel. However, you can specify a particular "preferred" channel that you want to scan first whenever the DFS process starts. You may also make channels unavailable by manually "blacklist" them and prevent those channels to be scanned, as well as display the Channel Blacklist Table.

With 5012 units, Dynamic Frequency Selection (DFS) is enabled automatically based upon the country you select. You can tell DFS is in use because the frequency selection field displays only the DFS-selected frequency. DFS scans all available frequencies, starting with the DFS preferred channel and skipping blacklisted channels, to select the operating frequency automatically.

A country selection with DFS enabled causes the Base Station to come up in scan mode. It scans the available frequencies and channels to avoid radar and selects a channel with the least interference.

NOTE: *Scanning is performed only on the frequencies allowed in the regulatory domain of the country selected when it is required for radar detection and avoidance.*

To comply with your country's regulations, change the DFS selection to specify your country. You can do this by logging into the unit, clicking the **Configure** button and selecting the **System** tab. There is a drop-down box labeled **Country** with all available countries from which to select. Choose your country, configure the unit as required, and reboot for the settings to take effect.

The SU also comes up in scan mode to scan all available frequencies to find a BSU with which it can register. Scanning may take several minutes. After establishing a wireless link, the wireless LED stops flashing and continues to shine green.

NOTE: *Because DFS may need to scan for radar on multiple channels, you must allow a sufficient amount of time for the units to start up. This is considerably longer than when the unit is not using DFS. This is expected behavior. Startup time is within four minutes if no radar is detected, but up to one minute is added for every selected channel that results in radar detection.*

DFS is required for two purposes:

1. **Radar avoidance both at startup and while operational.** To meet these requirements, the BSU scans available frequencies at startup for the presence of a radar signal on all available frequencies. If a radar signal is detected on any DFS enabled channel, the system will blacklist the channel for a period of 30 minutes in accordance to EN301-893. Once fully operational on a frequency, the BSU actively monitors the occupied frequency for radar interference. If radar interference is detected, the BSU blacklists the channel, logs a message and rescans to find a new frequency free of radar interference.

Radar detection is performed only by the BSU and not by the SU. When an SU is set to a country in which DFS is used, it scans all available channels upon startup looking for a BSU that best matches its connection criteria (such as **Base Station System Name**, **Network Name**, and **Shared Secret**). The SU connects to the BSU automatically on whatever frequency the BSU has selected. Because of this procedure, it is best to set up the BSU and have it fully operational before installing the SU, although this is not required. If a BSU rescans because of radar interference, the SU loses its wireless link. The SU waits 30 seconds (when the Mobility feature is enabled, the SU starts scanning for a BSU instantly rather than waiting 30 seconds); if it finds that it could not receive the BSU in this amount of time, it rescans the available frequencies for an active BSU.

2. **Guarantee the efficient use of available frequencies by all devices in a certain area.** To meet this requirement, the BSU scans each available frequency upon startup and selects a frequency based upon the least amount of noise and interference detected. This lets multiple devices operate in the same area with limited interference. This procedure is

done only at startup; if another non-radar device comes up on the same frequency, the BSU does not detect this or rescan because of it. It is expected that other devices using these frequencies also are in compliance with country regulations, so this should not happen.

Transmit Power Control

Transmit Power Control is a manual configuration selection to reduce the unit's output power. The maximum output power level for the operating frequency can be found in the event log of the unit's embedded software.

By default, the unit lets you transmit at the maximum output power that the radio can sustain for data rate and frequency selected. However, with Transmit Power Control (TPC), you can adjust the output power of the unit to a lower level in order to reduce interference to neighboring devices or to use a higher gain antenna without violating the maximum radiated output power allowed for your country. Also, most countries in the ETSI regulatory domain require the transmit power to be set to a 6 dB lower value than the maximum allowed EIRP when link quality permits, as part of the DFS requirements.

You can see your unit's current output power for the selected frequency in the event log. The event log shows the selected power for all data rates, so you must look up the relevant data rate to determine the actual power level.

NOTE: *This feature only lets you decrease your output power; you cannot increase your output power beyond the maximum the radio allows for your frequency and data rate.*

See [System Parameters](#) to configure **Country**. See [Configure the Wireless Interface](#) to configure Transmit Power Control.

SU Registration

The list of parameters you must configure for registration of the SU on a BSU are:

- Network Name
- Base Station System Name (when used; otherwise, leave blank)
- Network Secret
- Encryption (when used)
- Frequency Channel (or Roaming, or DFS)

See [System Parameters](#) to see the description of these fields and to configure them.

NOTES:

- *The frequency channel must be the same for the BSU and the SU in order to register the SU when roaming is not enabled and DFS is not required.*
- *Channel Bandwidth and Turbo mode must be the same for the BSU and SU in order to register the SU.*
- *Roaming will automatically select a channel on the SU corresponding to the BSU channel. Roaming is the procedure in which an SU terminates the session with the current BSU and starts the registration procedure with another BSU when it finds the quality of the other BSU to be better.*

Dynamic Data Rate Selection (DDRS)

The WORP Dynamic Data Rate Selection (DDRS) lets the BSU and SUs monitor and calculate the remote average signal-to-noise ratio (SNR) and adjust the transmission data rate to an optimal value to provide the best possible throughput according to the current communication conditions and link quality during run-time.

Each frame received in the WORP protocol reports the signal and noise level in dBm at which the sender received the previous frame from the receiver, and provides the values to calculate the SNR in dB. SNR is calculated according to this formula then averaged:

$$\text{SNR [dB]} = \text{signal level [dBm]} - \text{noise level [dBm]}$$

Both the BSU and the SUs monitor the remote SNR. The BSU monitors and calculates the average remote SNR for each SU that is registered. An SU monitors and calculates the average remote SNR for the BSU.

DDRS is enabled or disabled on the BSU only. This operation requires the BSU to be rebooted. After rebooting, the BSU sends a multicast announcement to all SUs to begin the registration process. During registration, an SU is informed by the BSU whether DDRS is enabled or disabled and it sets its DDRS status accordingly.

There are two DDRS data rates that need to be configured when DDRS is enabled:

- **Default DDRS Data Rate** (*ddrsdefdatarate*): The data rate at which the BSU starts communication with all SUs to begin the registration process (the default is 6 Mbps).
- **Maximum DDRS Data Rate** (*ddrsmaxdatarate*): The maximum data rate at which the device (BSU or SU) can operate (the default is 54 Mbps).

NOTE: *The default (BSU only) and maximum (BSU and SU) DDRS data rate values must be configured in the BSU and SUs separately through the CLI or the SNMP interface.*

Virtual Local Area Networks (VLANs)

Virtual Local Area Networks (VLANs) are logical groupings of network hosts. Defined by software settings, other VLAN members or resources appear (to connected hosts) to be on the same physical segment, no matter where they are attached on the logical LAN or WAN segment. They simplify allowing traffic to flow between hosts and their frequently-used or restricted resources according to the VLAN configuration.

Tsunami MP.11 5012 units are fully VLAN-ready; however, by default, VLAN support is disabled. Before enabling VLAN support (by assigning a VLAN Management ID), certain network settings should be configured and network resources such as VLAN-aware switches should be available, dependent upon the type of configuration.

VLANs are used to conveniently, efficiently, and easily manage your network in the following ways:

- Manage VLAN configuration from a single window
- Define groups
- Reduce broadcast and multicast traffic to unnecessary destinations
- Improve network performance and reduce latency
- Increase security
- Secure network restricts members to resources on their own VLAN

VLAN tagged data is collected and distributed through a unit's Ethernet interface. The units can communicate across a VLAN-capable switch that analyzes VLAN-tagged packet headers and directs traffic to the appropriate ports when the units are working in their Transparent mode.

VLAN features can be managed via:

- The BSU's Web interface
- The Command Line Interface (see "Command Line Interface" in the *Reference Manual*)
- SNMP (see the MIBs provided on the product CD)

For more information about VLAN configuration, see [VLAN Parameters](#).

Quality of Service (QoS)

The Quality of Service (QoS) feature is based on the 802.16 standard and defines the classes, service flows, and packet identification rules for specific types of traffic. QoS main priority is to guarantee a reliable and adequate transmission quality for all types of traffic under conditions of high congestion and bandwidth over-subscription.

Concepts and Definitions

The software supports QoS provisioning from the BSU only. You may define different classes of service on a BSU that can then be assigned to the SUs that are associated, or that may get associated, with that BSU.

The software provides the ability to create, edit, and delete classes of service that are specified by the following hierarchy of parameters:

- Packet Identification Rule (PIR) – up to 64 rules, including 17 predefined rules
- Service Flow class (SFC) – up to 32 SFs, including 7 predefined SFCs; up to 8 PIRs may be associated per SFC
- Priority for each rule within each SF class – 0 to 255, with 0 being lowest priority
- QoS class – up to 8 QoS classes, including 4 predefined classes; up to 4 SFCs may be associated per QoS class

Packet Identification Rule (PIR)

A Packet Identification Rule is a combination of parameters that specifies what type of traffic is allowed or disallowed. The software allows to create up to 64 different PIRs, including 17 predefined PIRs. It provides the ability to create, edit, and delete PIRs that contain none, one, or more of the following classification fields:

- Rule Name
- IP ToS (Layer 3 QoS identification)
- IP Protocol List containing up to 4 IP protocols
- 802.1p tag (layer 2 QoS identification)
- Up to 4 pairs of Source IP address + Mask
- Up to 4 pairs of Destination IP address + Mask
- Up to 4 source TCP/UDP port ranges
- Up to 4 destination TCP/UDP port ranges
- Up to 4 source MAC addresses
- Up to 4 destination MAC addresses
- VLAN ID
- Ether type (Ethernet protocol identification)

A good example is provided by the 17 predefined PIRs. Note that these rules help to identify specific traffic types:

1. All – No classification fields, all traffic matches
2. Cisco VoIP UL
 - a. Protocol Source Port Range (16,000-32,000)
 - b. IP Protocol List (17 = UDP)
3. Vonage VoIP UL
 - a. Protocol Source Port Range (8000-8001, 10000-20000)
 - b. IP Protocol List (17 = UDP)
4. Cisco VoIP DL
 - a. Protocol Destination Port Range (16,000-32,000)
 - b. IP Protocol List (17 = UDP)
5. Vonage VoIP DL

- a. Protocol Destination Port Range (8000-8001, 10000-20000)
- b. IP Protocol List (17 = UDP)
6. TCP
 - a. IP Protocol List (6)
7. UDP
 - a. IP Protocol List (17)
8. PPPoE Control
 - a. Ethertype (type 1, 0x8863)
9. PPPoE Data
 - a. Ethertype (type 1, 0x8864)
10. IP
 - a. Ethertype (type 1, 0x800)
11. ARP
 - a. Ethertype (type 1, 0x806)
12. Expedited Forwarding
 - a. IP TOS/DSCP (low=0x2D, high=0x2D, mask = 0x3F)
13. Streaming Video (IP/TV)
 - a. IP TOS/DSCP (low=0x0D, high=0x0D, mask = 0x3F)
14. 802.1p BE
 - a. Ethernet Priority (low=0, high=0) (this is the equivalent of the User Priority value in the TCI (Tag Control Information) field of a VLAN tag)
15. 802.1p Voice
 - a. Ethernet Priority (low=6, high=6) (this is the equivalent of the User Priority value in the TCI (Tag Control Information) field of a VLAN tag)
16. 802.1p Video
 - a. Ethernet Priority (low=5, high=5) (this is the equivalent of the User Priority value in the TCI (Tag Control Information) field of a VLAN tag)
17. L2 Broadcast/Multicast
 - a. Ethernet Destination (dest = 0x80000000, mask = 0x80000000)

Two different VoIP rule names have been defined for each direction of traffic, Uplink (UL) and Downlink (DL), (index numbers 2 to 5). This has been done to distinguish the proprietary nature of the Cisco VoIP implementation as opposed to the more standard Session Initiation Protocol (SIP) signaling found, for example, in the Vonage-type VoIP service.

Service Flow Class (SFC)

A Service Flow class defines a set of parameters that determines how a stream of application data that matches a certain classification profile will be handled. The software allows to create up to 32 different SFs, including seven predefined SFs. The software provides the ability to create, edit, and delete SFs that contain the following parameters and values:

- Service flow name
- Scheduling type – Best Effort (BE); Real-Time Polling Service (RtPS)
- Service Flow Direction – Downlink (DL: traffic from BSU to SU); Uplink (UL: traffic from SU to BSU)
- Maximum sustained data rate (or Maximum Information Rate, MIR) – specified in units of 1 Kbps from 8 Kbps up to the maximum rate of 108000 Kbps per SU
- Minimum reserved traffic rate (or Committed Information Rate, CIR) – specified in units of 1 Kbps from 0 Kbps up to the maximum rate of 10000 Kbps per SU

- Maximum Latency – specified in increments of 5 ms steps from a minimum of 5 ms up to a maximum of 100 ms
- Tolerable Jitter – specified in increments of 5 ms steps from a minimum of 0 ms up to the Maximum Latency (in ms)
- Traffic priority – zero (0) to seven (7), 0 being the lowest, 7 being the highest
- Maximum number of data messages in a burst – one (1) to four (4), which affects the percentage of the maximum throughput of the system
- Activation state – Active; Inactive

Note that traffic priority refers to the prioritization of this specific Service Flow.

The software tries to deliver the packets within the specified latency and jitter requirements, relative to the moment of receiving the packets in the unit. For delay-sensitive traffic the jitter must be equal to or less than the latency. A packet is buffered until an interval of time equal to the difference between Latency and Jitter (Latency – Jitter) has elapsed. The software will attempt to deliver the packet within a time window starting at (Latency – Jitter) until the maximum Latency time is reached. If the SFC's scheduling type is real-time polling (rtPS), and the packet is not delivered by that time, it will be discarded. This can lead to loss of packets without reaching the maximum throughput of the wireless link. For example, when the packets arrive in bursts on the Ethernet interface and the wireless interface is momentarily maxed out, then the packets at the "end" of the burst may be timed out before they can be sent.

Users are able to set up their own traffic characteristics (MIR, CIR, latency, jitter, etc.) per service flow class to meet their unique requirements. A good example is provided by the seven predefined SFCs:

1. UL-Unlimited BE
 - a. Scheduling Type = Best Effort
 - b. Service Flow Direction = Uplink
 - c. Initialization State = Active
 - d. Maximum Sustained Data Rate = 20 Mbps
 - e. Traffic Priority = 0
2. DL-Unlimited BE (same as UL-Unlimited BE, except Service Flow Direction = Downlink)
3. UL-G711 20 ms VoIP rtPS
 - a. Schedule type = Real time Polling
 - b. Service Flow Direction = Uplink
 - c. Initialization State = Active
 - d. Maximum Sustained Data Rate = 88 Kbps
 - e. Minimum Reserved Traffic Rate = 88 Kbps
 - f. Maximum Latency = 20 milliseconds
 - g. Traffic Priority = 1
4. DL-G711 20 ms VoIP rtPS (same as UL-G711 20ms VoIP rtPS, except Service Flow Direction = Downlink)
5. UL-G729 20 ms VoIP rtPS (same as UL-G711 20ms VoIP rtPS, except Maximum Sustained Data Rate and Maximum Reserved Traffic Rate = 64 Kbps)
6. DL-G729 20 ms VoIP rtPS (same as UL-G729 20ms VoIP rtPS, except Service Flow Direction = Downlink)
7. DL-2Mbps Video
 - a. Schedule type = Real time Polling
 - b. Service Flow Direction = Downlink
 - c. Initialization State = Active
 - d. Maximum Sustained Data Rate = 2 Mbps
 - e. Minimum Reserved Traffic Rate = 2 Mbps
 - f. Maximum Latency = 20 milliseconds
 - g. Traffic Priority = 1

Two different VoIP Service Flow classes for each direction of traffic have been defined (index numbers 3 to 6) which follow the ITU-T standard nomenclatures: G.711 refers to a type of audio companding and encoding that produces a 64 Kbps bitstream, suitable for all types of audio signals. G.729 is appropriate for voice and VoIP applications, but cannot transport music or fax tones reliably. This type of companding and encoding produces a bitstream between 6.4 and 11.8 Kbps (typically 8 Kbps) according to the quality of voice transport that is desired.

QoS Class

A QoS class is defined by a set of parameters that includes the PIRs and SFCs that were previously configured. The software allows creating up to eight different QoS classes, including four predefined QoS classes. Up to four SF classes can be associated to each QoS class, and up to eight PIRs can be associated to each SF class. For example, a QoS class called "G711 VoIP" may include the following SFCs: "UL-G711 20 ms VoIP rtPS" and "DL-G711 20 ms VoIP rtPS". In turn, the SFC named "UL-G711 20 ms VoIP rtPS" may include the following rules: "Cisco VoIP UL" and "Vonage VoIP UL".

The software provides the ability to create, edit, and delete QoS classes that contain the following parameters:

- QoS class name
- Service Flow (SF) class name list per QoS class (up to four SF classes can be associated to each QoS class)
- Packet Identification Rule (PIR) list per SF class (up to eight PIRs can be associated to each SF class)
- Priority per rule which defines the order of execution of PIRs during packet identification process. The PIR priority is a number in the range 0-63, with priority 63 being executed first, and priority 0 being executed last. The PIR priority is defined within a QoS class, and can be different for the same PIR in some other QoS class. If all PIRs within one QoS class have the same priority, the order of execution of PIR rules will be defined by the order of definition of SFCs, and by the order of definition of PIRs in each SFC, within that QoS class.

A good example of this hierarchy is provided by the four predefined QoS classes:

1. Unlimited Best Effort
 - a. SF class: UL-Unlimited BE
PIR: All; PIR Priority: 0
 - b. SF class: DL-Unlimited BE
PIR: All; PIR Priority: 0
2. G711 VoIP
 - a. SF class: UL-G711 20 ms VoIP rtPS
PIR: Vonage VoIP UL; PIR Priority: 1
PIR: Cisco VoIP UL; PIR Priority: 1
 - b. SF class: DL-G711 20 ms VoIP rtPS
PIR: Vonage VoIP DL; PIR Priority: 1
PIR: Cisco VoIP DL; PIR Priority: 1
3. G729 VoIP
 - a. SF class: UL-G729 20 ms VoIP rtPS
PIR: Vonage VoIP UL; PIR Priority: 1
PIR: Cisco VoIP UL; PIR Priority: 1
 - b. SF class: DL-G729 20 ms VoIP rtPS
PIR: Vonage VoIP DL; PIR Priority: 1
PIR: Cisco VoIP DL; PIR Priority: 1
4. 2Mbps Video
 - a. SF class: DL-2Mbps Video
PIR: Streaming Video (IP/TV); PIR Priority: 1

Basic Management

This chapter describes basic features and functionality of the unit. In most cases, configuring these basic features is sufficient. The “Glossary” in the *Tsunami MP.11 Reference Manual* provides a brief explanation of the terms used. For CLI commands you can use for basic management, see “Command Line Interface” in the *Tsunami MP.11 Reference Manual*.


The following topics are discussed in this chapter:

- [Navigation](#)
- [Rebooting and Resetting](#)
- [General Configuration Settings](#)
- [Monitoring Settings](#)
- [Security Settings](#)
- [Default Settings](#)
- [Upgrading the Unit](#)

Navigation

To use the Web Interface for configuration and management, you must access the unit. With ScanTool you can determine the unit’s current IP address. Then enter **http://<ip address>** in your Web browser (for example **http://10.0.0.1**). See [Setting the IP Address](#) for details.

NOTE: If you have your Security Internet Options set to **High**, you may not be able to access the Web interface successfully; a high security setting disables JavaScript, which is required for running Proxim’s Web browser interface. Adding the radio’s IP address as a Trusted site should fix this problem.



The Web Interface also provides online help, which is stored on your computer (see [Install Documentation and Software](#) for details).

Rebooting and Resetting

All configuration changes require a restart unless otherwise stated. New features explicitly state whether a reboot is required or not. You can restart the unit with the **Reboot** command; see the first method described in the following sub-sections.

Most changes you make become effective only when the 5012 is rebooted. A reboot stores configuration information in non-volatile memory and then restarts the 5012 with the new values (see [Soft Reset to Factory Default](#)).

In some cases, the 5012 reminds you that a reboot is required for a change to take effect. You need not reboot immediately; you can reboot after you have made all your changes.

NOTE: *Saving of the unit's configuration occurs only during a controlled reboot or by specifically issuing the CLI Save command. If you make changes to settings without a controlled reboot (command) and you have not issued the Save command, a power outage would wipe out all changes since the last reboot. For example, entering static routes takes effect immediately; however, the routes are not saved until the unit has gone through a controlled reboot. Proxim strongly recommends saving your settings immediately when you finish making changes.*

Rebooting


When you reboot, the changes you have made become effective and the 5012 is restarted. The changes are saved automatically in non-volatile memory before the actual reboot takes place.

To reboot, click the **Commands** button, then the **Reboot** tab. Click the **Reboot** button. The 5012 restarts the embedded software. During reboot, you are redirected to a page showing a countdown timer, and you are redirected to the **Status** page after the timer counts down to 0 (zero). The CLI is disconnected during reboot. This means that a new telnet session must be started.

Resetting Hardware

If the unit does not respond for some reason and you are not able to reboot, you can restart by means of a hardware reset. This restarts the hardware and embedded software. The last saved configuration is used. Any changes that you have made since then are lost.

To reset the hardware, press and release the RESET button on the 5012 unit with, for example, a pencil.



Soft Reset to Factory Default

If necessary, you can reset the unit to the factory default settings. *This must be done only when you are experiencing problems.* Resetting to the default settings requires you to reconfigure the 5012. To reset to factory default settings:

1. Click the **Commands** button, then the **Reset** tab.
2. Click the **Reset to Factory Default** button. The device configuration parameter values are reset to their factory default values.

If you do not have access to the unit, you can use the procedure described in [Hard Reset to Factory Default](#) as an alternative.

General Configuration Settings

- **System Status:** The status tab showing the system status is displayed automatically when you log into the Web interface. It is also the default window displayed when you click the **Status** button on the left side of the window. See [View System Status](#) for more information.
- **System Configuration:** The System Configuration window lets you change the unit's *country*, *system name*, *location name*, and so on (see the window to the right). The Country selection is required to enable the correct radio parameters. The other details help distinguish this unit from other routers, and let you know whom to contact in case of problems. See [System Parameters](#) for more information.
- **IP Configuration:** The **IP Configuration** window lets you change the unit's IP parameters. These settings differ between **Routing** and **Bridge** mode. See [Network Parameters](#) for more information.
- **Interface Configuration:** The **Interface** configuration pages let you change the Ethernet and Wireless parameters. The **Wireless** tab is displayed by default when you click the **Interfaces** tab.
- **Ethernet:** To configure the **Ethernet** interface, click the **Configure** button, the **Interfaces** tab, and the **Ethernet** sub-tab. You can set the **Configuration** parameter from this tab for the type of Ethernet transmission. The recommended setting is **auto-speed auto-duplex**. See [Configure the Ethernet Interface](#) for more information.
- **Wireless:** To configure the **wireless** interface, click the **Configure** button followed by the **Interfaces** tab; then click the **Wireless** sub-tab. For BSUs, the wireless interface can be placed in either **WORP Base** or **WORP Satellite** mode (selected from the **Interface Type** drop-down box). SUs can be placed only in **WORP Satellite** mode. (See [Interface Parameters](#) for more information.)
- **VLAN Configuration:** To configure BSU VLAN parameters, click the **Configure** button followed by the **VLAN** tab; the **BSU Table** tab is displayed. Click the **SUs' Table** tab to configure SU VLAN parameters. Virtual LAN (VLAN) implementation in the Tsunami MP.11 products lets the BSU and SU be used in a VLAN-aware network and processes IEEE 802.1Q VLAN-tagged packets. Network resources behind the BSU and SU can be assigned to logical groups. See [VLAN Parameters](#) for more information.

Monitoring Settings

The unit offers various facilities to monitor its operation and interfaces. Only the most significant monitoring categories are mentioned here.

- **Wireless:** To monitor the wireless interfaces, click the **Monitor** button and the **Wireless** tab. This tab lets you monitor the general performance of the radio and the performance of the **WORP Base** or **WORP Satellite** interfaces.
- **Interfaces:** To monitor transmission details, click the **Monitor** button and the **Interfaces** tab. The **Interfaces** tab provides detailed information about the MAC-layer performance of the wireless network and Ethernet interfaces.
- **Per Station:** Click the **Monitor** button and the **Per Station** tab to view **Station Statistics**. On the SU, the **Per Station** page shows statistics of the BSU to which the SU is registered. On the BSU, it shows statistics of all the SU's connected to the BSU. The page's statistics refresh every 4 seconds.

Security Settings

To prevent misuse, the 5012 provides wireless data encryption and password-protected access. *Be sure to set the encryption parameters and change the default passwords.*

In addition to Wired Equivalent Privacy (WEP), the units support Advanced Encryption Standard (AES) 128-bit encryption. Two types of the AES encryption are available. Previous releases supported only the AEC-OCB; the AES CCM protocol is now also supported.

Proxim highly recommends you change the **Network Name**, **Encryption Key**, and **Shared Secret** as soon as possible. To do so, click the **Configure** button and the **Interfaces** tab; then click the **Wireless** sub-tab. The encryption key is set using the **Security** tab. For systems that will use roaming features, the **Network Name**, **Encryption Key**, and the **Shared Secret** should each be the same for all SUs that are allowed to roam as well as for all BSUs to which these SUs are allowed to roam.

Encryption

You can protect the wireless data link by using encryption. Encryption keys can be 5 (64-bit), 13 (WEP 128-bit), or 16 (AES 128-bit) characters in length. Both ends of the wireless data link must use the same parameter values.

To set the encryption parameters, click the **Configure** button, the **Security** tab, and the **Encryption** sub-tab. See [Configure Encryption Parameters](#).

Passwords

Access to the units are protected with passwords. The default password is **public**. For better security it is recommended to change the default passwords to a value (6-32 characters) known only to you.

To change the unit's HTTP, Telnet, or SNMP passwords, click the **Configure** button, the **Management** tab, and the **Password** sub-tab. See [Configure Passwords](#).

Default Settings

Feature	Default Setting
System Name	Tsunami MP.11 5012
Mode of Operation	Bridge
Routing	Disabled
IP Address Assignment Type	Static
IP Address	10.0.0.1
Subnet Mask	255.255.255.0
Default Router IP Address	10.0.0.1
Default TTL	64
RIPv2	Enabled when in Routing Mode
Base Station System Name	<blank>
Network Name	OR_WORP
Frequency Channel	Channel 149, Frequency 5.745 GHz (FCC Only devices) DFS Enabled (World Mode devices)
Transmit Power Control (TPC)	0 dB
Data Rate	36 Mbps
Channel Bandwidth	20 MHz (not configurable)
VLAN	Disabled
Registration Timeout	5
Network Secret	Public
Serial port Baud Rate (for factory use only)	9600
SNMP Management Interface	Enabled
Telnet Management Interface	Enabled
HTTP Management Interface	Enabled
HTTP Port	80
Telnet Port	23
Telnet Login Timeout	30
Telnet Session Timeout	900
Password	public
Maximum Satellites (per BSU)	250
MAC Authentication	Disabled
Radius Authentication	Disabled
Encryption	Disabled
Static MAC Address Filter	Disabled / No Entries
Ethernet Protocol Filtering	All Filters Disabled
DFS Priority Frequency Channel	Disabled
Announcement Period (when roaming enabled)	100 ms
Multi-Frame Bursting	Enabled
Storm Threshold	Broadcast/Multicast Unlimited
Broadcast Protocol Filtering	All Protocols Allowed
Dynamic Data Rate Selection	Disabled
Roaming	Disabled
NAT	Disabled
Intra-Cell Blocking	Disabled
Antenna Alignment	Disabled

Feature	Default Setting
Country Selection	US-only device – US World device – GB
DHCP Server	Disabled
DHCP Relay	Disabled
Spanning Tree Protocol	Disabled
Antenna Gain	0 (For DFS Threshold compensation)
Satellite Density	Large
VLAN Mode	BSU: Transparent Mode SU: Transparent mode when BSU is in Transparent mode; Trunk mode when the BSU is in Trunk mode.
Access VLAN ID	BSU: N/A; SU: 1
Access VLAN Priority	BSU: N/A; SU: 0
Management VLAN ID	BSU: -1; SU: -1
Management VLAN Priority	BSU: 0; SU: 0
Trunk VLAN ID	BSU: N/A; SU: -1

Upgrading the Unit

The units are equipped with embedded software that can be updated when new versions are released. Updating the embedded software is described [Web Interface Image File Download](#). A TFTP server is provided on the Documentation and Software CD; the server is required to transfer the downloaded file to the unit. See [TFTP Server Setup](#).

To access all resolved problems in our solution database, or to search by product, category, keywords, or phrases, go to <http://support.proxim.com>. You can also find links to drivers, documentation, and downloads at this link.

System Status

This section describes viewing system status and event log information from the unit's Web Interface.

Click on the **Status** button to access system and event log information. See the following sections:

- [View System Status](#)
- [View the Event Log Contents](#)

Help and Exit buttons also appear on each page of the Web interface; click the **Help** button to access online help; click the **Exit** button to exit the application.

For an introduction to the basics of management, see [Basic Management](#).

View System Status

The **Status** tab showing the system status is displayed automatically when you log into the Web Interface. It also is the default window displayed when you click the **Status** button on the left side of the window.

The **Status** tab shows the **System Status** and the **System Traps**.

The screenshot displays the Web Interface for the Tsunami MP.11. On the left is a navigation sidebar with buttons for Status, Configure, Monitor, Commands, Help, and Exit. The main content area has two tabs: Status (selected) and Event Log. Under the Status tab, the 'System Status' section shows the device name 'Tsunami MP.11 SN- 04AT35580031' and a table of system information:

IP Address	10.0.0.1	Contact	Contact Name
Name	Tsunami MP.11	Location	Contact Location
Object ID	1.3.6.1.4.1.11898.2.4.9	Up Time (DD:HH:MM:SS)	00:00:00:55

Below the table is a link: [Click here to view event log messages.](#) This page may take a minute to load.

The 'System Traps' section contains a table with two rows of traps, each with a checkbox, a description, severity, and time stamp. Above the table are 'Select All' and 'Deselect All' buttons, and below is a 'Delete' button.

	Description	Severity	Time Stamp
<input type="checkbox"/>	OR Cold Started.	Informational	0 days 0 hrs 0 m 0 s
<input type="checkbox"/>	Link Up. Interface Index : 1	Informational	0 days 0 hrs 0 m 1 s

System Status


The basic system status is shown in this section, including the version number of the embedded software.

Systems Traps

The status of system traps is shown in this section. System traps occur when the 5012 encounters irregularities. Deleting system traps has no effect on the operation of the 5012. System traps also are sent to an SNMP manager station (if so configured). See "Alarm Traps" in the *Tsunami MP.11 Reference Manual* for a list and description of the traps.

View the Event Log Contents

Click the **Status** button and the **Event Log** tab to view the contents of your Event Log. The **Event Log** keeps track of events that occur during the operation of the 5012. The **Event Log** displays messages that may not be captured by System Traps, such as the **Transmit Power** for the **Frequency Channel** selected.



See “Event Log Error Messages” in the *Tsunami MP.11 Reference Manual* for an explanation of messages that can appear in the Event Log.

6

Configuration

This section describes configuring the 5012's settings using the unit's Web Interface.

Click the **Configure** button to access configuration settings.

The following topics are discussed in this section:

- [System Parameters](#)
- [Network Parameters](#)
- [Interface Parameters](#)
- [SNMP Parameters](#)
- [RIP Parameters](#)
- [Management Parameters](#)
- [Security Parameters](#)
- [Configure Packet Filtering](#)
- [Intra-Cell Blocking \(Base Station Unit only\)](#)
- [VLAN Parameters](#)
- [QoS \(Quality of Service\) Parameters](#)
- [SU Access to the Public Network \(NAT\)](#)

Help and Exit buttons also appear on each page of the Web interface; click the **Help** button to access online help; click the **Exit** button to exit the application.

For an introduction to the basics of management, see [Basic Management](#).

System Parameters

The **System** configuration page lets you change the 5012's **System Name**, **Location**, and so on. These details help you to distinguish the unit from other routers and let you know whom to contact in case you experience problems.

Click the **Configure** button and the **System** tab; the following window is displayed.

In this window, you can view or change the basic system information. **Mode of Operation** sets the unit as **bridge** (layer 2) or as **router** (layer 3). See [Bridge and Routing Modes](#) for more information.

You can enter the following details:

- **System Name:** This is the system name for easy identification of the BSU or SU. The System Name field is limited to a length of 32 bytes. Use the system name of a BSU to configure the Base Station System Name parameter on an SU if you want the SU to register only with this BSU. If the Base Station System Name is left blank on the SU, it can register with any Base Station that has a matching Network Name and Network Secret.
- **Country:** The Dynamic Frequency Selection (DFS) is enabled automatically when you choose a country with a regulatory domain that requires it. The Country selection pre-selects and displays only the allowed frequencies for the selected country.

Click the **Configure** button, the **Interfaces** tab, and the **Wireless** sub-tab to see the channel/frequency list for the selected Country.

NOTE: Units sold in the United States are pre-configured to scan and display only the outdoor frequencies permitted by the FCC. No other Country selections, channels, or frequencies can be configured. Units sold outside of the United States and Canada support the selection of a Country by the professional installer. If you change the Country, a reboot of the unit is necessary for the upgrade to take place.

Support for the 5.25 – 5.35 GHz and 5.725 – 5.825 GHz frequency bands is provided with a single country selection, **UNITED STATES (US)**, which does not provide DFS capability in these frequency bands.

For a non US-only device, the default country selected is **United Kingdom (GB)**.

Note the following:

- The channel center frequencies are not regulated; only the band edge frequencies are regulated.
- If, before upgrade, US was selected as a country for a non US-Only device (which is an incorrect configuration), the country is changed automatically to United Kingdom upon upgrade.

See [Country Codes and Channels](#) for a list of country codes.

- **Location:** This field can be used to describe the location of the unit, for example “Main Lobby.”
- **Contact Name, Contact Email, and Contact Phone:** In these fields, you can enter the details of the person to contact.
- **Mode of Operation:** This field lets you choose one of two operating modes: **Bridge** mode or **Routing** mode.

The static fields on this window are described as follows:

- **ObjectID:** This field shows the OID of the product name in the MIB.
- **Ethernet MAC Address:** The MAC address of the Ethernet interface of the device.
- **Descriptor:** Shows the product name and firmware build version.
- **Up Time:** The length of time the device has been up and running since the last reboot.

Bridge and Routing Modes

Bridge Mode

A bridge is a product that connects a local area network (LAN) to another local area network that uses the same protocol (for example, Ethernet). You can envision a bridge as being a device that decides whether a message from you to someone else is going to the local area network in your building or to someone on the local area network in the building across the street. A bridge examines each message on a LAN, passing those known to be within the same LAN, and forwarding those known to be on the other interconnected LAN (or LANs).

In bridging networks, computer or node addresses have no specific relationship to location. For this reason, messages are sent out to every address on the network and accepted only by the intended destination node. Bridges learn which addresses are on which network and develop a learning table so that subsequent messages can be forwarded to the correct network.

Bridging networks are generally always interconnected LANs since broadcasting every message to all possible destination would flood a larger network with unnecessary traffic. For this reason, router networks such as the Internet use a scheme that assigns addresses to nodes so that a message or packet can be forwarded only in one general direction rather than forwarded in all directions.

A bridge works at the data-link (physical) layer of a network, copying a data packet from one network to the next network along the communications path.

The default Bridging Mode is **Transparent Bridging**.

This mode works if you do not use source routing in your network. If your network is configured to use source routing, then you should use either Multi-Ring SRTB or Single-Ring SRTB mode.

In Multi-Ring SRTB mode, each unit must be configured with the Bridge number, Radio Ring number, and Token Ring number. The Radio Ring number is unique for each Token Ring Access Point and the Bridge number is unique for each Token Ring Access Point on the same Token Ring segment.

Alternatively, you may use the Single-Ring SRTB mode. In this mode, only the Token Ring number is required for configuration.

Routing Mode

Routing mode can be used by customers seeking to segment their outdoor wireless network using routers instead of keeping a transparent or bridged network. By default the unit is configured as a bridge device, which means traffic between different outdoor locations can be seen from any point on the network.

By switching to routing mode, your network now is segmented by a layer 3 (IP) device. By using Routing mode, each network behind the BSU and SUs can be considered a separate network with access to each controlled through routing tables.

The use of a router on your network also blocks the retransmission of broadcast and multicast packets on your networks, which can help to improve the performance on your outdoor network in larger installations.

The use of Routing mode requires more attention to the configuration of the unit and thorough planning of the network topology of your outdoor network. The unit can use Routing mode in any combination of BSU and SUs. For example, you may have the BSU in Routing mode and the SU in Bridge mode, or vice versa.

When using Routing mode, pay close attention to the configuration of the default gateway both on your unit and on your PCs and servers. The default gateway controls where packets with unknown destinations (Internet) should be sent. Be sure that each device is configured with the correct default gateway for the next hop router. Usually this is the next router on the way to your connection to the Internet. You can configure routes to other networks on your Intranet through the addition of static routes in your router's routing table.

Key Reasons to Use Routing Mode

One key reason why customers would use Routing mode is to implement virtual private networks (VPNs) or to let nodes behind two different SUs communicate with each other. Many customers do this same thing in Bridging mode by using secondary interfaces on the router at the BSU or virtual interfaces at the BSU in VLAN mode to avoid some of the drawbacks of IP Routing mode.

Routing mode prevents the transport of non-IP protocols, which may be desirable for Service Providers. Routing mode is theoretically more efficient because Ethernet headers are not transported and non-IP traffic is blocked.

Benefits of using Routing Mode

- Enabling RIP makes the 5012 easier to manage for a Service Provider that uses RIP to dynamically manage routes. RIP is no longer very common for Service Providers or Enterprise customers and an implementation of a more popular routing protocol like OSPF would be desirable.
- Routing mode saves bandwidth by not transporting non-IP protocols users might have enabled, like NetBEUI or IPX/SPX, which eliminates the transmission of broadcasts and multicasts.

- The MAC header is:
 - Destination MAC 6 bytes
 - Source MAC 6 bytes
 - Ethernet Type 2 bytes


If the average packet size is 1000 bytes, the overhead saved is 1.5%; With a frame size of 64 bytes, the overhead saved is 20%; and for frame sizes of 128 bytes, the saving is 10%. Network researches claim that most network traffic consists of frames smaller than 100 bytes.

In order to support routers behind the SUs with multiple subnets and prevent routing loops, you want individual routes (and more then one) per SU.

Routing Mode Examples

In the first example, both the BSU and the SUs are configured for Routing mode. This example is appropriate for businesses connecting remote offices that have different networks.

In example 2, the BSU is in Routing mode and the SUs are in Bridge mode. Notice the PCs behind the SUs must configure their default gateways to point to the BSU, not the SU.



Notes:


- One of the most important details to pay attention to in Routing mode are the unit's and the PC's default gateways. It is a common mistake to set up the PC's gateway to point to the SU when the SU is in Bridge mode and the BSU is in Routing mode. Always check to make sure the PCs on your network are configured to send their IP traffic to the correct default gateway.
- Be sure to reboot the unit to permanently save static routes. New routes take effect immediately without a reboot, but are not permanently saved with your configuration until you do reboot the device. An unexpected power outage could cause static routes you entered to "disappear" when the unit reboots if they have not been saved. You also should save a copy of your unit's configuration file in case the unit must be reloaded. This saves you from being required to re-enter numerous static routes in a large network.
- The routing table supports up to 500 static routes.

Network Parameters

Change IP Parameters

The IP Configuration window lets you change the 5012 IP parameters. These settings differ when the 5012 is in **Routing** mode.

Click the **Configure** button, the **Network** tab, and the **IP Configuration** sub-tab to view and configure local IP address information. See [Setting the IP Address](#) for more information.



If the device is configured in **Bridge** mode, you can set the **IP Address Assignment Type** parameter:

- Select **Static** if you want to assign a static IP address to the unit.
- Select **Dynamic** to have the device run in DHCP client mode, which gets an IP address automatically from a DHCP server over the network.

If you do not have a DHCP server or if you want to manually configure the IP settings, set this parameter to **Static**.

When the 5012 is in **Bridge** mode, only one IP address is required. This IP address also can be changed with ScanTool (see [Setting the IP Address](#)). In **Routing** mode, both Ethernet and Wireless interfaces require an IP address.

You can set the following remaining parameters only when the **IP Address Assignment Type** is set to **Static**.

- **IP Address:** The unit's static IP address (default IP address is 10.0.0.1).
- **Subnet Mask:** The mask of the subnet to which the 5012 is connected (the default subnet mask is 255.255.255.0).
- **Default Router IP Address:** The IP address of the default gateway.
- **Default TTL:** The default time-to-live value.

Configure Spanning Tree Options

This protocol is executed between the bridges to detect and logically remove redundant paths from the network. Spanning Tree can be used to prevent link-layer loops (broadcast is forwarded to all port where another device may forward it and, finally, it gets back to this unit; therefore, it is looping). Spanning Tree can also be used to create redundant links and operates by disabling links: hot standby customer is creating a redundant link without routing function.

If your network does not support Spanning Tree, be careful to avoid creating network loops between radios. For example, creating a WDS link between two units connected to the same Ethernet network creates a network loop (if spanning tree is disabled).

The Spanning Tree configuration options are advanced settings. Proxim recommends that you leave these parameters at their default values unless you are familiar with the Spanning Tree protocol.

Click the **Spanning Tree** tab to change Spanning Tree values.

The screenshot shows the 'Spanning Tree' configuration page. At the top, there are tabs for 'Security', 'Filtering', 'Intra-Cell Blocking', 'VLAN', and 'QoS'. Below these are 'System', 'Network', 'Interfaces', 'SNMP', 'RIP', and 'Management'. The 'Spanning Tree' tab is active, showing a configuration form with the following fields:

- Spanning Tree Status: **Disable** (dropdown)
- Bridge Priority: **32768**
- Max Age (1/100 sec.): **2000**
- Hello Time (1/100 sec.): **200**
- Forward Delay (1/100 sec.): **1500**

Below the form are 'OK' and 'Cancel' buttons. A section titled 'Priority and Path Cost Table' contains a table with the following data:

Port	Priority	Path Cost	State	Status
1	128	100	Forwarding	Enable
2	128	100	Disabled	Enable
3	128	100	Disabled	Enable
4	128	100	Disabled	Enable
5	128	100	Disabled	Enable
6	128	100	Disabled	Enable
7	128	100	Disabled	Enable
8	128	100	Disabled	Enable
9	128	100	Disabled	Enable
10	128	100	Disabled	Enable
...				
246	128	100	Disabled	Enable
247	128	100	Disabled	Enable
248	128	100	Disabled	Enable
249	128	100	Disabled	Enable
250	128	100	Disabled	Enable
251	128	100	Disabled	Enable

An 'Edit Table Entries' button is located at the bottom of the table.


Click **Edit Table Entries** to make changes; enter your changes and click **OK**.

The screenshot shows the 'Edit Table Entries' dialog box. It contains a table with the following columns: 'Port', 'Priority', 'Path Cost', and 'Status'. Each row has input fields for the first three columns and a dropdown menu for the 'Status' column. The 'Status' dropdowns are currently set to 'Enable'. Below the table is a 'NOTE: Changes made will only take effect after the device is rebooted.' and 'OK', 'Cancel', and 'Back' buttons.


Port	Priority	Path Cost	Status
1	128	100	Enable
2	128	100	Enable
3	128	100	Enable
4	128	100	Enable
5	128	100	Enable
6	128	100	Enable
7	128	100	Enable
8	128	100	Enable
9	128	100	Enable
10	128	100	Enable
11	128	100	Enable
12	128	100	Enable
13	128	100	Enable
14	128	100	Enable
15	128	100	Enable
16	128	100	Enable
17	128	100	Enable
18	128	100	Enable
19	128	100	Enable
20	128	100	Enable
...			
248	128	100	Enable
249	128	100	Enable
250	128	100	Enable
251	128	100	Enable

Configure IP Routes (Routing Mode only)

Click the **Configure** button, the **Network** tab and the **IP Routes** sub-tab to configure IP routes. You cannot configure IP Routes in **Bridge** mode. In **Routing** mode, the **Add Table Entries** and **Edit/Delete Table Entries** buttons are enabled.




Click the **Add** button to add entries; a window such as the following is displayed:



Enter the route information and click **Add**. The **IP Address** and **Subnet Mask** combination is validated for a proper combination.

NOTE: When adding a new entry, the IP address of the Route Destination must be in either the Ethernet subnet or in the wireless subnet of the unit.

Click the **Edit/Delete Table Entries** button to make changes to or delete existing entries.



Edit the route information and click OK. The IP address and subnet mask combination is validated for a proper combination.

Enable or Disable Roaming

Roaming is a feature by which an SU terminates the session with the current BSU and starts the registration procedure with another BSU when it finds the quality of the other BSU to be better. Roaming provides MAC level connectivity to the SU that roams from one BSU to another. Roaming takes place across the range of frequencies and channel bandwidths (5, 10, or 20 MHz) that are available per configuration (for a 5012 unit only the 20 MHz bandwidth is applicable). The current release offers handoff times of up to a maximum of 80 ms. This is fast enough to allow the SU to seamlessly roam from one BSU to the other therefore supporting session persistence for delay-sensitive applications. The feature also functions as BSU backup in case the current BSU fails or becomes unavailable.

The Roaming feature lets the SU monitor local SNR and data rate for all frames received from the current BSU. As long as the average local SNR for the current BSU is greater than the slow scanning threshold, and the number of retransmitted frames is greater than the slow scanning threshold given in percentage, the SU does not scan other channels for a better BSU.

- The **normal scanning** procedure starts when the average local SNR for the current BSU is less than or equal to the slow scanning threshold and the number of retransmitted frames is greater than the slow scanning threshold given in percentage. During the normal scanning procedure the SU scans the whole list of active channels while maintaining the current session uninterrupted.
- **Fast scanning** is the scanning procedure performed when the average local SNR for the current BSU is very low (below the fast scanning threshold) and the number of retransmitted frames is greater than the fast scanning retransmission threshold given in %, so that the current session should terminate as soon as possible. During this procedure, the SU scans other active channels as fast as possible.

Roaming can only occur if the normal scanning or fast scanning procedure is started under the following conditions:

1. If the roaming is started from the normal scanning procedure (after the SU scans all the active channels), the SU selects the BSU with the best SNR value on all available channels. The SU roams to the best BSU only if the SNR value for the current BSU is still below the slow scanning SNR threshold, and best BSU offers a better SNR value for at least roaming threshold than the current BSU. The SU starts a new registration procedure with the best BSU without ending the current session.
2. If the roaming is started from the fast scanning procedure, the SU selects the first BSU that offers better SNR than the current BSU, and starts a new registration procedure with the better BSU without ending the current session.

Roaming with Dynamic Data Rate Selection (DDRS) Enabled

When an SU roams from BSU-1 to BSU-2 and DDRS is enabled, the data rate at which the SU connects to BSU-2 is the default DDRS data rate. If this remains at the factory default of 6 Mbps, there can be issues with the application if it requires more than 6 Mbps (for example multiple video streams).

Applications requiring a higher data rate could experience a slight data loss during the roaming process while DDRS selects a higher rate (based upon link conditions).

When the applications re-transmit at a possibly slower rate, the WORP protocol initially services the data at 6 Mbps and increases the data rate up to the "Maximum DDRS Data Rate" (*ddrsmaxdatarate*) one step at a time. Because the applications are not being serviced at the best possible rate, they further slow down the rate of data send.

The DDRS algorithm requires data traffic (a minimum of 128 frames) to raise the rate to a higher value. Although roaming occurs successfully, the previous scenario causes applications to drop their sessions; hence session persistence is not maintained.

For a discussion on how to configure DDRS, see [Dynamic Data Rate Selection \(DDRS\)](#).

NOTE: *You must know the data rate required for the applications running and you must ensure (during network deployment) that the ranges and RF links can support the necessary data rate. You also must set the default*


DDRS data rate at the capacity necessary for the application so that it connects to the next Base Station at the required capacity if roaming occurs. Set the "Default DDRS Data Rate" (ddrsdefdatarate) to a greater value (24, 36, 48 or 54 Mbps, for example) for applications requiring session persistence when roaming occurs.

Click the **Configure** button, the **Network** tab and the **Roaming** sub-tab to configure Roaming. The screen differs depending on whether the unit is configured as a BSU or as an SU.

BSU Screen

Enable or disable the Roaming feature by selecting the **Enable Roaming Status** check box. The default value is disabled (clear). If you enable roaming, you may set the **Announcement Period** (from 25 to 100 ms, default is 100 ms).

On this screen you may also enable or disable the **Multi-Frame Bursting** (default value is enabled).




An SU scans all available channels for a given bandwidth during roaming. In order to reduce the number of channels an SU has to scan and thus decrease the roaming time, a channel priority list that tells the SU what channels to scan is implemented. Each channel in the channel priority list is specified with its corresponding bandwidth and the priority with which it should be scanned, either "Active" (standard priority), "Active High" (high priority), or "Inactive".

An SU will scan all channels indicated as "Active" during roaming. However, it will scan active channels indicated as "High Priority" before scanning active channels indicated as standard priority. Channels that are not going to be used in the wireless network should be configured as "Inactive" so that the SU can skip over those channels during scanning saving this way time.

A BSU broadcasts the channel priority list to all valid authenticated SUs in its sector. It re-broadcasts the channel priority list to all SUs every time the list is updated on the BSU.

Click **Edit Table Entries** to make changes; enter your changes and click **OK**.



Note that an SU may roam from one BSU with a bandwidth setting to another BSU with a different bandwidth setting. Since in this case more channels need to be scanned than with only one channel bandwidth setting, it is important that the channel priority list mentioned above is properly used to limit scanning time.


When **Scanning Across Bandwidth** on the SU is enabled (see [Interface Parameters](#)), the SU supports bandwidth selection of the communications channel of either 20 MHz, 10 MHz, or 5 MHz. This allows the BSUs in the network to be set to different bandwidths while an SU can still roam from one BSU to the next, because it will not only scan other frequencies (when the signal level or quality are lower than the threshold) but it will also switch to other bandwidths to find a BSU that may be on another bandwidth than its current one.

During roaming, the SU will start scanning first the channels on its current bandwidth from the “Active” channel list provided by the BSU in order to find a BSU to register, since that is the most likely setting for other BSUs in the network. If the SU cannot find an acceptable roaming candidate, it will switch bandwidth and start scanning channels on that corresponding bandwidth from the “Active” channel list provided by the BSU. The process is repeated until the SU finds an appropriate BSU to register.

In the example above, an SU whose current bandwidth is 20 MHz will start scanning all active channels within the bandwidth of 20 MHz. If it cannot find a suitable BSU, it will switch to a 10 MHz bandwidth and start scanning all active channels within that bandwidth, in this case channel 56 first since it is configured as high priority and channel 60 next. No channels will be scanned on the 5 MHz bandwidth since all those channels are configured as inactive.

SU Screen


Enable or disable the Roaming feature in the **Roaming Status** drop-down box. The default value is disabled.



NOTE: To enable roaming, you must enable **Roaming Status** on both the BSU and the SU.

Enable and Configure the DHCP Server

Click the **Configure** button, the **Network** tab and the **DHCP Server** sub-tab to enable the unit on a DHCP Server. The **Gateway IP Address** and **Primary DNS IP Address** must be entered, there must be at least one entry in the DHCP Server IP Pool Table, and the DHCP Relay Agent must be disabled, in order to enable the DHCP Server.



When enabled, the DHCP server allows allocation of IP addresses to hosts on the Ethernet side of the SU or BSU. Specifically, the DHCP Server feature lets the SU or BSU respond to DHCP requests from Ethernet hosts with the following information:

- Host IP address
- Gateway IP address
- Subnet Mask
- DNS Primary Server IP address
- DNS Secondary Server IP

The following parameters are configurable:

- **DHCP Server Status:** Verify that DHCP Relay Agent is disabled. After you have made at least one entry in the DHCP server IP Pool Table, enable DHCP Server by selecting "Enable" from the **DHCP Server Status** pull-down menu.

NOTE: There must be at least one entry in the DHCP server IP Pool Table to enable DHCP server. Also, DHCP server cannot be enabled if DHCP Relay Agent is enabled.

- **Subnet Mask:** The unit supplies this subnet mask in its DHCP response to a DHCP request from an Ethernet host. Indicates the IP subnet mask assigned to hosts on the Ethernet side using DHCP.
- **Gateway IP Address:** The 5012 supplies this gateway IP address in the DHCP response. Indicates the IP address of a router assigned as the default gateway for hosts on the Ethernet side.
- **Primary DNS IP Address:** The 5012 supplies this primary DNS IP address in the DHCP response. Indicates the IP address of the primary DNS server that hosts on the Ethernet side uses to resolve Internet host names to IP addresses
- **Secondary DNS IP Address:** The 5012 supplies this secondary DNS IP address in the DHCP response.
- **Number of IP Pool Table Entries:** The number of IP pool table entries is a read-only field that indicates the total number of entries in the DHCP server IP Pool Table. See [Add Entries to the DHCP Server IP Pool Table](#).

Add Entries to the DHCP Server IP Pool Table

You can add up to 20 entries in the IP Pool Table. An IP address can be added if the entry's network ID is the same as the network ID of the device. To add an entry click **Add Table Entries**.

The screenshot shows a web-based configuration interface for a network device. The main menu includes Security, Filtering, QoS, System, Network, Interfaces, SNMP, RIP, and Management. The 'Network' menu is expanded to show IP Configuration, Spanning Tree, IP Routes, Roaming, DHCP Server, and DHCP RA. The 'DHCP Server' sub-menu is selected, and the 'Add Table Entries' form is displayed. The form has a table with columns: Start IP, End IP, Default Lease, Max Lease, Comment, and Status. Below the table, there are input fields for Start IP Address, End IP Address, Default Lease Time, Max Lease Time, and Comment. A note states: 'Note: The Start and End IP address have to be in the configured subnet. The Default and Maximum Lease Time must be in the range of 3600 - 86400 seconds'. At the bottom, there is another note: 'NOTE: The value added will take effect only after the device is rebooted'. Buttons for 'Add', 'Cancel', and 'Back' are at the bottom of the form.

Enter the following parameters and click **Add**.


NOTE: After adding entries, you must reboot the unit before the values take effect.

The following parameters are configurable:

- **Start IP Address:** Indicates the starting IP address that is used for assigning address to hosts on the Ethernet side in the configured subnet.
- **End IP Address:** Indicates the ending IP address that is used for assigning address to hosts on the Ethernet side in the configured subnet.
- **Default Lease Time:** Specifies the default lease time for IP addresses in the address pool. The value is 3600-86400 seconds.
- **Max Lease Time:** The maximum lease time for IP addresses in the address pool. The value is 3600-86400 seconds.
- **Comment:** The comment field is a descriptive field of up to 255 characters.

Edit/Delete Entries to the DHCP Server IP Pool Table Entries

Click **Edit/Delete Table Entries** to make changes; enter your changes and click **OK**.



Enable the DHCP Relay Agent (Routing mode only)


Click the **Configure** button, the **Network** tab, and the **DHCP RA** sub-tab to enable the 5012 DHCP Relay Agent. When enabled, the DHCP relay agent forwards DHCP requests to the set DHCP server. There must be at least one entry in the corresponding Server IP Address table in order to enable the DHCP Relay Agent.

Note that DHCP Relay Agent parameters are configurable only in **Routing** mode. It cannot be enabled when NAT or DHCP Server is enabled.



Add Entries to the DHCP Relay Agent Table


To add entries to the table of DHCP Relay Agents, click **Add Table Entries**; the following window is displayed.



Enter the **Server IP Address** and any optional comments; click **Add**.

Edit/Delete Entries to the DHCP Relay Agent Table

Click **Edit/Delete Table Entries** to make changes; enter your changes and click **OK**.



Interface Parameters

Configure the Wireless Interface

To configure the wireless interface, click the **Configure** button followed by the **Interfaces** tab; then click the **Wireless** sub-tab.

For Base Station units, the wireless interface can be placed in either WORP Base or WORP Satellite mode (selected from the **Interface Type** drop-down box). SUs can be placed only in WORP Satellite mode. The wireless interface settings depend upon whether the mode is Base or Satellite.

The Wireless Outdoor Router Protocol (WORP) is a polling algorithm designed for wireless outdoor networks. WORP takes care of the performance degradation incurred by the so-called “hidden-node” problem, which can occur when wireless LAN technology is used for outdoor building-to-building connectivity. In this situation, when multiple radios send an RTS, if another radio is transmitting, it corrupts all data being sent, degrading overall performance. The WORP polling algorithm ensures that these collisions cannot occur, which increases the performance of the overall network significantly.

WORP dynamically adapts to the number of SUs that are active on the network and the amount of data they have queued to send.

The following are examples of the Wireless window when the country selected is US, and for countries different than the US:

Base Mode – US Country

The screenshot shows the 'Wireless' configuration window. The 'Interface Type' is set to 'WorP Base'. The 'MAC Address' is '00:30:F1:E8:82:96'. The 'Network Name' is 'OR_WORP'. The 'Operational Mode' is '802.11a'. The 'Dynamic Data Rate Selection (DDR5) Status' is 'Disable'. The 'Transmit Power Control (TPC)' is '-0 dB'. A note states: 'NOTE: Changes to TPC will take effect immediately after clicking OK Button.' The 'Enable Turbo Mode' checkbox is unchecked. The 'Frequency Channel' is '149 - 5.745 GHz'. The 'Multicast Rate' is '36 Mbps'. The 'Channel Bandwidth' is '20 MHz'. The 'Antenna Gain (Including Cable Loss)' is '0'. The 'Satellite Density' is 'Large'. The 'Maximum Satellites' is '100'. The 'No-sleep Mode' is 'Disable'. The 'Automatic Multi Frame Bursting' is 'Enable'. The 'RegistrationTimeout' is '5'. The 'Network Secret' is '*****'. The 'Input bandwidth limit (in kbits/s)' is '108032'. The 'Output bandwidth limit (in kbits/s)' is '108032'. There are 'OK' and 'Cancel' buttons at the bottom.

The following parameters are configurable:

- **Interface Type:** The interface type can be **WORP Satellite** or **WORP Base**.
- **Network Name:** A **Network Name** is a name given to a network so that multiple networks can reuse the same frequency without problems. An SU can only register to its base if it has the same **Network Name**. The **Network Name** is one of the parameters that allow a Subscriber Unit to register on a Base Station. The **Base Station System Name** and **Frequency Channel** also are parameters to guide the SU to the proper BSU on the network, but they

provide no security. Basic security is provided through encryption, as it causes none of the messages to be sent in the clear. Further security is provided by mutual authentication of the BSU and SU using the **Network Secret**. The Network Name can be 2 to 32 characters in length.

- **Operational Mode (not configurable):** This field indicates the operational mode of the unit – 11a, 11b, or 11g – depending upon the specific Tsunami MP.11. This operational mode cannot be changed as it is based upon a license file. For the 5012, this field shows 11a.

- **Dynamic Data Rate Selection (DDRS) Status:** The **DDRS Status** is configurable only for the **WORP Base Mode**. For **WORP Base Mode**, select the **DDRS Status** “Enable” or “Disable” from the drop-down box provided.

For the **WORP Satellite Mode**, **DDRS Status** is read-only parameter and its value is based upon the **WORP Base** to which this SU is associated.

When you enable or disable DDRS on the BSU, the BSU sends an announcement to the SUs and the SUs enable or disable DDRS automatically.

- **Transmit Power Control (TPC):** By default, the 5012 lets you transmit at the maximum output power for the country or regulatory domain and frequency selected. However, with Transmit Power Control (TPC), you can adjust the output power of the unit to a lower level in order to reduce interference to neighboring devices or to use a higher gain antenna without violating the maximum radiated output power allowed for your country. Also, most countries in the ETSI regulatory domain require the transmit power to be set to a 6 dB lower value than the maximum allowed EIRP when link quality permits. You can see your unit’s current output power for the selected frequency in the event log.

The event log shows the selected power for all data rates, so you must look up the proper data rate to determine the actual power level.

NOTE: *This feature only lets you decrease your output power; it does not let you increase your output power beyond the maximum allowed defaults for your frequency and country.*

Select one of the following options and click **OK** at the bottom of the window. Your original output power is adjusted relative to the value selected. The new setting takes effect immediately without rebooting:

TPC Selection (dB)	Maximum TX Power (dBm)
0 (default)	16
-3	13
-6	10
-9	7
-12	4
-15	1
-18 (minimum TPC level)	0

- **Enable Turbo Mode:** Check this box to enable Turbo Mode. Turbo Mode is supported only in the United States. Enabling turbo mode, in its current implementation, allows the 5012 to use two adjacent frequency channels to transmit and receive a signal. This works at 12, 18, 24 and 36 Mbps. By enabling turbo mode, the receive sensitivity improves by 4 dB for the 36 Mbps data rate and by 2 dB for the 24 Mbps data rate.

NOTE: *The additional sensitivity is provided with the impact of using twice as much spectrum and thus increasing the opportunity of interference and decreased ability for system collocation. Generally, Turbo mode is not recommended except when the extra sensitivity is absolutely required.*

- **Frequency Channel:** The frequency channel indicates the band center frequency the unit uses for communicating with peers. This frequency channel can be set in several ranges, depending upon regulatory domain. Refer to [Country Codes and Channels](#) for channelization information.
- **Multicast Rate:** The rate at which data is to be transferred. All RF traffic between 5012 units is multicast. This drop down box is unavailable when DDRS is enabled.

The default data rate for the 5012 is 36 Mbps. The SU must never be set to a lower data rate than the BSU because timeouts will occur at the BSU and communication will fail.

Selections for multicast rate are shown in the following table:

Multicast Rates in Mbps	
20 MHz	Turbo Enabled (40 MHz)
6	12
9	18
12	24
18	36
24	48
36	72
48 (see Note)	96 (see Note)
54 (see Note)	108 (see Note)

Note: If you select 48 or 54 Mbps (96 or 108 in Turbo mode) DDRS is automatically turned on (enabled).

- **Antenna Gain (BSU only):** You can modify the sensitivity of the radio card when detecting radar signals in accordance with ETSI and FCC Dynamic Frequency Selection (DFS) requirements. Given the radar detection threshold is fixed by ETSI and the FCC and that a variety of antennas with different gains may be attached to the 5012, you must adjust this threshold to account for higher than expected antenna gains and avoid false radar detection events. This can result in the units constantly changing frequency channels.

You can configure the threshold for radar detection at the radio card to compensate for increased external antenna gains.

The Antenna Gain value ranges from 0 to 35. The default value is 0.

- **Satellite Density:** The **Satellite Density** setting is a valuable feature for achieving maximum bandwidth in a wireless network. It influences the receive sensitivity of the radio interface and improves operation in environments with a high noise level. Reducing the sensitivity of the unit enables unwanted “noise” to be filtered out (it disappears under the threshold).

You can configure the **Satellite Density** to be **Large, Medium, Small, Mini, or Micro**. The default value for this setting is Large. The smaller settings are appropriate for high noise environments; a setting of **Large** would be for a low noise environment.

A long distance link may have difficulty maintaining a connection with a small density setting because the wanted signal can disappear under the threshold. Consider both noise level and distance between the peers in a link when configuring this setting. The threshold should be chosen higher than the noise level, but sufficiently below the signal level. A safe value is 10 dB below the present signal strength.

If the Signal-to-Noise Ratio (SNR) is not sufficient, you may need to set a lower data rate or use antennas with higher gain to increase the margin between wanted and unwanted signals. In a point-to-multipoint configuration, the BSU should have a density setting suitable for all of its registered SUs, especially the ones with the lowest signal levels (longest links).

Take care when configuring a remote interface; check the available signal level first, using Remote Link Test.

WARNING: When the remote interface accidentally is set at too small a value and communication is lost, it cannot be reconfigured remotely and a local action is required to bring the communication back. Therefore, the best place to experiment with the level is at the unit that can be managed without going through the link; if the link is lost, the setting can be adjusted to the correct level to bring the link back.

To set the **Satellite Density**, click the **Configure** button, then the **Interfaces** tab and the **Wireless** sub-tab. Make your density selection from the drop-down menu. This setting requires a reboot of the unit.

Sensitivity threshold settings related to the density settings for the 5012 are:

Set Satellite Density to:	For a Receive Sensitivity Threshold of:	And a Defer Threshold of:
LARGE	-95 dBm	-62 dBm

MEDIUM	-86 dBm	-62 dBm
SMALL	-78 dBm	-52 dBm
MINI	-70 dBm	-42 dBm
MICRO	-62 dBm	-36 dBm

- **Maximum Satellites (BSU only):** You can specify a maximum value of 250 in this field, because up to 250 SUs can be connected to a BSU. If a BSU already has as many SUs as specified in this field, a new SU cannot connect to the BSU.
- **No-Sleep Mode (BSU only):** No-Sleep Mode was a feature used to control jitter in Tsunami MP.11 products running 2.2.6, and earlier, versions of software. The introduction of QoS and the new WORP resource scheduling mechanism have eliminated the need for No-Sleep Mode. Furthermore, QoS provides better control over jitter and latency-sensitive applications (see [QoS \(Quality of Service\) Parameters](#) for details on configuration). This field is inactive and makes no difference whether is enabled or disabled.
- **Automatic Multi-Frame Bursting (BSU only):** In order to achieve higher throughput, WORP protocol allows each side (BSU or SU) to send a burst of up to 4 data messages instead of a single data message. The sole criteria for sending a burst is enough traffic to be sent out. This feature is called Multi-Frame Bursting support.

Automatic Multi-Frame bursting optimizes multi-burst performance when configuring QoS high-priority Service Flows. Three scenarios may be defined:

- *No Multi-Frame burst support* –To disable Multi-Frame burst support, click “Disable” on the drop-down box of the **Configure, Network, Roaming** sub-tab (see [BSU Screen](#)). In this case, each active SFC is limited to send a single data message. Total throughput available to remaining best effort traffic is around 76% of the maximum available throughput.

Multi-Frame burst support – The system will enable Multi-Frame burst for *all* SFCs, but the maximum number of data messages sent in a burst will be defined by the parameter “Number of data messages in a burst” for each of the SFCs (see [Service Flow Class \(SFC\)](#)). This scenario is set by enabling Multi-Frame burst on the drop-down box of the **Configure, Network, Roaming** sub-tab (see [BSU Screen](#)) and disabling **Automatic Multi-Frame Bursting** (this parameter).

The maximum number of data messages in a burst directly influences the total throughput of the system. Typical values are:

No. of messages in a burst:	% of the maximum throughput:
4	100%
3	97.6%
2	92.9%
1	76.2%

- *Automatic Multi-Frame burst support* – The system will continuously be monitoring which of the active SFCs has the highest priority and dynamically enable Multi-Frame burst for the highest priority SFC only, keeping all the lower priority SFCs with Multi-Frame burst disabled. If there are multiple SFCs having the same, highest priority, all of them will have Multi-Frame burst enabled. The maximum number of data messages sent in a burst is defined by the parameter “Number of data messages in a burst” and it can be different for each SFC (see [Service Flow Class \(SFC\)](#)). This scenario is set by enabling Multi-Frame burst on the drop-down box of the **Configure, Network, Roaming** sub-tab (see [BSU Screen](#)) and enabling **Automatic Multi-Frame Bursting** (this parameter). In this case, even the lowest priority SFC will have Multi-Frame burst dynamically enabled as long as it is the only SFC in the system that has traffic. By default, configuring even a single high priority SFC with automatic multi-frame bursting enabled will decrease throughput of low priority best-effort traffic to approximately 76% of maximum available throughput, because low priority traffic will have Multi-Frame burst disabled to optimize bandwidth for the high priority traffic.
- **Registration Timeout:** This is the registration process time-out of an SU on a BSU. Default is 5 seconds.
- **Network Secret:** A network secret is a secret password given to all nodes of a network. An SU can only register to a BSU if it has the same Network Secret. The Network Secret is sent encrypted and can be used as a security option.

- **Input / Output Bandwidth Limit:** These parameters limit the data traffic received on the wireless interface and transmitted to the wireless interface, respectively. Selections are in steps of 64 Kbps from 64 Kbps to 12 Mbps.

NOTE: The aggregate maximum bandwidth shared between input and output is 12 Mbps. If you attempt to set the input/output bandwidth values so that the total exceeds 12 Mbps, the management interface will automatically adjust the values to the available aggregate bandwidth of 12 Mbps. For example, the system default is 6 Mbps for both input and output bandwidths. If you change the input to 8 Mbps, the management interface will automatically adjust the output to 4 Mbps, for an aggregate bandwidth of 12 Mbps. The values will not adjust automatically if the total is less than 12 Mbps.

Satellite Mode – US Country

The screenshot displays the configuration page for the Wireless interface in Satellite Mode. The interface is divided into several sections: Security, Filtering, System, Network, Interfaces, SNMP, RIP, and Management. The 'Interfaces' section is active, and the 'Wireless' sub-section is selected. The configuration parameters are as follows:

Parameter	Value
Interface Type	Worx Satellite
MAC Address	00:30:F1:E8:82:96
Base Station System Name	
Operational Mode	802.11a
Network Name	DR_WORP
Dynamic Data Rate Selection (DDR5) Status	Disabled
Transmit Power Control (TPC)	0 dB
Enable Turbo Mode	<input type="checkbox"/>
Frequency Channel	149 - 5.745 GHz
Scanning Across Bandwidth	Enable
Multicast Rate	36 Mbps
Channel Bandwidth	20 MHz
Satellite Density	Large
Registration Timeout	5
Network Secret	*****
Input bandwidth limit (in kbits/s)	109032
Output bandwidth limit (in kbits/s)	109032

All the fields that are common to both the BSU and the SU are applicable here. The SU features two additional fields:

- **Base Station System Name (SU only):** The name found on the system page of the BSU to which this SU is connecting. This parameter can be used as an added security measure, and when there are multiple BSUs in the network and you want an SU to register with only one when it may actually have adequate signal strength for either. The **System Name** field is limited to a length of 32 bytes.

If the **Base Station System Name** is left blank on the SU, it can register with any BSU with a matching **Network Name** and **Network Secret**.

Base Mode – Non-US Country

Interface Type: Wired Base
 MAC Address: 00:30:F1:E8:82:96
 Network Name: OR_WDRP
 Operational Mode: 802.11a
 Dynamic Data Rate Selection (DDRS) Status: Disable
 Transmit Power Control (TPC): -0 dB
 NOTE: Changes to TPC will take effect immediately after clicking OK Button
 Frequency Channel - DFS, Auto selected: 132 - 5.66 GHz
 Multicast Rate: 36 Mbps
 Channel Bandwidth: 20 MHz
 Antenna Gain (Including Cable Loss): 0
 Satellite Density: Large
 Maximum Satellites: 100
 No-sleep Mode: Disable
 Automatic Multi Frame Bursting: Enable
 Registration Timeout: 5
 Network Secret: *****
 Input bandwidth limit (in kbits/s): 108032
 Output bandwidth limit (in kbits/s): 108032

DFS Preferred Channel: None

Channel Blacklist Table

This table is used to configure blacklist channels. A channel can be blacklisted automatically if radar is detected on the operating channel (this is applicable only to specific regulatory domains). If radar is detected on a channel, that channel will be blacklisted for 39 minutes. A channel can also be blacklisted by the administrator in case that channel is not to be used.

Channel	Radar Detected	Elapsed Time (Minutes)	Blacklist Status
100 - 5.5 GHz	FALSE	0	Disable
104 - 5.52 GHz	FALSE	0	Disable
108 - 5.54 GHz	FALSE	0	Disable
112 - 5.56 GHz	FALSE	0	Disable
116 - 5.58 GHz	FALSE	0	Disable
120 - 5.6 GHz	FALSE	0	Disable
124 - 5.62 GHz	FALSE	0	Disable
128 - 5.64 GHz	FALSE	0	Disable
132 - 5.66 GHz	FALSE	0	Disable
136 - 5.68 GHz	FALSE	0	Disable
140 - 5.7 GHz	FALSE	0	Disable

The differences between the BSU Wireless interface screen for a non-US country and the equivalent screen for the US are:

- There is no **Turbo Mode**.
- **Frequency Channel** is not configurable. Instead the channel is auto-selected by the DFS process.

All the other fields that appear in the US screen for the BSU are applicable. There are also these additional fields:


- **DFS Preferred Channel:** A single DFS preferred frequency channel on the BSU is provided so that when the DFS process starts the BSU will first try the DFS preferred channel before scanning all the other active channels in the DFS channel list. The DFS preferred channel must be selected from those channels indicated as “Disable” in the DFS channel blacklist list. It is not possible to select the DFS preferred channel from those channels in the DFS channel blacklist list indicated as “Enable”.
- **Channel Blacklist Table:** The DFS channel blacklist table shows all the channels in the current bandwidth and specifies the blacklist status of each channel as one of the following:
 - Enable – Channels that are made unavailable either for a certain period of time upon detection of a radar signal, or permanently because the operator has configured them as blacklisted. These channels are skipped over during DFS channel selection.
 - Disable – Channels that are to be scanned during DFS.

Edit Entries to the Channel Blacklist Table


In accordance to the EN301-893 non-occupancy rule, when a radar signal is detected on any active channel, the blacklist status of that channel will change to “Enable” and the Radar Detected status will change to TRUE (see previous figure). The channel will not be used for a period of 30 minutes after the radar signal has been detected. The elapsed time is also shown in the DFS channel blacklist table. When the elapsed time for a channel in the blacklist is greater than or equal to 30 minutes, the blacklist status of the channel will change to Disable and the Radar Detected and Elapsed Time fields will change accordingly.

If an operator knows in advance on which channels a radar signal is likely to exist, those channels can be blacklisted and hence they will be skipped during DFS. Similarly, if the operator knows of channels where a radar signal is unlikely to be detected, those channels can be defined as active and hence they will be scanned during DFS. This makes the whole process more efficient.

When you click **Edit** the channel blacklist table screen appears. Here you can manually configure each channel as “active” (Blacklist Status = Disable) or “blacklisted” (Blacklist Status = Enable). Enter your changes and click **OK**. To go back, click on the arrow button.



Satellite Mode – Non-US Country



The differences between the SU Wireless interface screen for a non-US country and the equivalent screen for the US are:

- There is no **Turbo Mode**.
- **Frequency Channel** is not configurable. Instead the channel is auto-selected by the DFS process.


All the other fields that appear in the US screen for the SU are applicable.

Notes:

- Turbo mode is available only when the specified **Country** is US.
- The list of parameters to configure for registration of the SU on a Base Station are:
 - Network Name
 - Base Station System Name (when used)
 - Channel Frequency
 - Encryption (when used)
 - Network Secret

Configure the Ethernet Interface

To set the Ethernet speed, duplex mode, and input and output bandwidth limits, click the **Configure** button, the **Interfaces** tab, and the **Ethernet** sub-tab.



You can set the desired speed and transmission mode by clicking on **Configuration**. Select from these settings for the type of Ethernet transmission:

- **Half-duplex** means that only one side can transmit at a time.
- **Full-duplex** lets both sides transmit.
- **Auto-duplex** selects the best transmission mode available when both sides are set to auto-select.

The recommended setting is **auto-speed-auto-duplex**.

SNMP Parameters

Click the **Configure** button and the **SNMP** tab to enable or disable trap groups, and to configure the SNMP management stations to which the 5012 sends system traps. See “Trap Groups” in the *Tsunami MP.11 Reference Manual* for a list of the system traps.

The screenshot shows the SNMP configuration page. On the left is a navigation menu with buttons for Status, Configure, Monitor, Commands, Help, and Exit. The main area has tabs for Security, Filtering, Intra-Cell Blocking, VLAN, OoS, System, Network, Interfaces, SNMP (selected), RIP, and Management. Under the 'Trap Groups' section, there are seven rows, each with a label and a dropdown menu set to 'Enable': Configuration Trap Status, Security Trap Status, Wireless Interface Trap Status, Operational Trap Status, Flash Memory Trap Status, TFTP Trap Status, and Image Trap Status. Below this are 'OK' and 'Cancel' buttons. The 'Trap Host Table' section has a table with columns for IP Address, Password, Comment, and Status. Below the table are 'Add Table Entries' and 'Edit/Delete Table Entries' buttons.

- **Trap Groups:** You can enable or disable different types of traps in the system. By default, all traps are enabled.
- **Trap Host Table:** This table shows the SNMP management stations to which the 5012 sends system traps.

Add Entries to the Trap Host Table

Click the **Add Table Entries** button to add entries to the Trap Host Table.

The screenshot shows the 'Add Table Entries' form. It has the same navigation and tab structure as the previous screenshot. The main area contains a form with four input fields: IP Address, Password, Password Confirm, and Comment. Below the form are 'Add', 'Cancel', and 'Back' buttons.

Edit/Delete Entries to the Trap Host Table


Click the **Edit/Delete Table Entries** button to make changes to or delete existing entries.

The image shows a web-based configuration interface for SNMP parameters. The interface has a top navigation bar with tabs for Security, Filtering, Intra-Cell Blocking, VLAN, and QoS. Below this is a sub-navigation bar with tabs for System, Network, Interfaces, SNMP (highlighted in orange), RIP, and Management. On the left side, there is a vertical menu with buttons for Status, Configure (highlighted in orange), Monitor, Commands, Help, and Exit. The main configuration area contains five columns: IP Address, Password, Confirm, Comment, and Status. Below the IP Address column is an OK button. Below the Confirm column is a Cancel button. Below the Status column is a Back button.

RIP Parameters

Routing Internet Protocol (RIP) is a dynamic routing protocol you can use to help automatically propagate routing table information between routers. The unit can be configured as RIPv1, RIPv2 or a combination of the two versions while operating in **Routing** mode. In general, the unit’s RIP module is based upon RFC 1389.

NOTE: RIP does not work when Network Address Translation (NAT) is enabled.



Note the following:

- RIPv2 is enabled by default when routing mode is selected.
- You may turn RIP off by clearing the **Enable RIP Interface** check box for the Ethernet or the wireless interface. Any RIP advertisements that are received on the designated interface are ignored. All other options on the page are dimmed.
- If the **Enable RIP Interface** check box is selected, the unit sends RIP requests and “listens” for RIP updates coming from RIP-enabled devices advertising on the network. You may configure the **Receive** field for RIPv1, RIPv2, or a combination of both. Although the unit receives and processes these updates, it does not further propagate these updates unless configured to advertise RIP. Again, you may configure the **Advertise** field for RIPv1, RIPv2, or a combination of both.
- The ability to enable or disable default route propagation is not user configurable. Once initialized, the 5012 uses its static default route and does not advertise this route in RIP updates. If another router on your network is configured to advertise its default route, this route overwrites the static default route configured on the 5012. The 5012 then also propagates the new dynamic default route throughout the network.

Be aware that, once a dynamic default route is learned, it behaves just as any other dynamic route learned through RIP. This means if the device sending the default route stops sending RIP updates, the default route times out and the unit has no default route to the network. Workarounds for this condition include rebooting or re-entering a static default route. In general, the best approach is to disable the propagation of default routes on the other routers in your network unless you understand the risks.

The following table describes the properties and features of each version of RIP supported.

Properties and Features of Supported RIP Versions	
RIPv1	RIPv2
Broadcast	Multicast
No Authentication	Authentication
Class routing	Classless routing (VLSM)
Distance-vector protocol	Distance-vector protocol

Properties and Features of Supported RIP Versions	
RIPv1	RIPv2
Metric-Hops	Metric-Hops
Maximum Distance 15	Maximum Distance 15
IGP	IGP

RIP Example

In the following example, assume that both the BSU and the SUs all are configured in **Routing** mode with RIP enabled to send and receive on both the Ethernet and Wireless interfaces. The network converges through updates until each unit has the following routing table:

BSU


```
0.0.0.0      172.16.0.1    metric 1
172.16.0.0  172.16.0.20  metric 1
10.0.0.0    10.0.0.1     metric 1
100.0.0.0   10.0.0.2     metric 2
200.0.0.0   10.0.0.3     metric 2
```

SU1

```
0.0.0.0    10.0.0.1     metric 1
10.0.0.0   10.0.0.2     metric 1
100.0.0.0  100.0.0.1    metric 1
172.16.0.0 10.0.0.1    metric 2
200.0.0.0  10.0.0.2     metric 2
```

SU2

```
0.0.0.0    10.0.0.1     metric 1
10.0.0.0   10.0.0.3     metric 1
200.0.0.0  200.0.0.1    metric 1
172.16.0.0 10.0.0.1    metric 2
100.0.0.0  10.0.0.2     metric 2
```



RIP Notes

- Ensure that routers on the same physical network are configured to use the same version of RIP.
- Routing updates occur every 30 seconds. It may take up to 3 minutes for a route that has gone down to timeout in a routing table.
- RIP is limited to networks with 15 or fewer hops.

Management Parameters

When you click the **Management** button, Passwords is displayed automatically. The other tab under **Management** is the **Services** tab.

Configure Passwords

The **Password** tab lets you configure the SNMP, Telnet, and HTTP (Web Interface) passwords.

The screenshot shows the 'Management' tab selected in the top navigation bar. Under 'Management', the 'Passwords' sub-tab is active. The main content area contains the following text and fields:

Passwords Services

This tab is used to configure SHIMPv1 v2c community, Telnet (CLI) and HTTP (web) passwords.

Change the default passwords to a value known only to you. If this is not done, then users may be able to manage the device and modify its configuration without your knowledge.

Note: Changes to Passwords must be between 6 and 32 characters. Changes will take effect immediately after clicking OK Button.

SNMP Read Community Password: [password field] Confirm: [password field]

SNMP Read/Write Community Password: [password field] Confirm: [password field]

Telnet (CLI) Password: [password field] Confirm: [password field]

HTTP (web) Password: [password field] Confirm: [password field]

OK Cancel

For all password fields, the passwords must be between 6 and 32 characters. Changes take effect immediately after you click **OK**.

- **SNMP Read Community Password:** The password for read access to the 5012 using SNMP. Enter a password in both the **Password** field and the **Confirm** field. The default password is **public**.
- **SNMP Read/Write Community Password:** The password for read and write access to the 5012 using SNMP. Enter a password in both the **Password** field and the **Confirm** field. The default password is **public**.
- **Telnet (CLI) Password:** The password for the CLI interface. Enter a password in both the **Password** field and the **Confirm** field. The default password is **public**.
- **HTTP (Web) Password:** The password for the Web browser HTTP interface. Enter a password in both the **Password** field and the **Confirm** field. The default password is **public**.

Configure Service Parameters

The **Services** tab lets you configure the SNMP, Telnet, and HTTP (Web Interface) parameters. Changes to these parameters require a reboot to take effect.



SNMP Configuration Settings

- **SNMP Interface Bitmask:** Configure the interface or interfaces (**Ethernet, Wireless, All Interfaces**) from which you will manage the 5012 using SNMP. You also can select **Disabled** to prevent a user from accessing the unit through SNMP.

HTTP Configuration Settings

- **HTTP Interface Bitmask:** Configure the interface or interfaces (**Ethernet, Wireless, All Interfaces**) from which you will manage the 5012 through the Web interface. For example, to allow Web configuration through the Ethernet network only, set **HTTP Interface Bitmask** to **Ethernet**. You can also select **Disabled** to prevent a user from accessing the 5012 from the Web interface.
- **HTTP Port:** Configure the HTTP port from which you will manage the 5012 through the Web interface. By default, the HTTP port is 80.

Telnet Configuration Settings

NOTE: To use HyperTerminal for CLI access, make sure to check “Send line ends with line feeds” in the ASCII Setup window (click Properties from the HyperTerminal window; select Setup, then ASCII Setup. See “HyperTerminal Connection Properties” in the Tsunami MP.11 Reference Manual for more information).

- **Telnet Interface Bitmask:** Select the interface (**Ethernet, Wireless, All Interfaces**) from which you can manage the 5012 through telnet. This parameter can also be used to disable telnet management.
- **Telnet Port Number:** The default port number for Telnet applications is 23. However, you can use this field if you want to change the Telnet port for security reasons (but your Telnet application also must support the new port number you select).
- **Telnet Login Timeout (seconds):** Enter the number of seconds the system is to wait for a login attempt. The 5012 terminates the session when it times out. The range is 1 to 300 seconds; the default is 30 seconds.
- **Telnet Session Timeout (seconds):** Enter the number of seconds the system is to wait during a session while there is no activity. The 5012 ends the session upon timeout. The range is 1 to 36000 seconds; the default is 900 seconds.

Serial Configuration Settings

The serial port interface on the 5012 is enabled at all times. See “Serial Port” in the *Tsunami MP.11 Reference Manual* for information about how to access the CLI interface through the serial port. You can configure and view following parameters:


- **Serial Baud Rate:** Select the serial port speed (bits per second). Choose between **2400**, **4800**, **9600**, **19200**, **38400**, or **57600**; the default Baud Rate is **9600**.
- **Serial Flow Control:** Select either **None** (default) or **Xon/Xoff** (software controlled) data flow control. To avoid potential problems when communicating with the 5012 through the serial port, Proxim recommends that you leave the **Flow Control** setting at **None** (the default value).
- **Serial Data Bits:** This is a read-only field and displays the number of data bits used in serial communication (8 data bits by default).
- **Serial Parity:** This is a read-only field and displays the number of parity bits used in serial communication (no parity bits by default).
- **Serial Stop Bits:** This is a read-only field that displays the number of stop bits used in serial communication (1 stop bit by default). The serial port bit configuration is commonly referred to as 8N1.

Security Parameters

Configure MAC Authentication


Click the **Configure** button, the **Security** tab, and the **MAC Auth** sub-tab to build a list of authorized wireless stations that can register at the 5012 and access the network.

MAC authentication is available only for BSUs.




This feature is supported on the wireless interface and only wireless MAC addresses should be entered in the list. For example, build a list of wireless MAC addresses on the BSU for the authorized SUs.

To add table entries, click the **Add Table Entries** button; a window such as the following is displayed:



Enter the MAC address and any comment, then click **Add**. The maximum number of MAC addresses that can be entered is 250.

To edit or delete table entries, click the **Edit/Delete Table Entries** button; make your corrections in the window displayed and click **OK**.



Configure Encryption Parameters

NOTE: Be sure to set the encryption parameters and change the default passwords.

You can protect the wireless data link by using encryption. Encryption keys can be 5 (64-bit), 13 (WEP 128-bit), or 16 (AES 128-bit) characters in length. Both ends of the wireless data link must use the same parameter values.

In addition to Wi-Fi Protected Access (WPA) and Wired Equivalent Privacy (WEP), the unit supports Advanced Encryption Standard (AES) 128-bit encryption. To provide even stronger encryption, the AES CCM Protocol is also supported.

Click the **Configure** button, the **Security** tab, and the **Encryption** sub-tab to set encryption keys for the data transmitted and received by the 5012. Note that all devices in one network must use the same encryption parameters to communicate to each other.



Configure RADIUS Authentication

Click the **Configure** button, the **Security** tab, and the **Radius Auth** sub-tab to set the IP address of the RADIUS server containing the central list of MAC addresses that are allowed to access the network. The RADIUS parameters let you enable HTTP or Telnet RADIUS management access to configure a RADIUS Profile for management access control, to enable or disable local user access, and to configure the local password.

RADIUS authentication is available only for BSUs.



In large networks with multiple 5012 devices, you can maintain a list of MAC addresses on a centralized location using a RADIUS authentication server that grants or denies access. If you use this kind of authentication, you must specify at least the primary RADIUS server. The backup RADIUS server is optional.

Configure Packet Filtering

Click the **Configure** button and the **Filtering** tab to configure packet filtering. Packet filtering can be used to control and optimize network performance.

The Filtering feature can selectively filter specific packets based upon their Ethernet protocol type. Protocol filtering is done at the Bridge layer.

Protocol filters are useful for preventing bridging of selected protocol traffic from one segment of a network to other segments (or subnets). You can use this feature both to increase the amount of bandwidth available on your network and to increase network security.

Increasing Available Bandwidth

It may be unnecessary to bridge traffic from a subnet using IPX/SPX or AppleTalk to a segment of the network with UNIX workstations. By denying the IPX/SPX AppleTalk traffic from being bridged to the UNIX subnet, the UNIX subnet is free of this unnecessary traffic.

Increasing Network Security

By bridging IP and IP/ARP traffic and blocking LAN protocols used by Windows, Novell, and Macintosh servers, you can protect servers and client systems on the private local LAN from outside attacks that use those LAN protocols. This type of filtering also prevents private LAN data from being bridged to an untrusted remote network or the Internet.

To prevent blocking your own access (administrator) to the unit, Proxim recommends that IP (0x800) and ARP (0x806) protocols are always passed through.

Sample Use and Validation

Configure the protocol filter to let only IP and ARP traffic pass through the 5012 (bridge) from one network segment to another. Then, attempt to use Windows file sharing across the bridge. The file should not allow sharing; the packets are discarded by the bridge.

Setting the ARP Filter

There may be times when you need to set the ARP or Multicast. Usually, this is required when there are many nodes on the wired network that are sending ARP broadcast messages or multicast packets that unnecessarily consume the wireless bandwidth. The goal of these filters is to allow only necessary ARP and multicast traffic through the 1.6 Mbps wireless pipe.

The TCP/IP Internet Protocol Suite uses a method known as ARP (Address Resolution Protocol) to match a device's MAC (Media Access Control) address with its assigned IP address. The MAC address is a unique 48-bit identifier assigned to each hardware device at the factory by the manufacturer. The MAC address is commonly represented as 6 pairs of hexadecimal digits separated by colons. For example, a RangeLAN2 device may have the MAC address of 00:20:A6:33:ED:45.

When devices send data over the network (Ethernet, Token Ring, or wireless), they use the MAC address to identify a packet's source and destination. Therefore, an IP address must be mapped to a MAC address in order for a device to send a packet to particular IP address. In order to resolve a remote node's IP address with its MAC address, a device sends out a broadcast packet to all nodes on the network. This packet is known as an ARP request or ARP broadcast and requests that the device assigned a particular IP address respond to the sender with its MAC address.

Because ARP requests are broadcast packets, these packets are forwarded to wireless nodes by default, even if the packet is not meant for a wireless node. As the number of nodes on a network backbone increases, so does the number of ARP broadcasts that are forwarded to the wireless nodes. Many of these ARP broadcasts are unnecessary and can consume valuable wireless bandwidth. On some networks, there are so many ARP broadcasts that the performance of the wireless network will degrade due to the amount of bandwidth being consumed by these messages.

To reduce the number of ARP broadcasts that are forwarded to the wireless nodes, you can enable ARP filtering. When enabled, the ARP Filter allows the unit to forward only those ARP broadcasts destined for an IP address that falls within the range specified by the ARP Filter Network Address and the ARP Filter Subnet Mask. The ARP Filter performs a logical AND function (essentially keeping what is the same and discarding what is different) on the IP address of the ARP request and the ARP Filter Subnet Mask. It then compares the result of the logical AND to the ARP Filter Network Address. If the two values match, the ARP broadcast is forwarded to the wireless network by the unit.

Configure Ethernet Protocol Filtering

The Ethernet Protocol filter blocks or forwards packets based upon the Ethernet protocols they support. Click the **Configure** button, the **Filtering** tab, and the **Ethernet Protocol** sub-tab to enable or disable certain protocols in the table. Entries can be selected from a drop-down box.




Follow these steps to configure the Ethernet Protocol Filter:

1. Select the interfaces that will implement the filter from the Ethernet Protocol Filtering drop-down menu.
 - Ethernet: Packets are examined at the Ethernet interface


- Wireless-Slot A or Wireless-Slot B: Packets are examined at the Wireless A or B interfaces
 - All Interfaces: Packets are examined at both interfaces
 - Disabled: The filter is not used
2. Select the **Filter Operation Type**.
 - If set to Block, the bridge blocks enabled Ethernet Protocols listed in the Filter Table.
 - If set to Passthru, only the enabled Ethernet Protocols listed in the Filter Table pass through the bridge.
 3. Configure the Ethernet Protocol Filter Table. This table is pre-populated with existing Ethernet Protocol Filters, however, you may enter additional filters by specifying the appropriate parameters.
 - To add an entry, click Add, and then specify the Protocol Number and a Protocol Name.
 - Protocol Number: Enter the protocol number. See <http://www.iana.org/assignments/ethernet-numbers> for a list of protocol numbers.
 - Protocol Name: Enter related information, typically the protocol name.
 - To edit or delete an entry, click Edit and change the information, or select Enable, Disable, or Delete from the Status drop-down menu.
 - An entry's status must be enabled in order for the protocol to be subject to the filter.

Add Entries to the Ethernet Protocol Filter Table

To add an entry to the table, click **Add Table Entries**, select the protocol name from the drop-down box and click the **Add** button.



To edit or delete table entries, click **Edit/Delete Table Entries**, make your changes or deletions, and click **OK**.




Configure Static MAC Pair Filtering

The Static MAC Address filter optimizes the performance of a wireless (and wired) network. When this feature is configured properly, the unit can block traffic between wired devices on the wired (Ethernet) interface and devices on the wireless interface based upon MAC address.

NOTE: The device on the wireless interface can be any device connected through the link, it can be directly connected to the Ethernet interface of the peer unit, or it can be attached through multiple hops. The only thing important is the MAC address in the packets arriving at the wireless interface.

The filter is an advanced feature that lets you limit the data traffic between two specific devices (or between groups of devices based upon MAC addresses) through the wireless interface of the 5012. For example, if you have a server on your network with which you do not want wireless clients to communicate, you can set up a static MAC filter to block traffic between these devices. The Static MAC Filter Table performs bi-directional filtering. However, note that this is an advanced filter and it may be easier to control wireless traffic through other filter options, such as **Protocol Filtering**.

Click the **Configure** button, the **Filtering** tab, and the **Static MAC** sub-tab to access the Static MAC Address filter.



Each MAC address or mask is comprised of 12 hexadecimal digits (0-9 and A-F) that correspond to a 48-bit identifier. (Each hexadecimal digit represents 4 bits (0 or 1).

Taken together, a MAC address/mask pair specifies an address or a range of MAC addresses that the unit looks for when examining packets. The unit uses Boolean logic to perform an “and” operation between the MAC address and the mask at the bit level. However, for most users, you do not need to think in terms of bits. It should be sufficient to create a filter using only the hexadecimal digits 0 and F in the mask (where 0 is any value and F is the value specified in the MAC address). A mask of 00:00:00:00:00:00 corresponds to all MAC addresses, and a mask of FF:FF:FF:FF:FF:FF applies only to the specified MAC address.

For example, if the MAC address is 00:20:A6:12:54:C3 and the mask is FF;FF;FF;00:00:00, the unit examines the source and destination addresses of each packet looking for any MAC address starting with 00:20:A6. If the mask is FF;FF;FF;FF;FF;FF, the unit looks only for the specific MAC address (in this case, 00:20:A6:12:54:C3).

When creating a filter, you can configure the Wired parameters only, the Wireless parameters only, or both sets of parameters. Which parameters to configure depends upon the traffic that you want to block.

- To prevent all traffic from a specific wired MAC address from being forwarded to the wireless network, configure only the Wired MAC address and Wired mask (leave the Wireless MAC and Wireless mask set to all zeros).
- To prevent all traffic from a specific wireless MAC address from being forwarded to the wired network, configure only the Wireless MAC and Wireless mask (leave the Wired MAC address and Wired mask set to all zeros).
- To block traffic between a specific wired MAC address and a specific wireless MAC address, configure all four parameters.


Add Entries to the Static MAC Filter Table

To add the entries to Filter table, click the **Add Table Entries** button.



After entering the data, click the **Add** button. The entry is enabled automatically when saved.

To edit an entry, click **Edit**. To disable or remove an entry, click **Edit** and change the **Status** field from **Enable** to **Disable** or **Delete**.



The following parameters appear on this page:

- **Wired MAC Address:** Enter the MAC address of the device on the Ethernet network that you want to prevent from communicating with a device on the wireless network.
- **Wired Mask:** Enter the appropriate bit mask to specify the range of MAC addresses to which this filter is to apply. To specify only the single MAC address you entered in the Wired MAC Address field, enter 00:00:00:00:00:00 (all zeroes).
- **Wireless MAC Address:** Enter the MAC address of the wireless device on the wireless interface that you want to prevent from communicating with a device on the wired network.
- **Wireless Mask:** Enter the appropriate bit mask to specify the range of MAC addresses to which this filter is to apply. To specify only the single MAC address you entered in the Wireless MAC Address field, enter 00:00:00:00:00:00 (all zeroes).
- **Comment:** Enter related information.
- **Status:** The Status field can show **Enable**, **Disable**, or **Delete**.

Static MAC Filter Examples

Consider a network that contains a wired server and three wireless clients. The MAC address for each unit is as follows:

Wired Server: 00:40:F4:1C:DB:6A
Wireless Client 1: 00:02:2D:51:94:E4
Wireless Client 2: 00:02:2D:51:32:12
Wireless Client 3: 00:20:A6:12:4E:38

Prevent two specific devices from communicating:

Configure the following settings to prevent the Wired Server and Wireless Client 1 from communicating:

Wired MAC Address: 00:40:F4:1C:DB:6A

Wired Mask: FF:FF:FF:FF:FF:FF

Wireless MAC Address: 00:02:2D:51:94:E4

Wireless Mask: FF:FF:FF:FF:FF:FF

Result: Traffic between the Wired Server and Wireless Client 1 is blocked. Wireless Clients 2 and 3 still can communicate with the Wired Server.

Prevent Multiple Wireless Devices From Communicating With a Single Wired Device

Configure the following settings to prevent Wireless Clients 1 and 2 from communicating with the Wired Server:

Wired MAC Address: 00:40:F4:1C:DB:6A

Wired Mask: FF:FF:FF:FF:FF:FF

Wireless MAC Address: 00:02:2D:51:94:E4

Wireless Mask: FF:FF:FF:00:00:00

Result: When a logical “AND” is performed on the Wireless MAC Address and Wireless Mask, the result corresponds to any MAC address beginning with the 00:20:2D prefix. Since Wireless Client 1 and Wireless Client 2 share the same prefix (00:02:2D), traffic between the Wired Server and Wireless Clients 1 and 2 is blocked. Wireless Client 3 can still communicate with the Wired Server since it has a different prefix (00:20:A6).

Prevent All Wireless Devices From Communicating With a Single Wired Device

Configure the following settings to prevent all three Wireless Clients from communicating with Wired Server:

Wired MAC Address: 00:40:F4:1C:DB:6A

Wired Mask: FF:FF:FF:FF:FF:FF

Wireless MAC Address: 00:00:00:00:00:00

Wireless Mask: 00:00:00:00:00:00

Result: The unit blocks all traffic between the Wired Server and all wireless clients.

Prevent A Wireless Device From Communicating With the Wired Network

Configure the following settings to prevent Wireless Client 3 from communicating with any device on the Ethernet:

Wired MAC Address: 00:00:00:00:00:00

Wired Mask: 00:00:00:00:00:00

Wireless MAC Address: 00:20:A6:12:4E:38

Wireless Mask: FF:FF:FF:FF:FF:FF

Result: The unit blocks all traffic between Wireless Client 3 and the Ethernet network.

Prevent Messages Destined for a Specific Multicast Group from Being Forwarded to the Wireless LAN

If there are devices on your Ethernet network that use multicast packets to communicate and these packets are not required by your wireless clients, you can set up a Static MAC filter to preserve wireless bandwidth. For example, if routers on your network use a specific multicast address (such as 01:00:5E:00:32:4B) to exchange information, you can set up a filter to prevent these multicast packets from being forwarded to the wireless network:

Wired MAC Address: 01:00:5E:00:32:4B

Wired Mask: FF:FF:FF:FF:FF:FF


Wireless MAC Address: 00:00:00:00:00:00

Wireless Mask: 00:00:00:00:00:00

Result: The unit does not forward any packets that have a destination address of 01:00:5E:00:32:4B to the wireless network.

Configure Storm Threshold Filtering

Click the **Configure** button, the **Filtering** tab, and the **Storm Threshold** sub-tab to use threshold limits to prevent broadcast/multicast overload.



Storm Threshold is an advanced Bridge setup option that you can use to protect the network against data overload by specifying:

- A maximum number of frames per second as received from a single network device (identified by its MAC address).
- An absolute maximum number of messages per port.

The **Storm Threshold** parameters let you specify a set of thresholds for each port of the 5012, identifying separate values for the number of broadcast messages per second and multicast messages per second.


When the number of frames for a port or identified station exceeds the maximum value per second, the 5012 ignores all subsequent messages issued by the particular network device, or ignores all messages of that type.

The following parameters are configurable:


- **Per Address Threshold:** Enter the maximum allowed number of packets per second.
- **Ethernet Threshold:** Enter the maximum allowed number of packets per second.
- **Wireless Threshold:** Enter the maximum allowed number of packets per second.

Configure Broadcast Protocol Filtering

Click the **Configure** button, the **Filtering** tab, and the **Broadcast Protocol** sub-tab to deny specific IP broadcast, IPX broadcast, and multicast traffic.




Click the **Edit Table Entries** button to display an editable window such as the following. You can configure whether this traffic must be blocked for Ethernet to wireless, wireless to Ethernet, or both.




Configure IP Access Table Filtering


The IP Access Table limits in-band management access to the IP addresses or range of IP addresses specified in the table. This feature applies to all management services (SNMP, HTTP, and CLI).



To add an entry, click the **Add Table Entries** button, specify the IP address and mask of the wireless stations to which you want to grant access, and click **Add**.



To edit or delete table entries, click the **Edit/Delete Table Entries** button, make your changes, and click **OK**.



For example, **172.17.23.0/255.255.255.0** allows access from all wireless stations with an IP address in the 172.17.23.xxx range.

Ensure that the IP address of the management PC you use is within the first entry in the table, as this filter takes effect immediately. Otherwise, you have locked yourself out.

When you do lock yourself out, you may try to give the PC the correct IP address; otherwise you must reset the unit.

Intra-Cell Blocking (Base Station Unit only)

The Intra-Cell Blocking feature lets traffic be blocked between two SUs registered to the same Base Station. There are two potential reasons to isolate traffic among wireless subscribers:

- To provide better security to the subscribers by isolating the traffic from one subscriber to another in a public space.
- To block unwanted traffic between subscribers to prevent this traffic from using bandwidth.

You can form groups of SUs at the Base Station, which define the filtering criteria. All data to or from SUs belonging to the same group are bridged. All other data from SUs that do not belong to a particular group are automatically forwarded through the Ethernet interface of the Base Station. If an SU does not belong to any group, the Base Station discards the data.

You can also configure a *Security Gateway* to block traffic between SUs connected to different BSUs. All packets destined for SUs not connected to the same Base Station are forwarded to the Security Gateway MAC address (configured in the *Security Gateway* tab).

When you change the device from **Bridge** to **Routing** mode, Intra-Cell Blocking stops working with or without a reboot. When you change the device from **Routing** to **Bridge** mode, Intra-Cell Blocking starts working with or without a reboot.

Enable Intra-Cell Blocking

The Group Table tab lets you enable the Intra-Cell Blocking feature and to configure Intra-Cell Blocking Groups.




The following items are configurable:

- **Intra-Cell Blocking Status:** Enables or disables the Intra-Cell Blocking feature.
- **Group Table:** Entries in this table show the Intra-Cell Blocking filter groups that have been configured. When Intra-Cell Blocking is enabled, the Base Station Unit discards all packets coming from one SU to another SU, if both SUs do not belong to the same filter group.

Configure Intra-Cell Blocking Groups


Click the **Add Table Entries** button to add groups to the Group Table.

Intra-Cell Blocking (Base Station Unit only)




Enter the group name, and click **Add**. The group is assigned an Index and appears in the Group Table. Up to 16 groups can be configured per Base Station.

You can enable, disable or delete an existing filter group by using the **Edit/Delete Table Entries** button.




Assign MAC Addresses

After configuring the Intra-Cell Blocking Groups on the **Group Table** tab, use the **MAC Table** tab to assign specific MAC addresses to an Intra-Cell Blocking Group.



Adding Entries


Click the **Add Table Entries** button.



Enter the MAC address of the SU. Select **Enable** from the drop-down menu for the Group Index


Click **Add**. The MAC address is assigned to the groups. Additions to the MAC Table take effect immediately after clicking the **Add** button.

You can **enable, disable, delete, or reassign** the groups for a MAC address by using the **Edit/Delete Table Entries** button. A maximum of 250 MAC addresses can be added among all filter groups.



Block Traffic Between SUs (Security Gateway)

You can configure a Security Gateway to block traffic between SUs connected to different BSUs. Verify that Intra-Cell Blocking has been enabled on the **Group Table** tab before configuring the Security Gateway.



- **Security Gateway Status:** Enables or disables packet forwarding to the external Security Gateway.
- **Security Gateway MAC Address:** Lets you configure the MAC address of the external Security Gateway.

Intra-Cell Blocking Group Rules

The following rules apply to Intra-Cell Blocking Groups:

- One SU can be assigned to more than one group.
- An SU that has not been assigned to any group cannot communicate to any other SU connected to the same or different BSU.

Example of Intra-Cell Blocking Groups

Four Intra-Cell Blocking Groups have been configured on one BSU. SUs 1 through 6 are registered to BSU 1. SUs 7 through 9 are registered to BSU 2.

Intra-Cell Blocking Group Example			
Group 1	Group 2	Group 3	Group 4
SU 1	SU 2	SU 6	SU 8
SU 4	SU 3	SU 1	SU 9
SU 5	SU 8	SU 3	SU 2

In this example, SU 1 belongs to two groups, Group 1 and Group 3. Therefore, packets from SU 1 destined to SU 4, SU 5, SU 6, and SU 3 are not blocked. However, SU 9 belongs to group 4 only and packets from SU 9 are blocked unless sent to SU 8 or SU 2.

Achieving Communication Between Two SUs

In a multipoint configuration, an SU can communicate with another SU through the BSU when in Bridge mode by default. Use the intra-cell blocking feature if this is not desired. In a routing configuration, each of the SUs must have a different subnet on their Ethernet port to distinguish traffic for each SU, and each subnet must be entered into a routing rule in the BSU as well as into an upstream router. The wireless side of all SUs must share the same subnet with the BSU wireless interface. These IP addresses must be used as next hop when creating the routes for the SU subnets.

VLAN Parameters

Virtual LAN (VLAN) implementation in the Tsunami 5012 products:

- Lets the BSU and SU be used in a VLAN-aware network.
- Processes IEEE 802.1Q VLAN-tagged packets.

Network resources behind the BSU and SU can be assigned to logical groups.

VLAN Modes

Transparent Mode

Transparent mode applies to both the SU and the BSU. This mode is equivalent to NO VLAN support and is the default mode. It is used when the devices behind the SU and BSU are both VLAN aware or unaware. The SU/BSU transfers both tagged and untagged frames received on the Ethernet or WORP interface. Both tagged and untagged management frames can access the device.

Trunk Mode

Trunk mode VLAN applies to both the SU and the BSU. It is used when all devices behind the SU and BSU are VLAN aware. The SU and BSU transfer only tagged frames received on the Ethernet or WORP interface. Both tagged and untagged management frames can access the device.

Access Mode

Access mode applies only to the SU. It is used when the devices behind the SU are VLAN unaware. Frames to and from the Ethernet interface behind the SU map into only one VLAN segment. Frames received on the Ethernet interface are tagged with the configured Access VLAN ID before forwarding them to the WORP interface. Both tagged and untagged management frames can access the device from the WORP interface. However, only untagged management frames can access the device from the Ethernet Interface.

VLAN Forwarding

The VLAN Trunk mode provides a means to configure a list of VLAN IDs in a Trunk VLAN Table. The SU and BSU only forward frames (between Ethernet and WORP interface) tagged with the VLAN IDs configured in the Trunk VLAN Table. Up to 256 VLAN IDs can be configured for the BSU and up to 16 VLAN IDs can be configured for the SU (depending upon the capabilities of your switching equipment).

VLAN Relaying

The VLAN Trunk mode for BSU operation provides an option to enable and disable a VLAN relaying flag; when enabled, the BSU shall relay frames between SUs on the same BSU having the same VLAN ID.

Management VLAN

The BSU and SU allow the configuration of a separate VLAN ID and priority for SNMP, ICMP, Telnet, and TFTP management frames for device access.


The management VLAN ID and management VLAN priority may be applied in any mode. The management stations tag the management frames they send to the BSU or SU with the management VLAN ID configured in the device. The BSU and SU tag all the management frames from the device with the configured management VLAN and priority.

BSU and SU in Transparent Mode

When the BSU is in Transparent mode, all associated SUs must be in Transparent mode.

How the BSU and SUs function in Transparent mode is described in the following table.

BSU Function – Transparent Mode	SU Function – Transparent Mode
<ul style="list-style-type: none"> • BSU forwards both tagged and untagged frames received from the Ethernet interface or from any of the associated SUs. • If a valid management VLAN ID is configured, BSU allows only management frames tagged with the configured management VLAN ID to access it. • If a valid management VLAN ID is configured, BSU tags all management frames generated by the BSU with the configured management VLAN ID and priority. • If the management VLAN ID is configured as - 1 (untagged), BSU allows only untagged management frames to access it. 	<ul style="list-style-type: none"> • SU forwards both tagged and untagged frames received from the Ethernet interface or from the BSU. • If a valid management VLAN ID is configured, SU allows only management frames tagged with the configured management VLAN ID to access it. • If a valid management VLAN ID is configured, SU tags all management frames generated by the SU with the configured management VLAN ID and priority. • If the management VLAN ID is configured as - 1 (untagged), SU allows only untagged management frames to access them.




BSU in Trunk Mode and SU in Trunk/Access Mode

When the BSU is in Trunk mode, the associated SUs must be in either Trunk mode or Access mode. When an SU associates to a BSU that is in Trunk mode, it gets the VLAN mode from the BSU.

How the BSU and SU function in Trunk mode, and the SU in Access mode, is described in the following table.

BSU Function – Trunk Mode	SU Function – Trunk Mode	SU Function – Access Mode
<ul style="list-style-type: none"> Up to 256 VLAN IDs can be configured on a BSU. BSU discards all untagged frames received from the Ethernet interface or from any of the associated SUs (unexpected). If a valid VLAN ID is configured, BSU forwards only VLAN-tagged frames received from the Ethernet interface or from any of the associated SUs that are tagged with the configured VLAN ID; it discards all other tagged frames. If a valid management VLAN ID is configured, BSU allows only management frames tagged with the configured management VLAN ID to access it. If a valid management VLAN ID is configured, BSU tags all management frames generated by the BSU with the configured management VLAN ID and priority. If the management VLAN ID is configured as -1 (untagged), BSU allows only untagged management frames to access it. 	<ul style="list-style-type: none"> Up to 16 VLAN IDs can be configured on an SU. SU discards all untagged frames received from the Ethernet interface or from the BSU (unexpected). If a valid VLAN ID is configured, SU forwards only VLAN-tagged frames received from the Ethernet interface or from the BSU that are tagged with the configured VLAN ID; it discards all other tagged frames. If a valid management VLAN ID is configured, SU allows only management frames tagged with the configured management VLAN ID to access it. If a valid management VLAN ID is configured, SU tags all management frames generated by the SU with the configured management VLAN ID and priority. If the management VLAN ID is configured as -1 (untagged), SU allows only untagged management frames to access it. 	<ul style="list-style-type: none"> SU discards all tagged frames received from the Ethernet interface and all untagged frames received from the BSU (unexpected). SU tags all untagged frames received from the Ethernet interface with the configured Access VLAN ID and forwards them to the BSU. SU untags all tagged frames received from the BSU that are tagged with the configured Access VLAN ID and forwards them to the Ethernet interface; it discards all other tagged frames from the BSU. If a valid management VLAN ID is configured, SU allows only management frames tagged with the configured management VLAN ID to access it from the BSU. If a valid management VLAN ID is configured, SU tags all management frames generated by the SU with the configured management VLAN ID and priority and forwards them to the BSU. If the management VLAN ID is configured as -1 (untagged), SU allows only untagged management frames to access it from the BSU. SU allows only untagged management frames to access it from the Ethernet interface, regardless of the value of the management VLAN ID.



BSU VLAN Configuration

The HTTP Interface to configure BSU VLAN parameters is shown in the following figure.




The following parameters are configurable:

- **BSU VLAN Mode:** The **BSU VLAN mode** can be either **Transparent** or **Trunk**. By default, the BSU is in Transparent mode.
- **Management VLAN ID:** The **Management VLAN ID** is configurable in any mode. The management VLAN ID has a default value of **untagged** and may be configured with a value in the range of **1** to **4095**.
- **Management VLAN Priority:** The **Management VLAN priority** values range from **0** to **7** and the default priority is **0** (zero).
- **Relaying Flag:** When this flag is enabled, the BSU relays frames between SUs on the same BSU.
- **BSU VLAN Table:** The **BSU VLAN Table** is configurable in both Transparent and Trunk mode, but applies only when the BSU is in Trunk mode. The VLAN ID values for the BSU VLAN Table range from **1** to **4095**. The maximum number of VLAN IDs that can be configured in the BSU VLAN Table is 256. An SU in Trunk mode is assigned VLAN IDs from this table.


Add BSU VLAN Table Entries

To add entries to the BSU VLAN table, click the **Add Table Entries** button. Enter a **VLAN ID** and select a **Status**, then click **Add** to add your entry to the table.



Edit or Delete BSU VLAN Table Entries

To edit or delete entries in the BSU VLAN Table, click the **Edit/Delete Table Entries** button, make your changes, then click **OK** for your changes to take effect.



Restricting Unit Management

Management access to the unit can be easily secured by making management stations or hosts and the unit itself members of a common VLAN. Simply configure a non-zero management VLAN ID: management of the unit will be restricted to members of the same VLAN.

CAUTION: *If a non-zero management VLAN ID is configured, management access to the unit is restricted to hosts that are members of the same VLAN. Ensure your management platform or host is a member of the same VLAN before attempting to manage the unit or you will lose access to the unit.*


Providing Access to Hosts in the Same VLAN

The VLAN feature lets hosts manage the unit. If the **Management VLAN ID** matches a VLAN User ID, those hosts who are members of that VLAN will have management access to the unit.

CAUTION: *Once a VLAN Management ID is configured and is equivalent to one of the VLAN User IDs, all members of that VLAN will have management access to the unit. Be careful to restrict VLAN membership to those with legitimate access to the unit.*


SU VLAN Configuration

The HTTP Interface to configure SU VLAN parameters is shown in the following figure.



Add SU Table Entries

To add entries to the SU VLAN Table, click the **Add Table Entries** button. Enter the desired parameters in the corresponding fields, then click **Add** to add and save the entry.




The following parameters are configurable:

- **MAC:** Enter the MAC address of the SU to be configured.
- **SU VLAN Mode:** The **SU VLAN mode** can be either **Transparent**, **Trunk**, or **Access** (by default, the BSU is in Transparent mode).
 - When the BSU is in Transparent mode, the SU must be in Transparent mode.
 - When the BSU is in Trunk mode, the SU must be in either Access mode or Trunk mode.
 - When the BSU is changed from Transparent mode to Trunk mode, all the configured SUs are changed to Trunk mode by default.
- **Access VLAN ID:** The **Access VLAN ID** is configurable in any mode, but applies only when the SU is in Access mode. The Access VLAN ID values range from **1** to **4095**; the default value is **1**.
- **Access VLAN Priority:** The **Access VLAN Priority** is configurable in any mode, but applies only when the SU is in Access mode. The Access VLAN priority values range from **0** to **7**; the default priority is **0**. For voice frames, the priority field is set to the VoIP configured value (**5** according to latest IETF draft, or **6** according to IEEE 802.1D) regardless of the priority value configured.
- **Management VLAN ID:** The **management VLAN ID** is configurable in any mode. The management VLAN ID has a default value of **untagged (-1)** and may be configured with a value in the range of **1** to **4095**.
- **Management Priority:** The **Management VLAN priority** values range from **0** to **7** and the default priority is **0** (zero).
- **VLAN 1-16:** The **VLAN IDs** are configurable in any mode, but apply only when the SU is in Trunk mode. The VLAN ID values range from **1** to **4095**; the default value is **untagged (-1)**. The maximum number of VLAN IDs that can be configured in the SU VLAN Table is 16 for each SU. The SU VLAN IDs must be in the BSU VLAN Table that corresponds to the BSU.

Edit SU Table Entries

To edit SU table entries, click the **Edit/Delete Table Entries** button; make your changes on the window displayed, then click **OK** to save your changes.



Typical User VLAN Configurations

VLANs segment network traffic into groups, which lets you limit broadcast and multicast traffic. These groups enable hosts from different VLANs to access different resources using the same network infrastructure. Hosts using the same physical network are limited to those resources available to their workgroup.

The unit can segment users into a maximum of 16 different VLANs per unit, based upon a VLAN ID.

The primary scenarios for using VLAN workgroups are as follows:

- **VLAN disabled:** Your network does not use VLANs.
- **VLAN enabled:** Each VLAN workgroup uses a different VLAN ID Tag. A mixture of Tagged and Untagged workgroups may be supported.

QoS (Quality of Service) Parameters

The Quality of Service (QoS) feature is based on 802.16 standard and defines the classes, service flows (SFCs), and packet identification rules (PIRs) for specific types of traffic. QoS main priority is to guarantee a reliable and adequate transmission quality for all traffic types under conditions of high congestion and bandwidth over-subscription (for a complete discussion on QoS see [Quality of Service \(QoS\)](#)).

There are already several pre-defined QoS classes, SFCs and PIRs available that you may choose from which cover the most common types of traffic. If you want to configure something else, you start building the hierarchy of a QoS class by defining PIRs; then you associate some of those PIRs to specific Service Flow classes (SFCs); you assign priorities to each PIR within each SFC; and finally you define the QoS class by associating relevant SFCs to each QoS class.

QoS PIR Configuration


Click the Configure button, the QoS tab and the QoS PIR Table sub-tab. The 17 predefined PIRs are shown.

QoS PIR Table
This page allows you to define up to 64 Packet Identification Rules. Changes take effect immediately.

PIR Index	PIR Name	Status	
1	All	enable	Details
2	Cisco VoIP UL	enable	Details
3	Vonage VoIP UL	enable	Details
4	Cisco VoIP DL	enable	Details
5	Vonage VoIP DL	enable	Details
6	TCP	enable	Details
7	UDP	enable	Details
8	PPPoE Control	enable	Details
9	PPPoE Data	enable	Details
10	IP	enable	Details
11	ARP	enable	Details
12	Expedited Forwarding	enable	Details
13	Streaming Video	enable	Details
14	802.1p BE	enable	Details
15	802.1p Voice	enable	Details
16	802.1p Video	enable	Details
17	L2 Broadcast/Multicast	enable	Details

Add Table Entries

To view/edit the parameters of each PIR click on its **Details** button. You may enable, disable or delete this PIR entry by clicking on the **Status** drop-down box and then clicking **OK**.




To add entries to the PIR Table, click the **Add Table Entries** button. Enter the **Rule Name** and select Enable or Disable from the **Entry Status** drop-down box, then click **Add** to add the entry. Once the new entry shows up on the screen, click its **Details** button to view/edit its parameters.




QoS SFC Configuration

Click the **Configure** button, the **QoS** tab and the **QoS SF Class** sub-tab. The 7 predefined SFCs are shown.



To add entries to the SFC Table, click the **Add Table Entries** button.



The following parameters are configurable:


- **SF Name:** Enter the name of the SF class you want to add.
- **SF Sched Type:** This field can be set to **BE** (Best Effort) or **RtPS** (Real-Time Polling Service).
- **SF Direction:** This field can be set to **Downlink** (DL: traffic from BSU to SU) or **Uplink** (UL: traffic from SU to BSU).
- **MIR (Maximum Information Rate):** The maximum sustained data rate specified in units of 1 Kbps from 8 Kbps up to the maximum rate of 108000 Kbps per SU.
- **CIR (Committed Information Rate):** The minimum reserved traffic rate specified in units of 1 Kbps from 0 Kbps up to the maximum rate of 10000 Kbps per SU.
- **Latency:** The maximum allowed latency specified in increments of 5 ms steps from a minimum of 5 ms up to a maximum of 100 ms.
- **Jitter:** The maximum tolerable jitter specified in increments of 5 ms steps from a minimum of 0 ms up to the Maximum Latency (in ms).
- **Priority:** The priority of this SFC from zero (0) to seven (7), 0 being the lowest, 7 being the highest.
- **Number of Frames per Burst:** The Maximum number of data messages in a Multi-Frame burst from one (1) to four (4), which affects the percentage of the maximum throughput of the system according to the table.

QoS (Quality of Service) Parameters

- **SF Entry State:** This field can be set to **Enable**, **Disable**, or **Delete**.

Click **Add** to add the entry. The new entry will show up on the screen taking up the next sequential index entry.

To make changes to the entries of the SFC Table, click the **Edit/Delete Table Entries** button.




Enter your changes and click **OK**. To delete an entry, click the **Status** drop-down box and select **Delete**, then click **OK**.

QoS Class Configuration


Click the **Configure** button, the **QoS** tab and the **QoS Class** sub-tab. The 4 predefined QoS classes are shown.




To view/edit a QoS Class click on its **Details** button. You may enable, disable or delete this QoS Class entry by clicking on the **Status** drop-down box and then clicking **OK**. You may also edit an existing SFC associated to this QoS class, or add a new SFC.



To edit an existing SFC associated to this QoS Class click its **Details** button. You may enable, disable or delete this SFC entry by clicking on the **Status** drop-down box and then clicking **OK**. You may also delete a PIR associated to this SFC by clicking on the **Status** drop-down box and then clicking **OK**, or add a new PIR to this SFC.



To add more PIRs to this SFC click the **Add Table Entries** button.



The following parameters are configurable:

- **PIR Table Reference Index:** Select one of the possible PIRs that have been previously configured from the drop-down box.
- **PIR Priority:** This priority per rule defines the order of execution of PIRs during packet identification process. The PIR priority is a number in the range 0-63, with priority 63 being executed first, and priority 0 being executed last. The PIR priority is defined within a QoS class, and can be different for the same PIR in some other QoS class. If all PIRs within one QoS class have the same priority, the order of execution of PIR rules will be defined by the order of definition of SFCs, and by the order of definition of PIRs in each SFC, within that QoS class.
- **Entry Status:** This field is always set to **Enable**.

Click **Add** to add the entry. The new entry will show up on the screen taking up the next sequential index entry. You may delete any PIR entry by clicking on the **Status** drop-down box.

Back to the QoS Class screen, to add a new SFC and associate it to this QoS Class click the **Add Table Entries** button.



The following parameters are configurable:

QoS (Quality of Service) Parameters

- **SF Table Reference Index:** Select one of the possible SFCs that have been previously configured from the drop-down box to associate to this QoS Class.
- **PIR Table Reference Index:** Select one of the possible PIRs that have been previously configured from the drop-down box to associate to this SFC.
- **PIR Priority:** This priority per rule defines the order of execution of PIRs during packet identification process. The PIR priority is a number in the range 0-63, with priority 63 being executed first, and priority 0 being executed last. The PIR priority is defined within a QoS class, and can be different for the same PIR in some other QoS class. If all PIRs within one QoS class have the same priority, the order of execution of PIR rules will be defined by the order of definition of SFCs, and by the order of definition of PIRs in each SFC, within that QoS class.
- **Entry Status:** This field is always set to **Enable**.

Click Add to add the entry. The new entry will show up on the screen taking up the next sequential index entry.

From this screen you may also edit an existing SFC by clicking on its **Details** button. This will take you to the same QoS Class SF Class Entry Details screen.

Finally, to add a new QoS Class click the **Add Table Entries** button on the screen.



The following parameters are configurable:


- **Class Name:** Enter the name of the QoS class you want to add.
- **SF Table Reference Index:** Select one of the possible SFCs that have been previously configured from the drop-down box to associate to this QoS Class.
- **PIR Table Reference Index:** Select one of the possible PIRs that have been previously configured from the drop-down box to associate to this SFC.
- **PIR Priority:** This priority per rule defines the order of execution of PIRs during packet identification process. The PIR priority is a number in the range 0-63, with priority 63 being executed first, and priority 0 being executed last. The PIR priority is defined within a QoS class, and can be different for the same PIR in some other QoS class. If all PIRs within one QoS class have the same priority, the order of execution of PIR rules will be defined by the order of definition of SFCs, and by the order of definition of PIRs in each SFC, within that QoS class.
- **Entry Status:** This field is always set to **Enable**.

Click **Add** to add the entry. The new entry will show up on the screen taking up the next sequential index entry.

From this screen you may also edit an existing QoS Class by clicking on its **Details** button. This will take you to the same QoS Class Entry View/Edit screen.

QoS SU Configuration

Click the **Configure** button, the **QoS** tab and the **QoS SU** sub-tab.



This screen defines which QoS Classes will be associated to which given SUs by using their MAC addresses.

To add entries to the QoS SU Table, click the **Add Table Entries** button.



The following parameters are configurable:

- **SU MAC Address:** The MAC Address of the SU you want to associate to a specific QoS Class.
- **SU QoSC Index:** Select one of the possible QoS Classes that have been previously configured from the drop-down box to associate to this SU.
- **SU QoSC State:** This field can be set to **Enable**, **Disable**, or **Delete**.

Click **Add** to add the entry. The new entry will show up on the screen taking up the next sequential index entry.

To make changes to QoS SU Table, click the **Edit/Delete Table Entries** button.



Enter your changes and click **OK**. To delete an entry, click the **Status** drop-down box and select **Delete**, then click **OK**.


SU Access to the Public Network (NAT)

The NAT (Network Address Translation) feature lets hosts on the Ethernet side of the SU transparently access the public network through the BSU. All hosts in the private network can have simultaneous access to the public network.

NOTE: The NAT tab is available for SUs in Routing mode only. The SU supports NAPT (Network Address Port Translation) where all private IP addresses are mapped to a single public IP address, and does not support Basic NAT (where private IP addresses are mapped to a pool of public IP addresses).

Both **dynamic mapping** (allowing private hosts to access hosts in the public network) and **static mapping** (allowing public hosts to access hosts in the private network) are supported.

- In dynamic mapping, the SU maps the private IP addresses and its transport identifiers to transport identifiers of a single Public IP address as they originate sessions to the public network. This is used only for outbound access.
- Static mapping is used to provide inbound access. The SU maps a private IP address and its local port to a fixed public port of the global IP address. This is used to provide inbound access to a local server for hosts in the public network. Static port mapping allows only one server of a particular type. Up to 1000 ports (500 UDP and 500 TCP) are supported.



The following parameters are configurable:

- **NAT Status:** Enables or disables the NAT feature. NAT can be enabled only for SUs in Routing mode. The default is disabled.
NOTE: Changes to NAT parameters, including the NAT Static Port Mapping Table, require a reboot to take effect.
- **NAT Static Bind Status:** Enables or disables the NAT Static Bind status (static mapping) allowing public hosts to access hosts in a private network. The default is disabled.
- **Public IP Address:** The NAT Public IP address is the wireless interface IP address.

NAT Feature Interactions

When NAT is enabled, the DHCP Relay Agent feature is not supported (DHCP Relay Agent must be disabled before NAT is enabled) and RIP updates are not sent or received.

You can configure a DHCP server to allocate IP addresses to hosts on the Ethernet side of the SU/ BSU (see [Enable and Configure the DHCP Server](#)).

NAT Static Port Mapping Table

Adding entries to the NAT Static Mapping Table lets configured hosts in a private address realm on the Ethernet side of the SU access hosts in the public network using Network Address Port Translation (NAPT). Up to 1000 entries can be configured (500 UDP ports and 500 TCP ports).

Adding Entries


To add an entry:

1. Click the **Add Table Entries** button.
2. Enter the **Local IP Address** of the host on the Ethernet side of the SU.
3. Select the **Port Type**: **TCP**, **UDP**, or **Both**.
4. Enter the **Start Port** and **End Port**.
5. Click **Add**.



Editing Entries

To make changes to an entry, click the **Edit/Delete Table Entries** button. Enter your changes and click **OK**. To delete an entry, click the **Status** drop-down box and select **Delete**, then click **OK**.



Supported Session Protocols

The NAT feature supports the following session protocols for both inbound and outbound access with the required support, applications, and limitations given in the following table.

Certain Internet applications require an Application Level Gateway (ALG) to provide the required transparency for an application running on a host in a private network to connect to its counterpart running on a host in the public network. An ALG may interact with NAT to set up state information, use NAT state information, modify application specific payload and perform the tasks necessary to get the application running across address realms.

No more than one server of a particular type is supported within the private network behind the SU.

These VPN protocols are supported with their corresponding ALGs: IPsec, PPTP, L2TP.

Supported Session Protocols			
Protocol	Support	Applications	Limitations
ICMP	ICMP ALG	Ping	

Supported Session Protocols			
Protocol	Support	Applications	Limitations
FTP	FTP ALG	File transfer	
H.323	H.323 ALG	Multimedia conferencing	
HTTP	Port mapping for inbound connection.	Web browser	
TFTP	Port mapping for inbound connection.	File transfer	
Telnet	Port mapping for inbound connection.	Remote login	
CUSEEME	Port mapping for inbound and outbound connection.	Video conferencing	One user is allowed for video conferencing
IMAP	Port mapping for inbound connection.	Mail	
PNM	Port mapping for inbound connection.	Streaming media with Real Player	
POP3	Port mapping for inbound connection.	E-mail	
SMTP	Port mapping for inbound connection.	E-mail	Mails with IP addresses of MTAs or using IP addresses in place of FQDN are not supported (requires SMTP ALG).
RTSP	Port mapping for inbound connection.	Streaming audio/video with Quick Time and Real Player	
ICQ	Port mapping for inbound connection.	Chat and file transfer	Each host using ICQ needs to be mapped for different ports.
IRC	Port mapping for inbound connection.	Chat and file transfer	Each host using IRC needs to be mapped for different ports.
MSN Messenger	Port mapping for inbound and outbound connection.	Conference and Share files with Net meeting	Only one user is allowed for net meeting.
Net2Phone	Port mapping for inbound and outbound connection.	Voice communication	
IP Multicast	Pass Through	Multicasting	
Stream works	Port mapping for inbound connection.	Streaming video	
Quake	Port mapping for inbound connection.	Games	When a Quake server is configured within the private network behind a SU, the SU cannot provide information about that server on the public network. Also, certain Quake servers do not let multiple users log in using the same IP address, in which case only one Quake user is allowed.

Monitoring

This section describes using the Web interface to obtain detailed information about the settings and performance of the 5012.

Click the **Monitor** button to access this information.

The following tabs appear in the **Monitor** section:

- Wireless (see [Monitor the Wireless Settings](#))
- ICMP (see [View Number of ICMP Messages](#))
- Per Station (see [View Per Station Statistics](#))
- Features (see [View Features Supported](#))
- Link Test (see [Test Link Quality](#))
- Interfaces (see [Monitor Interfaces](#))
- IP ARP Table (see [View the Mapping of IP and MAC Addresses](#))
- IP Routes (see [View Active IP Routes](#))
- Learn Table (see [View All Detected MAC Addresses \(Learn Table\)](#))
- RIP (see [View RIP Data](#))
- Radius (see [View RADIUS Traffic Information](#))
- QoS (see [View Quality of Service \(QoS\) Information](#))

NOTE: The **Radius** tab is available on BSUs only. The **RIP** tab is relevant only in Routing mode.


Help and Exit buttons also appear on each page of the Web interface; click the **Help** button to access online help; click the **Exit** button to exit the application.

For an introduction to the basics of management, see [Basic Management](#).

Monitor the Wireless Settings

General Performance

Click the **Monitor** button and the **General** tab to monitor the general performance of the wireless interface.




The screenshot shows a web-based monitoring interface. On the left, there is a vertical menu with buttons for Status, Configure, Monitor (highlighted in orange), Commands, Help, and Exit. The main content area has a top navigation bar with tabs for IP ARP Table, IP Routes, Learn Table, RIP, Radius, and QoS. Below this is a sub-navigation bar with tabs for Wireless (highlighted in orange), ICMP, Per Station, Features, Link Test, and Interfaces. The main display area shows the 'General' tab selected, with a sub-tab for 'Worp'. The data is presented in a table for 'Wireless-slot A'.

Wireless-slot A	
Transmitted Fragment Count	17700
Multicast Transmitted Frame Count	17780
Failed Count	0
FCS Error	1
Multicast Received Frame Count	0
Received Fragment Count	0
WEP Undecryptable Count	0

WORP Interface Performance

Click the **Monitor** button, the **Wireless** tab, and the **WORP** tab to monitor the performance of the WORP Base or WORP SU interfaces.



The screenshot shows the same web-based monitoring interface as above, but with the 'Worp' sub-tab selected. The main display area shows the 'Worp' performance data for 'Wireless-slot A'.

Wireless-slot A	
Interface Type	Worp Base
Remotes	
Remote Partners	0
Registration Packet Counter Group	
Base Announces	18503
Registration requests	0
Registration Reject	0
Authentication requests	0
Authentication Confirms	0
Registration Process Counter Group	
Registration attempts	0
Registration Incompletes	0
Registration Time-outs	0
Registration Last Reason	None
Data Packet Counter Group	
Poll Data	0
Poll with No Data Sent	0

Possible values for the **Registration Last Reason** field are as follows:

- 1 = None (successful registration)
- 2 = Maximum number of SUs reached
- 3 = Authentication failure
- 4 = Roaming
- 5 = No response from SU within the Registration Timeout Period
- 6 = Low Signal Quality

View Number of ICMP Messages

Click the **Monitor** button and the **ICMP** tab to view the number of ICMP messages sent and received by the 5012. It includes **ping**, **route**, and **host unreachable** messages.




The screenshot shows a web-based network management interface. At the top, there are several tabs: IP ARP Table, IP Routes, Learn Table, RIP, Radius, and QoS. Below these, there are more specific tabs: Wireless, ICMP (highlighted in orange), Per Station, Features, Link Test, and Interfaces. On the left side, there is a vertical menu with buttons for Status, Configure, Monitor (highlighted in orange), Commands, Help, and Exit. The main content area is divided into two columns: Messages Received and Messages Sent. Each column lists various ICMP message types and their corresponding counts, all of which are currently zero.

Messages Received		Messages Sent	
Total Messages	0	Total Messages	0
Errors	0	Errors	0
Destination Unreachable	0	Destination Unreachable	0
Time Exceeded	0	Time Exceeded	0
Parameter Problems	0	Parameter Problems	0
Source Quench	0	Source Quench	0
Redirects	0	Redirects	0
Echos	0	Echos	0
Echo Reply	0	Echo Reply	0
Time Stamps	0	Time Stamps	0
Time Stamp Reply	0	Time Stamp Reply	0
Address Mask	0	Address Mask	0
Address Mask Reply	0	Address Mask Reply	0

View Per Station Statistics


Click the **Monitor** button and the **Per Station** tab to view Station Statistics. On the SU, the “Per Station” page shows statistics of the BSU to which the SU is registered. On the BSU, it shows statistics of all the SU’s connected to the BSU.

The page’s statistics refresh every 4 seconds.



View Features Supported

Click the **Monitor** button and the **Features** tab to view the following information.



Feature	Supported	Licensed
Upstream Bandwidth WORP (in kbits/s)	100032	100032
Downstream Bandwidth WORP (in kbits/s)	100032	100032
Max. WORP Satellites	250	250
Max. Users On Satellite	60535	60535

NOTE: A BSU shows how many WORP SUs it can support; the SU shows how many Ethernet hosts it supports on its Ethernet port as the "Max Users on Satellite" parameter.

Test Link Quality

Click the **Monitor** button and the **Link Test** tab to find out which wireless stations are in range and to check their link quality.

NOTE: Link Test requires Internet Explorer version 6.0 or later. Earlier versions do not support Link Test.


Link Test for the unit reports the Signal-to-Noise Ratio (SNR) value in dB; the higher this number, the better the signal quality. Furthermore, it reports the signal level and noise level in dBm. The latter two are approximations of the level at which the unit receives the signal of the peer unit and the background noise.

- Clicking **Explore** from a BSU displays all its registered SUs.
- Clicking **Explore** from an SU displays only the BSU with which it is registered.



All stations displayed after “Explore” come up “Disabled.” Select a station by changing **Disabled** to **Start** and click the **Link Test** button. You can change multiple stations to **Start**, but only the last station in the list is displayed as the remote partner when you click the **Link Test** button.

The Link Test provides SNR, Signal, and Noise information for both, the local and the remote unit’s levels. Link Test stops when you close the **Link Test** page.



Monitor Interfaces

Click the **Monitor** button and the **Interfaces** tab to view detailed information about the IP-layer performance of the unit's interfaces. There are two sub-tabs: **Wireless** and **Ethernet**. The following figures show both interfaces.

Ethernet	
Type	ethernet-csmcd
Description	Ethernet Interface
MIB Specific Definition	0.0
Physical Address	00:20:A6:56:9E:98
Time Since Last Change(DD:HH:MM:SS)	00:00:47:45
Operational Status	Up
Admin Status	Up
Speed	100000000
Maximum Packet Size	1504
In Octets (bytes)	854726
In Unicast Packets	2591
In Non-unicast Packets	75
In Discards	0
In Errors	0
Unknown Protocols	0
Out Octets (bytes)	170994
Out Unicast Packets	2992
Out Non-unicast Packets	70
Out Discards	0
Out Errors	0
Output Queue Length	0

Wireless	
Type	802.11a
Description	WORP Interface
MIB Specific Definition	0.0
Physical Address	00:30:F1:E8:82:96
Time Since Last Change(DD:HH:MM:SS)	00:00:52:58
Operational Status	down
Admin Status	Up
Speed	36000000
Maximum Packet Size	1512
In Octets (bytes)	0
In Unicast Packets	0
In Non-unicast Packets	0
In Discards	33
In Errors	2
Unknown Protocols	0
Out Octets (bytes)	4769748
Out Unicast Packets	0
Out Non-unicast Packets	21248
Out Discards	0
Out Errors	0
Output Queue Length	0

View the Mapping of IP and MAC Addresses

View the Mapping of IP and MAC Addresses

Click the **Monitor** button and the **IP ARP Table** tab to view the mapping of the IP and MAC addresses of all radios registered at the 5012. This information is based upon the Address Resolution Protocol (ARP).



View Active IP Routes

Click the **Monitor** button and the **IP Routes** tab to view all active IP routes of the 5012. These can be either **static** or **dynamic** (obtained through RIP). This tab is available only in **Routing** mode, and you can add routes only when in **Routing** mode.



Destination	Subnet Mask	Next Hop	Interface	Metric
0.0.0.0	0.0.0.0	10.0.0.1	1	0
10.0.0.0	255.255.255.0	10.0.0.1	1	0
127.0.0.1	255.255.255.255	127.0.0.1	0	0

View All Detected MAC Addresses (Learn Table)

View All Detected MAC Addresses (Learn Table)

Click the **Monitor** button and the **Learn Table** tab to view all MAC addresses the 5012 has detected on an interface. The **Learn Table** displays information relating to network bridging. It reports the MAC address for each node that the device has learned is on the network and the interface on which the node was detected. There can be up to 10,000 entries in the **Learn Table**. This tab is only available in **Bridge** mode.



View RIP Data

Click the **Monitor** button and the **RIP** tab to view Routing Internet Protocol data for the Ethernet and Wireless interfaces.

The screenshot displays a web-based monitoring interface for RIP. On the left is a vertical sidebar with buttons for Status, Configure, Monitor (highlighted in orange), Commands, Help, and Exit. The main content area has a top navigation bar with tabs for Wireless, ICMP, Per Station, Features, Link Test, and Interfaces. Below this is a sub-navigation bar with tabs for IP ARP Table, IP Routes, Learn Table, RIP (highlighted in orange), Radius, and QoS. The main display area shows the following data:

Routes Changed	0	
Responses to Route Requests	0	
	Ethernet	Wireless-slot A
Address	10.0.0.1	10.0.1.1
Network Mask	255.255.255.0	255.255.255.0
Triggered Advertisements		
Bad Routes		
Bad Packets		

View RADIUS Traffic Information


Click the **Monitor** button and the **Radius** tab to view information about the traffic exchanged with a RADIUS server.

The screenshot shows a web-based monitoring interface. On the left is a vertical sidebar with buttons: Status, Configure, Monitor (highlighted in orange), Commands, Help, and Exit. The main content area has a top navigation bar with tabs: Wireless, ICMP, Per Station, Features, Link Test, and Interfaces. Below this is a sub-navigation bar with tabs: IP ARP Table, IP Routes, Learn Table, RIP, Radius (highlighted in orange), and QoS. The main content area displays a table of RADIUS traffic statistics. At the top left of the table, it says 'Invalid Server Replies' with a value of '0'. Below this, the table is divided into two columns: 'Primary' and 'Backup'. Each column lists various RADIUS events and their counts, all of which are currently zero.

Primary		Backup	
Access Requests	0	Access Requests	0
Access Accepts	0	Access Accepts	0
Access Retransmissions	0	Access Retransmissions	0
Access Rejects	0	Access Rejects	0
Access Challenges	0	Access Challenges	0
Malformed Access Responses	0	Malformed Access Responses	0
Authentication Bad Authenticators	0	Authentication Bad Authenticators	0
Timeouts	0	Timeouts	0

View Quality of Service (QoS) Information

Click the **Monitor** button and the **QoS** tab to view summary information about the Quality of Service per BSU and for each SU registered with that BSU.



Commands

This section describes the commands that you can issue with the Web Interface.

Click the Commands button to access available commands. See the following:

- Download (see [Download Files](#))
- Upload (see [Upload Files](#))
- Reboot (see [Reboot the Unit](#))
- Reset (see [Reset the Unit to Factory Default](#))
- Help Link (see [Set the Help Link Location](#))

Help and Exit buttons also appear on each page of the Web interface; click the **Help** button to access online help; click the **Exit** button to exit the application.

For an introduction to the basics of management, see [Basic Management](#).

Download Files

Click the **Commands** button and the **Download** tab to download configuration, image and license files to the unit via a TFTP server (see [TFTP Server Setup](#) for information about the SolarWinds TFTP server software located on your product installation CD).

The following parameters may be configured or viewed:

- **Server IP address:** Enter the TFTP Server IP address.
- **File Name:** Enter the name of the file to be downloaded. If you are using the SolarWinds TFTP server software located on your product installation CD, the default directory for downloading files is **C:\TFTP-Root**.
- **File Type:** Choose either **Config**, **image**, **BspBI**, or **license**.
- **File Operation:** Choose either **Download** or **Download and Reboot**.

Click **OK** to start the download.

Upload Files

Click the **Commands** button and the **Upload** tab to upload a configuration or log file from the unit to a TFTP server (see [TFTP Server Setup](#) for information about the SolarWinds TFTP server software located on your product installation CD).

The screenshot shows a web management console interface. At the top, there are tabs for 'Download', 'Upload' (which is selected and highlighted in orange), 'Reboot', 'Reset', and 'Help Link'. On the left side, there is a vertical menu with buttons for 'Status', 'Configure', 'Monitor', 'Commands' (which is highlighted in orange), 'Help', and 'Exit'. The main content area is titled 'System Information' and displays 'Software Version 3.0.0' and 'Boot Loader Version 3.1.0'. Below this is the 'TFTP Information' section, which contains three input fields: 'Server IP Address' with the value '10.0.0.2', 'File Name' with the value 'FILENAME', and 'Filetype' with a dropdown menu set to 'Config'. A note below the fields reads: 'Note: Upload copies files from the device to the tftp server.' At the bottom of the form are 'OK' and 'Cancel' buttons.


The following parameters may be configured or viewed:

- **Server IP address:** Enter the TFTP Server IP address.
- **File Name:** Enter the name of the file to be uploaded. If you are using the SolarWinds TFTP server software located on your product installation CD, the default directory for uploading files is **C:\TFTP-Root**.
- **File Type:** Choose either **Config**, **Templog**, or **Eventlog**.

Click **OK** to start the upload.

Reboot the Unit


Click the **Commands** button and the **Reboot** tab to reboot the embedded software of the 5012. Configuration changes are saved and the unit is reset.



CAUTION: Rebooting the unit causes all users currently connected to lose their connection to the network until the 5012 has completed the reboot process and resumed operation.

Reset the Unit to Factory Default

Click the **Commands** button and the **Reset** tab to restore the configuration of the 5012 to the factory default values.




You can also reset the 5012 by pressing the RESET button located on the side of the unit. Because this resets the unit's current IP address, a new IP address must be assigned.

CAUTION: *Resetting the 5012 to its factory default configuration permanently overwrites all changes made to the unit. The 5012 reboots automatically after this command has been issued.*

Set the Help Link Location

Click the **Commands** button and the **Help Link** tab to set the location of the help files of the Web Interface. Upon installation, the help files are installed in the **C:\Program Files\Tsunami\MP.11\Help** folder.

If you want to place these files on a shared drive, copy the **Help** folder to the new location and specify the new path in the **Help Link** box.



Procedures

This chapter contains a set of procedures, as described in the following table:

Procedure	Description
TFTP Server Setup	Prepares the TFTP server for transferring files to and from the 5012. This procedure is used by the other procedures that transfer files.
Web Interface Image File Download	Upgrades the embedded software.
Configuration Backup	Saves the configuration of the 5012.
Configuration Restore	Restores a previous configuration through configuration file download.
Soft Reset to Factory Default	Resets the 5012 to the factory default settings through the Web or Command Line Interface.
Hard Reset to Factory Default	In some cases, it may be necessary to revert to the factory default settings (for example, if you cannot access the 5012 or you lost the password for the Web Interface).
Forced Reload	Completely resets the 5012 and erases the embedded software. Use this procedure only as a last resort if the 5012 does not boot and the “Hard Reset to Factory Default” procedure did not help. If you perform a “Forced Reload,” you must download a new image file as described in “Image File Download with the Bootloader.”
Image File Download with the Bootloader	If the 5012 does not contain embedded software, or the embedded software is corrupt, you can use this procedure to download a new image file.

TFTP Server Setup

A Trivial File Transfer Protocol (TFTP) server lets you transfer files across a network. You can upload files from the unit for backup or copying, and you can download the files for configuration and image upgrades. The SolarWinds TFTP server software is located on the product installation CD, or can be downloaded from <http://support.proxim.com>. You can also download the latest TFTP software from SolarWind's Web site at <http://www.solarwinds.net>. **The instructions that follow assume that you are using the SolarWinds TFTP server software**; other TFTP servers may require different configurations.

NOTE: *If a TFTP server is not available in the network, you can perform similar file transfer operations using the HTTP interface.*

To download or upload a file, you must connect to the computer with the TFTP server through the 5012's Ethernet port. This can be any computer in the network or a computer connected to the 5012 with a cross-over Ethernet cable. For information about installing the TFTP server, see [Install Documentation and Software](#).

Ensure that:

1. The upload or download directory is correctly set (the default directory is **C:\TFTP-Root**).
2. The required image file is present in the directory.
3. The TFTP server is running. **The TFTP server must be running only during file upload and download.** You can check the connectivity between the 5012 and the TFTP server by pinging the 5012 from the computer that hosts the TFTP server. The ping program should show replies from the 5012.
4. The TFTP server is configured to both Transmit and Receive files (on the **Security** tab under **File > Configure**), with no automatic shutdown or time-out (on the **Auto-Close** tab).

Web Interface Image File Download

In some cases, it may be necessary to upgrade the embedded software of the 5012 by downloading an image file. To download an image file through the Web Interface:

1. Set up the TFTP server as described in [TFTP Server Setup](#).
2. Access the 5012 as described in [Starting the Web Interface](#).
3. Click the **Commands** button and the **Download** tab.
4. Fill in the following details:
 - **Server IP Address** <IP address TFTP server>
 - **File Name** <image file name>
 - **File Type** Image
 - **File Operation** Download
5. Click OK to start the file transfer.

The 5012 downloads the image file. The TFTP server program should show download activity after a few seconds. When the download is complete, the 5012 is ready to start the embedded software upon reboot.

Configuration Backup

You can back up the 5012 configuration by uploading the configuration file. You can use this file to restore the configuration or to configure another 5012 (see [Configuration Restore](#)).

To upload a configuration file through the Web Interface:

1. Set up the TFTP server as described in [TFTP Server Setup](#).
2. Access the 5012 as described in [Starting the Web Interface](#).
3. Click the **Commands** button and the **Upload** tab.
4. Fill in the following details:
 - **Server IP Address** <IP address TFTP server>
 - **File Name** <configuration file name>
 - **File Type** Config
 - **File Operation** Upload
5. Click **OK** to start the file transfer.

The 5012 uploads the configuration file. The TFTP server program should show upload activity after a few seconds. When the upload is complete, the configuration is backed up.

Configuration Restore

You can restore the configuration of the 5012 by downloading a configuration file. The configuration file contains the configuration information of an 5012.

To download a configuration file through the Web Interface:

1. Set up the TFTP server as described in [TFTP Server Setup](#).
2. Access the 5012 as described in [Starting the Web Interface](#).
3. Click the **Commands** button and the **Download** tab.
4. Fill in the following details:
 - **Server IP Address** <IP address TFTP server>
 - **File Name** <configuration file name>
 - **File Type** Config
 - **File Operation** Download
 - Click **OK** to start the file transfer.

The 5012 downloads the configuration file. The TFTP server program should show download activity after a few seconds. When the download is complete and the system rebooted, the configuration is restored.

Soft Reset to Factory Default

If necessary, you can reset the 5012 to the factory default settings. Resetting to default settings means that you must configure the 5012 anew.

To reset to factory default settings using the Web Interface:

1. Click the **Commands** button and the **Reset** tab.
2. Click the **Reset to Factory Default** button.


The device configuration parameter values are reset to their factory default values.

If you do not have access to the 5012, you can use the procedure described in “Hard Reset to Factory Default” below as an alternative.

Hard Reset to Factory Default

If you cannot access the unit or you have lost its password, you can reset the 5012 to the factory default settings. Resetting to default settings means you must configure the 5012 anew.

To reset to factory default settings, press and hold the RELOAD button on the side of the 5012 unit for about 10 seconds. Image and configuration are deleted from the unit, the unit reboots and restores the factory default settings.



Forced Reload

With Forced Reload, you reset the 5012 to the factory default settings and erase the embedded software. Use this procedure only as last resort if the 5012 does not boot and the “Reset to Factory Defaults” procedure did not help. If you perform a Forced Reload, you must download a new image file with the Bootloader (see [Image File Download with the Bootloader](#) below).

CAUTION: *The following procedure erases the embedded software of the 5012. This software image must be reloaded through an Ethernet connection with a TFTP server. The image filename to be downloaded can be configured with ScanTool through the Ethernet interface to make the 5012 functional again.*

To do a forced reload:

1. Press the RESET button on the 5012 unit; the 5012 resets and the LEDs flash.
2. Immediately press and hold the RELOAD button on the 5012 unit for about 20 seconds. Now image and configuration are deleted from the unit.
3. Follow the procedure “Image File Download with the Bootloader” to download an image file.

Image File Download with the Bootloader

The following procedures download an image file to the 5012 after the embedded software has been erased with **Forced Reload** or when the embedded software cannot be started by the Bootloader. A new image file can be downloaded to the 5012 with ScanTool. The file is transferred through Ethernet with TFTP.

Download with ScanTool

To download an image file with the ScanTool:

1. Set up the TFTP server as described in [TFTP Server Setup](#).
2. Run ScanTool on a computer that is connected to the same LAN subnet as the unit. ScanTool scans the subnet for units and displays the found units in the main window. If in **Forced Reload**, ScanTool does not find the device until the unit Bootloader times out from its default operation to download an image. Click **Rescan** to re-scan the subnet and update the display until the unit shows up in Bootloader mode.
3. Select the unit to which you want to download an image file and click Change.
4. Ensure that **IP Address Type Static** is selected and fill in the following details:
 - Password
 - IP Address and Subnet Mask of the unit.
 - **TFTP Server IP Address** and, if necessary, the **Gateway IP Address** of the TFTP server.
 - **Image File Name** of the file with the new image.
5. Click **OK** to start the file transfer.

The unit downloads the image file. The TFTP server program should show download activity after a few seconds. When the download is complete, the LED pattern should return to **reboot** state. the unit is ready to start the embedded software.

After a Forced Reload procedure, the 5012 returns to factory default settings and must be reconfigured. ScanTool can be used to set the system name and IP address.

To access the 5012 see [Starting the Web Interface](#).

Troubleshooting

This chapter helps you to isolate and solve problems with your 5012. In the event this chapter does not provide a solution, or the solution does not solve your problem, check our support website at <http://support.proxim.com>.

Before you start troubleshooting, it is important that you have checked the details in the product documentation. For details about RADIUS, TFTP, terminal and telnet programs, and Web browsers, refer to their appropriate documentation.

In some cases, rebooting the 5012 clears the problem. If nothing else helps, consider a [Soft Reset to Factory Default](#) or a [Forced Reload](#). The Forced Reload option requires you to download a new image file to the 5012.

See the following:

- [Connectivity Issues](#)
- [Communication Issues](#)
- [Setup and Configuration Issues](#)
- [VLAN Operation Issues](#)
- [Link Problems](#)

Connectivity Issues

The issues described in this section relate to the connections of the 5012.

5012 Does Not Boot

The 5012 shows no activity (the power LED is off).

1. Ensure that the power supply is properly working and correctly connected.
2. Ensure that all cables are correctly connected.
3. Check the power source.
4. If you are using an Active Ethernet splitter, ensure that the voltage is correct.

Ethernet Link Does Not Work

1. First check the Ethernet LED:
 - Solid Green: Power is on, the radio is up, and the Ethernet link is also up.
 - Blinking Green: Power is on, the radio is coming up and the Ethernet is down.
2. Verify pass-through versus cross-over cable.

Cannot use the Web Interface

1. Open a command prompt window and enter `ping <ip address unit>` (for example `ping 10.0.0.1`). If the unit does not respond, make sure that you have the correct IP address.
If the unit responds, the Ethernet connection is working properly, continue with this procedure.
2. Ensure that you are using one of the following Web browsers:
 - Microsoft Internet Explorer version 5.0 or later (Version 6.0 or later recommended)
 - Netscape version 6.0 or later.
3. Ensure that you are not using a proxy server for the connection with your Web browser.
4. Ensure that you have not exceeded the maximum number of Web Interface or CLI sessions.

5. Double-check the physical network connections. Use a well-known unit to ensure the network connection is properly functioning.
6. Perform network infrastructure troubleshooting (check switches, routers, and so on).

Communication Issues

Two Units Are Unable to Communicate Wirelessly

If a wireless link is possible after testing two units within close distance of each other, then there are two possible reasons why wireless connectivity is not possible while the MP.11 units are at their desired locations:

There may be a problem in the RF path, for example, a bad connector attachment (this is the most common problem in installations) or a bad cable (water ingress).

NOTE: *The cables can be swapped with known good ones as a temporary solution to verify cable quality.*

Another reason may be related to an interference problem caused by a high signal level from another radio. This can be checked by changing the frequency and then verifying whether another channel works better or by changing the polarization as a way of avoiding the interfering signal. To know in advance how much interference is present in a given environment, a Spectrum Analyzer can be attached to a (temporary) antenna for measuring the signal levels on all available Channels.

NOTE: *The antennas are usually not the problem, unless mounted upside down causing the drain hole to be quickly filled with radome.*

If a wireless link is not possible after testing two units within close distance of each other, then the problem is either hardware or configuration related, such as a wrong Network name, Encryption key, Network Secret or Base Station Name. To eliminate these issues from being a factor, resetting the both units to factory defaults is the recommended solution.

If a wireless link is not possible after resetting the units and verifying that one unit is a BSU with WORP Base interface configured and the other is a Satellite, then the problem is not configuration related and the only remaining reason is a possible hardware problem. Acquiring a third unit and then testing it amongst the existing units will help pinpoint the broken unit.

Setup and Configuration Issues

The following issues relate to setup and configuration problems.

Lost Password

If you lost your password, you must reset the 5012 to the default settings. See [Hard Reset to Factory Default](#). The default password is **public**.

If you record your password, keep it in a safe place.

The 5012 Responds Slowly

If the 5012 takes a long time to become available, it could mean that:

- No DHCP server is available.
- The IP address of the 5012 is already in use.

Verify that the IP address is assigned only to the 5012. Do this by switching off the 5012 and then pinging the IP address. If there is a response to the ping, another device in the network is using the same IP address. If the 5012 uses a static IP address, switching to DHCP mode could remedy this problem. Also see [Setting the IP Address](#).

- There is too much network traffic.

TFTP Server Does Not Work

With TFTP, you can transfer files to and from the 5012. Also see [TFTP Server Setup](#). If a TFTP server is not properly configured and running, you cannot upload and download files. The TFTP server:

- Can be situated either local or remote
- Must have a valid IP address
- Must be set for send and receive without time-out
- Must be running only during file upload and download

If the TFTP server does not upload or download files, it could mean:

- The TFTP server is not running
- The IP address of the TFTP server is invalid
- The upload or download directory is not correctly set
- The file name is not correct

Online Help Is Not Available

Online help is not available:

1. Make sure that the Help files are installed on your computer or server. Also see [Install Documentation and Software](#).
2. Verify whether the path of the help files in the Web Interface refers to the correct directory. See [Set the Help Link Location](#).

Changes Do Not Take Effect

Changes made in the Web Interface do not take effect:

1. Restart your Web browser.
2. Log into the radio unit again and make changes.
3. Reboot the radio unit when prompted to do so.

Wait until the reboot is completed before accessing the 5012 again.

VLAN Operation Issues

The correct VLAN configuration can be verified by “pinging” wired hosts from both sides of the device and the network switch. Traffic can be “sniffed” on the wired (Ethernet) network. Packets generated by hosts and viewed on one of the backbones should contain IEEE 802.1Q compliant VLAN headers when in Transparent mode. The VLAN ID in the headers should correspond to one of the VLAN Management IDs configured for the unit in Trunk mode.

The correct VLAN assignment can be verified by pinging:

- The unit to ensure connectivity
- The switch to ensure VLAN properties
- Hosts past the switch to confirm the switch is functional

Ultimately, traffic can be “sniffed” on the Ethernet interface using third-party packages. Most problems can be avoided by ensuring that 802.1Q compliant VLAN tags containing the proper VLAN ID have been inserted in the bridged frames. The VLAN ID in the header should correspond to the assigned VLAN.

What if network traffic is being directed to a nonexistent host?

- All sessions are disconnected, traffic is lost, and a manual override is necessary.
- Workaround: You can configure the switch to mimic the nonexistent host.

Link Problems

While wireless networking emerges more and more, the number of wireless connections to networks grows every day. The Tsunami MP.11 5012 is one of the successful product families used by customers today who enjoy the day after day high-speed, cost-effective connections. To successfully use the connections, technicians must be able to troubleshoot the system effectively. This section gives hints on how a 5012 network could be analyzed in the case of “no link,” a situation in which the customer thinks that the link is down because there is no traffic being passed.

The four general reasons that a wireless link may not work are related to:

- Hardware
- Configuration
- Path issues (such as distance, cable loss, obstacles)
- Environment (anything that is outside the equipment and not part of the path itself)

You have tested the equipment in the office and have verified that the hardware and configurations are sound. The path calculation has been reviewed, and the path has been double-checked for obstacles and canceling reflections. Still, the user reports that the link does not work.

Most likely, the problem reported is caused by the environment or by improper tests to verify the connection. This article assumes that the test method, cabling, antennas, and antenna alignment have been checked. Always do this before checking the environment.

General Check

Two general checks are recommended before taking any action:

- Check whether the software version at both sides is the most current
- Check for any reported alarm messages in the Event Log

Statistics Check

Interference and other negative environment factors always have an impact on the number of correctly received frames. The Tsunami MP.11 models give detailed information about transmission errors in the Web interface, under **Monitor**.

The windows that are important for validating the health of the link are:

- **Monitor / Wireless / General (Lowest level of the wireless network):** Check FCS errors: Rising FCS errors indicate interference or low fade margin. So does **Failed count**. If only one of those is high, this indicates that a source of interference is significant near one end of the link.
- **Monitor / Interfaces / Wireless (One level higher than Wireless / General):** The information is given after the wireless Ethernet frame is converted into a normal Ethernet frame. The parameters shown are part of the MIB-II.
 - Both operational and admin status should be **up**. An admin status of **down** indicates that the interface is configured to be down.
 - **In Discards** and **Out Discards** indicate overload of the buffers, likely caused by network traffic, which is too heavy.
 - **In Errors** and **Out Errors** should never happen; however, it might happen if a frame's FCS was correct while the content was still invalid.
- **Monitor / Wireless / WORP (Statistics on WORP):** WORP runs on top of normal Ethernet, which means that the WORP frame is in fact the data field of the Ethernet frame. **Send Failure** or **Send Retries** must be low in comparison to **Send Success**. **Low** is about 1%. The same applies for **Receive Success** versus **Receive Retries** and **Receive Failures**. Note that the **Receive Failures** and **Retries** can be inaccurate. A frame from the remote site might have been transmitted without even being received; therefore, the count of that frame might not have been added to the statistics and the receiver simply could not know that there was a frame.

- **Remote Partners** indicates how many SUs are connected (in case of a BSU) or whether a Base is connected (in case of a Subscriber).
- **Base Announces** should increase continuously.
- **Registration Requests** and **Authentication Requests** should be divisible by 3. WORP is designed in a way that each registration sequence starts with 3 identical requests. It is not a problem if, once in a while, one of those requests is missing. Missing requests frequently is to be avoided.
- **Monitor / Per Station (Information per connected remote partner):** Check that the received signal level (RSL) is the same on both sides; this should be the case if output power is the same. Two different RSLs indicate a broken transmitter or receiver. A significant difference between Local Noise and Remote Noise could indicate a source of interference near the site with the highest noise. Normally, noise is about –80 dBm at 36 Mbps. This number can vary from situation to situation, of course, also in a healthy environment.
- **Monitor / Link Test (Information used by Administrators for on-the-spot checking):** Check the received signal level (RSL) and noise level. Compare the RSL with the values from path analysis. If the figures differ significantly from the values recorded at the Per Station window, check for environment conditions that change over time.

Analyzing the Spectrum

The ultimate way to discover whether there is a source of interference is to use a spectrum analyzer. Usually, the antenna is connected to the analyzer when measuring. By turning the antenna 360 degrees, one can check from which direction the interference is coming. The analyzer will also display the frequencies and the level of signal is detected.

Proxim recommends performing the test at various locations to find the most ideal location for the equipment.

Avoiding Interference

When a source of interference is identified and when the level and frequencies are known, the next step is to avoid the interference. Some of the following actions can be tried:

- Changing the channel to a frequency away from the interference is the first step in avoiding interference. For countries that require DFS, it might be not possible to manually select a different frequency.
- Each antenna has a polarization; try to change to a polarization different from the interferer.
- A small beam antenna looks only in one particular direction. Because of the higher gain of such an antenna, lowering the output power or adding extra attenuation might be required to stay legal. This solution cannot help when the source of interference is right behind the remote site.
- Lowering the antennas can help avoid seeing interference from far away.

Move the antennas to a different location on the premises. This causes the devices to look from a different angle, causing a different pattern in the reception of the signals. Use obstructions such as buildings, when possible, to shield from the interference.

Conclusion

A spectrum analyzer can be a great help to identify whether interference might be causing link problems on Tsunami MP.11 systems.

Before checking for interference, the link should be verified by testing in an isolated environment, to make sure that hardware works and your configurations are correct. The path analysis, cabling and antennas should be checked as well.

Statistics in the web interface under Monitor tell if there is a link, if the link is healthy, and a continuous test can be done using the Link Test.



Country Codes and Channels

In the CLI and MIB browser, the country code is set using the string code, as shown in the following example.

Example: To set Taiwan as the country:
`set syscountrycode tw`

Model 5012 (5.8 GHz) Channels/Frequencies by Country

Country (Code)	Frequency Bands	DFS	Allowed Channels (Center Freq)		
			20 MHz	10 MHz (N/A to the 5012)	5 MHz (N/A to the 5012)
Argentina (AR)	5.25 - 5.35 GHz and 5.725 - 5.825 GHz	No	56 (5280), 60 (5300), 64 (5320), 149 (5745), 153 (5765), 157 (5785), 161 (5805)	56 (5280), 58 (5290), 60 (5300), 62 (5310), 64 (5320), 149 (5745), 151 (5755), 153 (5765), 155 (5775), 157 (5785), 159 (5795), 161 (5805)	56 (5280), 57 (5285), 58 (5290), 59 (5295), 60 (5300), 61 (5305), 62 (5310), 63 (5315), 64 (5320), 149 (5745), 150 (5750), 151 (5755), 152 (5760), 153 (5765), 154 (5770), 155 (5775), 156 (5780), 157 (5785), 158 (5790), 159 (5795), 160 (5800), 161 (5805)
Australia (AU)	5.725 - 5.85 GHz	No	149 (5745), 153 (5765), 157 (5785), 161 (5805), 165 (5825)	147 (5735), 149 (5745), 151 (5755), 153 (5765), 155 (5775), 157 (5785), 159 (5795), 161 (5805), 163 (5815), 165 (5825), 167 (5835)	147 (5735), 148 (5740), 149 (5745), 150 (5750), 151 (5755), 152 (5760), 153 (5765), 154 (5770), 155 (5775), 156 (5780), 157 (5785), 158 (5790), 159 (5795), 160 (5800), 161 (5805), 162 (5810), 163 (5815), 164 (5820), 165 (5825), 166 (5830), 167 (5835)
Austria (AT)	5.47 - 5.725 GHz	Yes	100 (5500), 104 (5520), 108 (5540), 112 (5560), 116 (5580), 120 (5600), 124 (5620), 128 (5640), 132 (5660), 136 (5680), 140 (5700)	98 (5490), 100 (5500), 102 (5510), 104 (5520), 106 (5530), 108 (5540), 110 (5550), 112 (5560), 114 (5570), 116 (5580), 118 (5590), 120 (5600), 122 (5610), 124 (5620), 126 (5630), 128 (5640), 130 (5650), 132 (5660), 134 (5670), 136 (5680), 138 (5690), 140 (5700), 142 (5710)	97 (5485), 98 (5490), 99 (5495), 100 (5500), 101 (5505), 102 (5510), 103 (5515), 104 (5520), 105 (5525), 106 (5530), 107 (5535), 108 (5540), 109 (5545), 110 (5550), 111 (5555), 112 (5560), 113 (5565), 114 (5570), 115 (5575), 116 (5580), 117 (5585), 118 (5590), 119 (5595), 120 (5600), 121 (5605), 122 (5610), 123 (5615), 124 (5620), 125 (5625), 126 (5630), 127 (5635), 128 (5640), 129 (5645), 130 (5650), 131 (5655), 132 (5660), 133 (5665), 134 (5670), 135 (5675), 136 (5680), 137 (5685), 138 (5690), 139 (5695), 140 (5700), 141 (5705), 142 (5710)

Country Codes and Channels

Tsunami MP.11 5012-SUI Installation and Management

Model 5012 (5.8 GHz) Channels/Frequencies by Country

Country (Code)	Frequency Bands	DFS	Allowed Channels (Center Freq)		
			20 MHz	10 MHz (N/A to the 5012)	5 MHz (N/A to the 5012)
Belgium (BE)	5.47 - 5.725 GHz	Yes	100 (5500), 104 (5520), 108 (5540), 112 (5560), 116 (5580), 120 (5600), 124 (5620), 128 (5640), 132 (5660), 136 (5680), 140 (5700)	98 (5490), 100 (5500), 102 (5510), 104 (5520), 106 (5530), 108 (5540), 110 (5550), 112 (5560), 114 (5570), 116 (5580), 118 (5590), 120 (5600), 122 (5610), 124 (5620), 126 (5630), 128 (5640), 130 (5650), 132 (5660), 134 (5670), 136 (5680), 138 (5690), 140 (5700), 142 (5710)	97 (5485), 98 (5490), 99 (5495), 100 (5500), 101 (5505), 102 (5510), 103 (5515), 104 (5520), 105 (5525), 106 (5530), 107 (5535), 108 (5540), 109 (5545), 110 (5550), 111 (5555), 112 (5560), 113 (5565), 114 (5570), 115 (5575), 116 (5580), 117 (5585), 118 (5590), 119 (5595), 120 (5600), 121 (5605), 122 (5610), 123 (5615), 124 (5620), 125 (5625), 126 (5630), 127 (5635), 128 (5640), 129 (5645), 130 (5650), 131 (5655), 132 (5660), 133 (5665), 134 (5670), 135 (5675), 136 (5680), 137 (5685), 138 (5690), 139 (5695), 140 (5700), 141 (5705), 142 (5710)
Belize (BZ)	5.725 - 5.85 GHz	No	149 (5745), 153 (5765), 157 (5785), 161 (5805), 165 (5825)	149 (5745), 151 (5755), 153 (5765), 155 (5775), 157 (5785), 159 (5795), 161 (5805), 163 (5815), 165 (5825), 167 (5835)	149 (5745), 150 (5750), 151 (5755), 152 (5760), 153 (5765), 154 (5770), 155 (5775), 156 (5780), 157 (5785), 158 (5790), 159 (5795), 160 (5800), 161 (5805), 162 (5810), 163 (5815), 164 (5820), 165 (5825), 166 (5830), 167 (5835)
Bolivia (BO)	5.725 - 5.85 GHz	No	149 (5745), 153 (5765), 157 (5785), 161 (5805), 165 (5825)	149 (5745), 151 (5755), 153 (5765), 155 (5775), 157 (5785), 159 (5795), 161 (5805), 163 (5815), 165 (5825), 167 (5835)	149 (5745), 150 (5750), 151 (5755), 152 (5760), 153 (5765), 154 (5770), 155 (5775), 156 (5780), 157 (5785), 158 (5790), 159 (5795), 160 (5800), 161 (5805), 162 (5810), 163 (5815), 164 (5820), 165 (5825), 166 (5830), 167 (5835)
Brazil (BR)	5.47 - 5.725 GHz	Yes	100 (5500), 104 (5520), 108 (5540), 112 (5560), 116 (5580), 120 (5600), 124 (5620), 128 (5640), 132 (5660), 136 (5680), 140 (5700)	98 (5490), 100 (5500), 102 (5510), 104 (5520), 106 (5530), 108 (5540), 110 (5550), 112 (5560), 114 (5570), 116 (5580), 118 (5590), 120 (5600), 122 (5610), 124 (5620), 126 (5630), 128 (5640), 130 (5650), 132 (5660), 134 (5670), 136 (5680), 138 (5690), 140 (5700), 142 (5710)	97 (5485), 98 (5490), 99 (5495), 100 (5500), 101 (5505), 102 (5510), 103 (5515), 104 (5520), 105 (5525), 106 (5530), 107 (5535), 108 (5540), 109 (5545), 110 (5550), 111 (5555), 112 (5560), 113 (5565), 114 (5570), 115 (5575), 116 (5580), 117 (5585), 118 (5590), 119 (5595), 120 (5600), 121 (5605), 122 (5610), 123 (5615), 124 (5620), 125 (5625), 126 (5630), 127 (5635), 128 (5640), 129 (5645), 130 (5650), 131 (5655), 132 (5660), 133 (5665), 134 (5670), 135 (5675), 136 (5680), 137 (5685), 138 (5690), 139 (5695), 140 (5700), 141 (5705), 142 (5710)

Country Codes and Channels

Tsunami MP.11 5012-SUI Installation and Management

Model 5012 (5.8 GHz) Channels/Frequencies by Country

Country (Code)	Frequency Bands	DFS	Allowed Channels (Center Freq)		
			20 MHz	10 MHz (N/A to the 5012)	5 MHz (N/A to the 5012)
Brazil1 (B1)	5.725 - 5.85 GHz	No	149 (5745), 153 (5765), 157 (5785), 161 (5805), 165 (5825)	149 (5745), 151 (5755), 153 (5765), 155 (5775), 157 (5785), 159 (5795), 161 (5805), 163 (5815), 165 (5825), 167 (5835)	149 (5745), 150 (5750), 151 (5755), 152 (5760), 153 (5765), 154 (5770), 155 (5775), 156 (5780), 157 (5785), 158 (5790), 159 (5795), 160 (5800), 161 (5805), 162 (5810), 163 (5815), 164 (5820), 165 (5825), 166 (5830), 167 (5835)
Brunei Darussalam (BN)	5.725 - 5.85 GHz	No	149 (5745), 153 (5765), 157 (5785), 161 (5805), 165 (5825)	149 (5745), 151 (5755), 153 (5765), 155 (5775), 157 (5785), 159 (5795), 161 (5805), 163 (5815), 165 (5825), 167 (5835)	149 (5745), 150 (5750), 151 (5755), 152 (5760), 153 (5765), 154 (5770), 155 (5775), 156 (5780), 157 (5785), 158 (5790), 159 (5795), 160 (5800), 161 (5805), 162 (5810), 163 (5815), 164 (5820), 165 (5825), 166 (5830), 167 (5835)
Bulgaria (BG)	5.47 - 5.725 GHz	Yes	100 (5500), 104 (5520), 108 (5540), 112 (5560), 116 (5580), 120 (5600), 124 (5620), 128 (5640), 132 (5660), 136 (5680), 140 (5700)	98 (5490), 100 (5500), 102 (5510), 104 (5520), 106 (5530), 108 (5540), 110 (5550), 112 (5560), 114 (5570), 116 (5580), 118 (5590), 120 (5600), 122 (5610), 124 (5620), 126 (5630), 128 (5640), 130 (5650), 132 (5660), 134 (5670), 136 (5680), 138 (5690), 140 (5700), 142 (5710)	97 (5485), 98 (5490), 99 (5495), 100 (5500), 101 (5505), 102 (5510), 103 (5515), 104 (5520), 105 (5525), 106 (5530), 107 (5535), 108 (5540), 109 (5545), 110 (5550), 111 (5555), 112 (5560), 113 (5565), 114 (5570), 115 (5575), 116 (5580), 117 (5585), 118 (5590), 119 (5595), 120 (5600), 121 (5605), 122 (5610), 123 (5615), 124 (5620), 125 (5625), 126 (5630), 127 (5635), 128 (5640), 129 (5645), 130 (5650), 131 (5655), 132 (5660), 133 (5665), 134 (5670), 135 (5675), 136 (5680), 137 (5685), 138 (5690), 139 (5695), 140 (5700), 141 (5705), 142 (5710)
Canada (CA)	5.25 - 5.35 GHz and 5.725 - 5.85 GHz	No	56 (5280), 60 (5300), 64 (5320), 149 (5745), 153 (5765), 157 (5785), 161 (5805), 165 (5825)	54 (5270), 56 (5280), 58 (5290), 60 (5300), 62 (5310), 64 (5320), 66 (5330), 147 (5735), 149 (5745), 151 (5755), 153 (5765), 155 (5775), 157 (5785), 159 (5795), 161 (5805), 163 (5815), 165 (5825), 167 (5835)	53 (5265), 54 (5270), 55 (5275), 56 (5280), 57 (5285), 58 (5290), 59 (5295), 60 (5300), 61 (5305), 62 (5310), 63 (5315), 64 (5320), 65 (5325), 66 (5330), 67 (5335), 147 (5735), 148 (5740), 149 (5745), 150 (5750), 151 (5755), 152 (5760), 153 (5765), 154 (5770), 155 (5775), 156 (5780), 157 (5785), 158 (5790), 159 (5795), 160 (5800), 161 (5805), 162 (5810), 163 (5815), 164 (5820), 165 (5825), 166 (5830), 167 (5835)
China (CN)	5.725 - 5.85 GHz	No	149 (5745), 153 (5765), 157 (5785), 161 (5805), 165 (5825)	149 (5745), 151 (5755), 153 (5765), 155 (5775), 157 (5785), 159 (5795), 161 (5805), 163 (5815), 165 (5825), 167 (5835)	149 (5745), 150 (5750), 151 (5755), 152 (5760), 153 (5765), 154 (5770), 155 (5775), 156 (5780), 157 (5785), 158 (5790), 159 (5795), 160 (5800), 161 (5805), 162 (5810), 163 (5815), 164 (5820), 165 (5825), 166 (5830), 167 (5835)

Country Codes and Channels

Tsunami MP.11 5012-SUI Installation and Management

Model 5012 (5.8 GHz) Channels/Frequencies by Country

Country (Code)	Frequency Bands	DFS	Allowed Channels (Center Freq)		
			20 MHz	10 MHz (N/A to the 5012)	5 MHz (N/A to the 5012)
Colombia (CO)	5.25 - 5.35 GHz and 5.725 - 5.85 GHz	No	56 (5280), 60 (5300), 64 (5320), 149 (5745), 153 (5765), 157 (5785), 161 (5805), 165 (5825)	54 (5270), 56 (5280), 58 (5290), 60 (5300), 62 (5310), 64 (5320), 66 (5330), 147 (5735), 149 (5745), 151 (5755), 153 (5765), 155 (5775), 157 (5785), 159 (5795), 161 (5805), 163 (5815), 165 (5825), 167 (5835)	53 (5265), 54 (5270), 55 (5275), 56 (5280), 57 (5285), 58 (5290), 59 (5295), 60 (5300), 61 (5305), 62 (5310), 63 (5315), 64 (5320), 65 (5325), 66 (5330), 67 (5335), 147 (5735), 148 (5740), 149 (5745), 150 (5750), 151 (5755), 152 (5760), 153 (5765), 154 (5770), 155 (5775), 156 (5780), 157 (5785), 158 (5790), 159 (5795), 160 (5800), 161 (5805), 162 (5810), 163 (5815), 164 (5820), 165 (5825), 166 (5830), 167 (5835)
Cyprus (CY)	5.47 - 5.725 GHz	Yes	100 (5500), 104 (5520), 108 (5540), 112 (5560), 116 (5580), 120 (5600), 124 (5620), 128 (5640), 132 (5660), 136 (5680), 140 (5700)	98 (5490), 100 (5500), 102 (5510), 104 (5520), 106 (5530), 108 (5540), 110 (5550), 112 (5560), 114 (5570), 116 (5580), 118 (5590), 120 (5600), 122 (5610), 124 (5620), 126 (5630), 128 (5640), 130 (5650), 132 (5660), 134 (5670), 136 (5680), 138 (5690), 140 (5700), 142 (5710)	97 (5485), 98 (5490), 99 (5495), 100 (5500), 101 (5505), 102 (5510), 103 (5515), 104 (5520), 105 (5525), 106 (5530), 107 (5535), 108 (5540), 109 (5545), 110 (5550), 111 (5555), 112 (5560), 113 (5565), 114 (5570), 115 (5575), 116 (5580), 117 (5585), 118 (5590), 119 (5595), 120 (5600), 121 (5605), 122 (5610), 123 (5615), 124 (5620), 125 (5625), 126 (5630), 127 (5635), 128 (5640), 129 (5645), 130 (5650), 131 (5655), 132 (5660), 133 (5665), 134 (5670), 135 (5675), 136 (5680), 137 (5685), 138 (5690), 139 (5695), 140 (5700), 141 (5705), 142 (5710)
Denmark (DK)	5.47 - 5.725 GHz	Yes	100 (5500), 104 (5520), 108 (5540), 112 (5560), 116 (5580), 120 (5600), 124 (5620), 128 (5640), 132 (5660), 136 (5680), 140 (5700)	98 (5490), 100 (5500), 102 (5510), 104 (5520), 106 (5530), 108 (5540), 110 (5550), 112 (5560), 114 (5570), 116 (5580), 118 (5590), 120 (5600), 122 (5610), 124 (5620), 126 (5630), 128 (5640), 130 (5650), 132 (5660), 134 (5670), 136 (5680), 138 (5690), 140 (5700), 142 (5710)	97 (5485), 98 (5490), 99 (5495), 100 (5500), 101 (5505), 102 (5510), 103 (5515), 104 (5520), 105 (5525), 106 (5530), 107 (5535), 108 (5540), 109 (5545), 110 (5550), 111 (5555), 112 (5560), 113 (5565), 114 (5570), 115 (5575), 116 (5580), 117 (5585), 118 (5590), 119 (5595), 120 (5600), 121 (5605), 122 (5610), 123 (5615), 124 (5620), 125 (5625), 126 (5630), 127 (5635), 128 (5640), 129 (5645), 130 (5650), 131 (5655), 132 (5660), 133 (5665), 134 (5670), 135 (5675), 136 (5680), 137 (5685), 138 (5690), 139 (5695), 140 (5700), 141 (5705), 142 (5710)

Country (Code)	Frequency Bands	DFS	Allowed Channels (Center Freq)		
			20 MHz	10 MHz (N/A to the 5012)	5 MHz (N/A to the 5012)
Dominican Republic (DO)	5.25 - 5.35 GHz and 5.725 - 5.85 GHz	No	56 (5280), 60 (5300), 64 (5320), 149 (5745), 153 (5765), 157 (5785), 161 (5805), 165 (5825)	54 (5270), 56 (5280), 58 (5290), 60 (5300), 62 (5310), 64 (5320), 66 (5330), 147 (5735), 149 (5745), 151 (5755), 153 (5765), 155 (5775), 157 (5785), 159 (5795), 161 (5805), 163 (5815), 165 (5825), 167 (5835)	53 (5265), 54 (5270), 55 (5275), 56 (5280), 57 (5285), 58 (5290), 59 (5295), 60 (5300), 61 (5305), 62 (5310), 63 (5315), 64 (5320), 65 (5325), 66 (5330), 67 (5335), 147 (5735), 148 (5740), 149 (5745), 150 (5750), 151 (5755), 152 (5760), 153 (5765), 154 (5770), 155 (5775), 156 (5780), 157 (5785), 158 (5790), 159 (5795), 160 (5800), 161 (5805), 162 (5810), 163 (5815), 164 (5820), 165 (5825), 166 (5830), 167 (5835)
Estonia (EE)	5.47 - 5.725 GHz	Yes	100 (5500), 104 (5520), 108 (5540), 112 (5560), 116 (5580), 120 (5600), 124 (5620), 128 (5640), 132 (5660), 136 (5680), 140 (5700)	98 (5490), 100 (5500), 102 (5510), 104 (5520), 106 (5530), 108 (5540), 110 (5550), 112 (5560), 114 (5570), 116 (5580), 118 (5590), 120 (5600), 122 (5610), 124 (5620), 126 (5630), 128 (5640), 130 (5650), 132 (5660), 134 (5670), 136 (5680), 138 (5690), 140 (5700), 142 (5710)	97 (5485), 98 (5490), 99 (5495), 100 (5500), 101 (5505), 102 (5510), 103 (5515), 104 (5520), 105 (5525), 106 (5530), 107 (5535), 108 (5540), 109 (5545), 110 (5550), 111 (5555), 112 (5560), 113 (5565), 114 (5570), 115 (5575), 116 (5580), 117 (5585), 118 (5590), 119 (5595), 120 (5600), 121 (5605), 122 (5610), 123 (5615), 124 (5620), 125 (5625), 126 (5630), 127 (5635), 128 (5640), 129 (5645), 130 (5650), 131 (5655), 132 (5660), 133 (5665), 134 (5670), 135 (5675), 136 (5680), 137 (5685), 138 (5690), 139 (5695), 140 (5700), 141 (5705), 142 (5710)
Finland (FI)	5.47 - 5.725 GHz	Yes	100 (5500), 104 (5520), 108 (5540), 112 (5560), 116 (5580), 120 (5600), 124 (5620), 128 (5640), 132 (5660), 136 (5680), 140 (5700)	98 (5490), 100 (5500), 102 (5510), 104 (5520), 106 (5530), 108 (5540), 110 (5550), 112 (5560), 114 (5570), 116 (5580), 118 (5590), 120 (5600), 122 (5610), 124 (5620), 126 (5630), 128 (5640), 130 (5650), 132 (5660), 134 (5670), 136 (5680), 138 (5690), 140 (5700), 142 (5710)	97 (5485), 98 (5490), 99 (5495), 100 (5500), 101 (5505), 102 (5510), 103 (5515), 104 (5520), 105 (5525), 106 (5530), 107 (5535), 108 (5540), 109 (5545), 110 (5550), 111 (5555), 112 (5560), 113 (5565), 114 (5570), 115 (5575), 116 (5580), 117 (5585), 118 (5590), 119 (5595), 120 (5600), 121 (5605), 122 (5610), 123 (5615), 124 (5620), 125 (5625), 126 (5630), 127 (5635), 128 (5640), 129 (5645), 130 (5650), 131 (5655), 132 (5660), 133 (5665), 134 (5670), 135 (5675), 136 (5680), 137 (5685), 138 (5690), 139 (5695), 140 (5700), 141 (5705), 142 (5710)

Country (Code)	Frequency Bands	DFS	Allowed Channels (Center Freq)		
			20 MHz	10 MHz (N/A to the 5012)	5 MHz (N/A to the 5012)
France (FR)	5.47 - 5.725 GHz	Yes	100 (5500), 104 (5520), 108 (5540), 112 (5560), 116 (5580), 120 (5600), 124 (5620), 128 (5640), 132 (5660), 136 (5680), 140 (5700)	98 (5490), 100 (5500), 102 (5510), 104 (5520), 106 (5530), 108 (5540), 110 (5550), 112 (5560), 114 (5570), 116 (5580), 118 (5590), 120 (5600), 122 (5610), 124 (5620), 126 (5630), 128 (5640), 130 (5650), 132 (5660), 134 (5670), 136 (5680), 138 (5690), 140 (5700), 142 (5710)	97 (5485), 98 (5490), 99 (5495), 100 (5500), 101 (5505), 102 (5510), 103 (5515), 104 (5520), 105 (5525), 106 (5530), 107 (5535), 108 (5540), 109 (5545), 110 (5550), 111 (5555), 112 (5560), 113 (5565), 114 (5570), 115 (5575), 116 (5580), 117 (5585), 118 (5590), 119 (5595), 120 (5600), 121 (5605), 122 (5610), 123 (5615), 124 (5620), 125 (5625), 126 (5630), 127 (5635), 128 (5640), 129 (5645), 130 (5650), 131 (5655), 132 (5660), 133 (5665), 134 (5670), 135 (5675), 136 (5680), 137 (5685), 138 (5690), 139 (5695), 140 (5700), 141 (5705), 142 (5710)
Germany (DE)	5.47 - 5.725 GHz	Yes	100 (5500), 104 (5520), 108 (5540), 112 (5560), 116 (5580), 120 (5600), 124 (5620), 128 (5640), 132 (5660), 136 (5680), 140 (5700)	98 (5490), 100 (5500), 102 (5510), 104 (5520), 106 (5530), 108 (5540), 110 (5550), 112 (5560), 114 (5570), 116 (5580), 118 (5590), 120 (5600), 122 (5610), 124 (5620), 126 (5630), 128 (5640), 130 (5650), 132 (5660), 134 (5670), 136 (5680), 138 (5690), 140 (5700), 142 (5710)	97 (5485), 98 (5490), 99 (5495), 100 (5500), 101 (5505), 102 (5510), 103 (5515), 104 (5520), 105 (5525), 106 (5530), 107 (5535), 108 (5540), 109 (5545), 110 (5550), 111 (5555), 112 (5560), 113 (5565), 114 (5570), 115 (5575), 116 (5580), 117 (5585), 118 (5590), 119 (5595), 120 (5600), 121 (5605), 122 (5610), 123 (5615), 124 (5620), 125 (5625), 126 (5630), 127 (5635), 128 (5640), 129 (5645), 130 (5650), 131 (5655), 132 (5660), 133 (5665), 134 (5670), 135 (5675), 136 (5680), 137 (5685), 138 (5690), 139 (5695), 140 (5700), 141 (5705), 142 (5710)
Greece (GR)	5.47 - 5.725 GHz	Yes	100 (5500), 104 (5520), 108 (5540), 112 (5560), 116 (5580), 120 (5600), 124 (5620), 128 (5640), 132 (5660), 136 (5680), 140 (5700)	98 (5490), 100 (5500), 102 (5510), 104 (5520), 106 (5530), 108 (5540), 110 (5550), 112 (5560), 114 (5570), 116 (5580), 118 (5590), 120 (5600), 122 (5610), 124 (5620), 126 (5630), 128 (5640), 130 (5650), 132 (5660), 134 (5670), 136 (5680), 138 (5690), 140 (5700), 142 (5710)	97 (5485), 98 (5490), 99 (5495), 100 (5500), 101 (5505), 102 (5510), 103 (5515), 104 (5520), 105 (5525), 106 (5530), 107 (5535), 108 (5540), 109 (5545), 110 (5550), 111 (5555), 112 (5560), 113 (5565), 114 (5570), 115 (5575), 116 (5580), 117 (5585), 118 (5590), 119 (5595), 120 (5600), 121 (5605), 122 (5610), 123 (5615), 124 (5620), 125 (5625), 126 (5630), 127 (5635), 128 (5640), 129 (5645), 130 (5650), 131 (5655), 132 (5660), 133 (5665), 134 (5670), 135 (5675), 136 (5680), 137 (5685), 138 (5690), 139 (5695), 140 (5700), 141 (5705), 142 (5710)

Country (Code)	Frequency Bands	DFS	Allowed Channels (Center Freq)		
			20 MHz	10 MHz (N/A to the 5012)	5 MHz (N/A to the 5012)
Guatemala (GT)	5.25 - 5.35 GHz and 5.725 - 5.85 GHz	No	56 (5280), 60 (5300), 64 (5320), 149 (5745), 153 (5765), 157 (5785), 161 (5805), 165 (5825)	54 (5270), 56 (5280), 58 (5290), 60 (5300), 62 (5310), 64 (5320), 66 (5330), 147 (5735), 149 (5745), 151 (5755), 153 (5765), 155 (5775), 157 (5785), 159 (5795), 161 (5805), 163 (5815), 165 (5825), 167 (5835)	53 (5265), 54 (5270), 55 (5275), 56 (5280), 57 (5285), 58 (5290), 59 (5295), 60 (5300), 61 (5305), 62 (5310), 63 (5315), 64 (5320), 65 (5325), 66 (5330), 67 (5335), 147 (5735), 148 (5740), 149 (5745), 150 (5750), 151 (5755), 152 (5760), 153 (5765), 154 (5770), 155 (5775), 156 (5780), 157 (5785), 158 (5790), 159 (5795), 160 (5800), 161 (5805), 162 (5810), 163 (5815), 164 (5820), 165 (5825), 166 (5830), 167 (5835)
Hong Kong (HK)	5.725 - 5.85 GHz	No	149 (5745), 153 (5765), 157 (5785), 161 (5805), 165 (5825)	147 (5735), 149 (5745), 151 (5755), 153 (5765), 155 (5775), 157 (5785), 159 (5795), 161 (5805), 163 (5815), 165 (5825), 167 (5835)	147 (5735), 148 (5740), 149 (5745), 150 (5750), 151 (5755), 152 (5760), 153 (5765), 154 (5770), 155 (5775), 156 (5780), 157 (5785), 158 (5790), 159 (5795), 160 (5800), 161 (5805), 162 (5810), 163 (5815), 164 (5820), 165 (5825), 166 (5830), 167 (5835)
Hungary (HU)	5.47 - 5.725 GHz	Yes	100 (5500), 104 (5520), 108 (5540), 112 (5560), 116 (5580), 120 (5600), 124 (5620), 128 (5640), 132 (5660), 136 (5680), 140 (5700)	98 (5490), 100 (5500), 102 (5510), 104 (5520), 106 (5530), 108 (5540), 110 (5550), 112 (5560), 114 (5570), 116 (5580), 118 (5590), 120 (5600), 122 (5610), 124 (5620), 126 (5630), 128 (5640), 130 (5650), 132 (5660), 134 (5670), 136 (5680), 138 (5690), 140 (5700), 142 (5710)	97 (5485), 98 (5490), 99 (5495), 100 (5500), 101 (5505), 102 (5510), 103 (5515), 104 (5520), 105 (5525), 106 (5530), 107 (5535), 108 (5540), 109 (5545), 110 (5550), 111 (5555), 112 (5560), 113 (5565), 114 (5570), 115 (5575), 116 (5580), 117 (5585), 118 (5590), 119 (5595), 120 (5600), 121 (5605), 122 (5610), 123 (5615), 124 (5620), 125 (5625), 126 (5630), 127 (5635), 128 (5640), 129 (5645), 130 (5650), 131 (5655), 132 (5660), 133 (5665), 134 (5670), 135 (5675), 136 (5680), 137 (5685), 138 (5690), 139 (5695), 140 (5700), 141 (5705), 142 (5710)
Iceland (IS)	5.47 - 5.725 GHz	Yes	100 (5500), 104 (5520), 108 (5540), 112 (5560), 116 (5580), 120 (5600), 124 (5620), 128 (5640), 132 (5660), 136 (5680), 140 (5700)	98 (5490), 100 (5500), 102 (5510), 104 (5520), 106 (5530), 108 (5540), 110 (5550), 112 (5560), 114 (5570), 116 (5580), 118 (5590), 120 (5600), 122 (5610), 124 (5620), 126 (5630), 128 (5640), 130 (5650), 132 (5660), 134 (5670), 136 (5680), 138 (5690), 140 (5700), 142 (5710)	97 (5485), 98 (5490), 99 (5495), 100 (5500), 101 (5505), 102 (5510), 103 (5515), 104 (5520), 105 (5525), 106 (5530), 107 (5535), 108 (5540), 109 (5545), 110 (5550), 111 (5555), 112 (5560), 113 (5565), 114 (5570), 115 (5575), 116 (5580), 117 (5585), 118 (5590), 119 (5595), 120 (5600), 121 (5605), 122 (5610), 123 (5615), 124 (5620), 125 (5625), 126 (5630), 127 (5635), 128 (5640), 129 (5645), 130 (5650), 131 (5655), 132 (5660), 133 (5665), 134 (5670), 135 (5675), 136 (5680), 137 (5685), 138 (5690), 139 (5695), 140 (5700), 141 (5705), 142 (5710)

Country (Code)	Frequency Bands	DFS	Allowed Channels (Center Freq)		
			20 MHz	10 MHz (N/A to the 5012)	5 MHz (N/A to the 5012)
India (IN)	5.15 - 5.35 GHz and 5.725 - 5.825 GHz	No	36 (5180), 40 (5200), 44 (5220), 48 (5240), 52 (5260), 56 (5280), 60 (5300), 64 (5320), 149 (5745), 153 (5765), 157 (5785), 161 (5805)	36 (5180), 38 (5190), 40 (5200), 42 (5210), 44 (5220), 46 (5230), 48 (5240), 50 (5250), 52 (5260), 54 (5270), 56 (5280), 58 (5290), 60 (5300), 62 (5310), 64 (5320), 66 (5330), 147 (5735), 149 (5745), 151 (5755), 153 (5765), 155 (5775), 157 (5785), 159 (5795), 161 (5805), 163 (5815)	36 (5180), 37 (5185), 38 (5190), 39 (5195), 40 (5200), 41 (5205), 42 (5210), 43 (5215), 44 (5220), 45 (5225), 46 (5230), 47 (5235), 48 (5240), 49 (5245), 50 (5250), 51 (5255), 52 (5260), 53 (5265), 54 (5270), 55 (5275), 56 (5280), 57 (5285), 58 (5290), 59 (5295), 60 (5300), 61 (5305), 62 (5310), 63 (5315), 64 (5320), 65 (5325), 66 (5330), 67 (5335), 147 (5735), 148 (5740), 149 (5745), 150 (5750), 151 (5755), 152 (5760), 153 (5765), 154 (5770), 155 (5775), 156 (5780), 157 (5785), 158 (5790), 159 (5795), 160 (5800), 161 (5805), 162 (5810), 163 (5815)
Iran (IR)	5.725 - 5.85 GHz	No	149 (5745), 153 (5765), 157 (5785), 161 (5805), 165 (5825)	149 (5745), 151 (5755), 153 (5765), 155 (5775), 157 (5785), 159 (5795), 161 (5805), 163 (5815), 165 (5825), 167 (5835)	149 (5745), 150 (5750), 151 (5755), 152 (5760), 153 (5765), 154 (5770), 155 (5775), 156 (5780), 157 (5785), 158 (5790), 159 (5795), 160 (5800), 161 (5805), 162 (5810), 163 (5815), 164 (5820), 165 (5825), 166 (5830), 167 (5835)
Ireland (IE)	5.47 - 5.725 GHz	Yes	100 (5500), 104 (5520), 108 (5540), 112 (5560), 116 (5580), 120 (5600), 124 (5620), 128 (5640), 132 (5660), 136 (5680), 140 (5700)	98 (5490), 100 (5500), 102 (5510), 104 (5520), 106 (5530), 108 (5540), 110 (5550), 112 (5560), 114 (5570), 116 (5580), 118 (5590), 120 (5600), 122 (5610), 124 (5620), 126 (5630), 128 (5640), 130 (5650), 132 (5660), 134 (5670), 136 (5680), 138 (5690), 140 (5700), 142 (5710)	97 (5485), 98 (5490), 99 (5495), 100 (5500), 101 (5505), 102 (5510), 103 (5515), 104 (5520), 105 (5525), 106 (5530), 107 (5535), 108 (5540), 109 (5545), 110 (5550), 111 (5555), 112 (5560), 113 (5565), 114 (5570), 115 (5575), 116 (5580), 117 (5585), 118 (5590), 119 (5595), 120 (5600), 121 (5605), 122 (5610), 123 (5615), 124 (5620), 125 (5625), 126 (5630), 127 (5635), 128 (5640), 129 (5645), 130 (5650), 131 (5655), 132 (5660), 133 (5665), 134 (5670), 135 (5675), 136 (5680), 137 (5685), 138 (5690), 139 (5695), 140 (5700), 141 (5705), 142 (5710)
Ireland 5.8 GHz (I1)	5.725 - 5.85 GHz	Yes	147 (5735), 151 (5755), 155 (5775), 167 (5835)	145 (5725), 147 (5735), 149 (5745), 151 (5755), 153 (5765), 155 (5775), 157 (5785), 163 (5815), 165 (5825), 167 (5835), 169 (5845)	145 (5725), 146 (5730), 147 (5735), 148 (5740), 149 (5745), 150 (5750), 151 (5755), 152 (5760), 153 (5765), 154 (5770), 155 (5775), 156 (5780), 157 (5785), 158 (5790), 159 (5795), 163 (5815), 164 (5820), 165 (5825), 166 (5830), 167 (5835), 168 (5840), 169 (5845), 170 (5850)

Country (Code)	Frequency Bands	DFS	Allowed Channels (Center Freq)		
			20 MHz	10 MHz (N/A to the 5012)	5 MHz (N/A to the 5012)
Italy (IT)	5.47 - 5.725 GHz	Yes	100 (5500), 104 (5520), 108 (5540), 112 (5560), 116 (5580), 120 (5600), 124 (5620), 128 (5640), 132 (5660), 136 (5680), 140 (5700)	98 (5490), 100 (5500), 102 (5510), 104 (5520), 106 (5530), 108 (5540), 110 (5550), 112 (5560), 114 (5570), 116 (5580), 118 (5590), 120 (5600), 122 (5610), 124 (5620), 126 (5630), 128 (5640), 130 (5650), 132 (5660), 134 (5670), 136 (5680), 138 (5690), 140 (5700), 142 (5710)	97 (5485), 98 (5490), 99 (5495), 100 (5500), 101 (5505), 102 (5510), 103 (5515), 104 (5520), 105 (5525), 106 (5530), 107 (5535), 108 (5540), 109 (5545), 110 (5550), 111 (5555), 112 (5560), 113 (5565), 114 (5570), 115 (5575), 116 (5580), 117 (5585), 118 (5590), 119 (5595), 120 (5600), 121 (5605), 122 (5610), 123 (5615), 124 (5620), 125 (5625), 126 (5630), 127 (5635), 128 (5640), 129 (5645), 130 (5650), 131 (5655), 132 (5660), 133 (5665), 134 (5670), 135 (5675), 136 (5680), 137 (5685), 138 (5690), 139 (5695), 140 (5700), 141 (5705), 142 (5710)
Japan (JP)	5.25 - 5.35 GHz	Yes	56 (5280), 60 (5300), 64 (5320)	54 (5270), 56 (5280), 58 (5290), 60 (5300), 62 (5310), 64 (5320), 66 (5330)	53 (5265), 54 (5270), 55 (5275), 56 (5280), 57 (5285), 58 (5290), 59 (5295), 60 (5300), 61 (5305), 62 (5310), 63 (5315), 64 (5320), 65 (5325), 66 (5330), 67 (5335)
Japan1 (JP1)	5.15 - 5.25 GHz	No	36 (5180), 40 (5200), 44 (5220), 48 (5240)	36 (5180), 38 (5190), 40 (5200), 42 (5210), 44 (5220), 46 (5230), 48 (5240)	36 (5180), 37 (5185), 38 (5190), 39 (5195), 40 (5200), 41 (5205), 42 (5210), 43 (5215), 44 (5220), 45 (5225), 46 (5230), 47 (5235), 48 (5240)
Japan2 (J2)	5.15 - 5.25 GHz	No	36 (5180), 40 (5200), 44 (5220), 48 (5240)	36 (5180), 38 (5190), 40 (5200), 42 (5210), 44 (5220), 46 (5230), 48 (5240)	36 (5180), 37 (5185), 38 (5190), 39 (5195), 40 (5200), 41 (5205), 42 (5210), 43 (5215), 44 (5220), 45 (5225), 46 (5230), 47 (5235), 48 (5240)
Japan3 (JP3)	5.15 - 5.25 GHz and 4.9 GHz	No	8 (5040), 12 (5060), 16 (5080), 34 (5170), 38 (5190), 42 (5210), 46 (5230), 184 (4920), 188 (4940), 192 (4960), 196 (4980)	6 (5030), 8 (5040), 10 (5050), 12 (5060), 14 (5070), 16 (5080), 32 (5160), 34 (5170), 36 (5180), 38 (5190), 40 (5200), 42 (5210), 44 (5220), 46 (5230), 182 (4910), 184 (4920), 186 (4930), 188 (4940), 190 (4950), 192 (4960), 194 (4970), 196 (4980)	6 (5030), 7 (5035), 8 (5040), 9 (5045), 10 (5050), 11 (5055), 12 (5060), 13 (5065), 14 (5070), 15 (5075), 16 (5080), 32 (5160), 33 (5165), 34 (5170), 35 (5175), 36 (5180), 37 (5185), 38 (5190), 39 (5195), 40 (5200), 41 (5205), 42 (5210), 43 (5215), 44 (5220), 45 (5225), 46 (5230), 181 (4905), 182 (4910), 183 (4915), 184 (4920), 185 (4925), 186 (4930), 187 (4935), 188 (4940), 189 (4945), 190 (4950), 191 (4955), 192 (4960), 193 (4965), 194 (4970), 195 (4975), 196 (4980)
Japan4 (JP4)	5.25 - 5.35 GHz	Yes	56 (5280), 60 (5300), 64 (5320)	54 (5270), 56 (5280), 58 (5290), 60 (5300), 62 (5310), 64 (5320), 66 (5330)	53 (5265), 54 (5270), 55 (5275), 56 (5280), 57 (5285), 58 (5290), 59 (5295), 60 (5300), 61 (5305), 62 (5310), 63 (5315), 64 (5320), 65 (5325), 66 (5330), 67 (5335)
Japan5 (JP5)	5.25 - 5.35 GHz	Yes	56 (5280), 60 (5300), 64 (5320)	54 (5270), 56 (5280), 58 (5290), 60 (5300), 62 (5310), 64 (5320), 66 (5330)	53 (5265), 54 (5270), 55 (5275), 56 (5280), 57 (5285), 58 (5290), 59 (5295), 60 (5300), 61 (5305), 62 (5310), 63 (5315), 64 (5320), 65 (5325), 66 (5330), 67 (5335)

Country Codes and Channels

Tsunami MP.11 5012-SUI Installation and Management

Model 5012 (5.8 GHz) Channels/Frequencies by Country

Country (Code)	Frequency Bands	DFS	Allowed Channels (Center Freq)		
			20 MHz	10 MHz (N/A to the 5012)	5 MHz (N/A to the 5012)
Korea Republic (KR)	5.725 - 5.825 GHz	No	149 (5745), 153 (5765), 157 (5785), 161 (5805)	147 (5735), 149 (5745), 151 (5755), 153 (5765), 155 (5775), 157 (5785), 159 (5795), 161 (5805), 163 (5815)	147 (5735), 148 (5740), 149 (5745), 150 (5750), 151 (5755), 152 (5760), 153 (5765), 154 (5770), 155 (5775), 156 (5780), 157 (5785), 158 (5790), 159 (5795), 160 (5800), 161 (5805), 162 (5810), 163 (5815)
Korea Republic2 (KR2)	5.725 - 5.825 GHz	No	149 (5745), 153 (5765), 157 (5785), 161 (5805)	147 (5735), 149 (5745), 151 (5755), 153 (5765), 155 (5775), 157 (5785), 159 (5795), 161 (5805), 163 (5815)	147 (5735), 148 (5740), 149 (5745), 150 (5750), 151 (5755), 152 (5760), 153 (5765), 154 (5770), 155 (5775), 156 (5780), 157 (5785), 158 (5790), 159 (5795), 160 (5800), 161 (5805), 162 (5810), 163 (5815)
Latvia (LV)	5.47 - 5.725 GHz	Yes	100 (5500), 104 (5520), 108 (5540), 112 (5560), 116 (5580), 120 (5600), 124 (5620), 128 (5640), 132 (5660), 136 (5680), 140 (5700)	98 (5490), 100 (5500), 102 (5510), 104 (5520), 106 (5530), 108 (5540), 110 (5550), 112 (5560), 114 (5570), 116 (5580), 118 (5590), 120 (5600), 122 (5610), 124 (5620), 126 (5630), 128 (5640), 130 (5650), 132 (5660), 134 (5670), 136 (5680), 138 (5690), 140 (5700), 142 (5710)	97 (5485), 98 (5490), 99 (5495), 100 (5500), 101 (5505), 102 (5510), 103 (5515), 104 (5520), 105 (5525), 106 (5530), 107 (5535), 108 (5540), 109 (5545), 110 (5550), 111 (5555), 112 (5560), 113 (5565), 114 (5570), 115 (5575), 116 (5580), 117 (5585), 118 (5590), 119 (5595), 120 (5600), 121 (5605), 122 (5610), 123 (5615), 124 (5620), 125 (5625), 126 (5630), 127 (5635), 128 (5640), 129 (5645), 130 (5650), 131 (5655), 132 (5660), 133 (5665), 134 (5670), 135 (5675), 136 (5680), 137 (5685), 138 (5690), 139 (5695), 140 (5700), 141 (5705), 142 (5710)
Liechtenstein (LI)	5.47 - 5.725 GHz	Yes	100 (5500), 104 (5520), 108 (5540), 112 (5560), 116 (5580), 120 (5600), 124 (5620), 128 (5640), 132 (5660), 136 (5680), 140 (5700)	98 (5490), 100 (5500), 102 (5510), 104 (5520), 106 (5530), 108 (5540), 110 (5550), 112 (5560), 114 (5570), 116 (5580), 118 (5590), 120 (5600), 122 (5610), 124 (5620), 126 (5630), 128 (5640), 130 (5650), 132 (5660), 134 (5670), 136 (5680), 138 (5690), 140 (5700), 142 (5710)	97 (5485), 98 (5490), 99 (5495), 100 (5500), 101 (5505), 102 (5510), 103 (5515), 104 (5520), 105 (5525), 106 (5530), 107 (5535), 108 (5540), 109 (5545), 110 (5550), 111 (5555), 112 (5560), 113 (5565), 114 (5570), 115 (5575), 116 (5580), 117 (5585), 118 (5590), 119 (5595), 120 (5600), 121 (5605), 122 (5610), 123 (5615), 124 (5620), 125 (5625), 126 (5630), 127 (5635), 128 (5640), 129 (5645), 130 (5650), 131 (5655), 132 (5660), 133 (5665), 134 (5670), 135 (5675), 136 (5680), 137 (5685), 138 (5690), 139 (5695), 140 (5700), 141 (5705), 142 (5710)

Country (Code)	Frequency Bands	DFS	Allowed Channels (Center Freq)		
			20 MHz	10 MHz (N/A to the 5012)	5 MHz (N/A to the 5012)
Lithuania (LT)	5.47 - 5.725 GHz	Yes	100 (5500), 104 (5520), 108 (5540), 112 (5560), 116 (5580), 120 (5600), 124 (5620), 128 (5640), 132 (5660), 136 (5680), 140 (5700)	98 (5490), 100 (5500), 102 (5510), 104 (5520), 106 (5530), 108 (5540), 110 (5550), 112 (5560), 114 (5570), 116 (5580), 118 (5590), 120 (5600), 122 (5610), 124 (5620), 126 (5630), 128 (5640), 130 (5650), 132 (5660), 134 (5670), 136 (5680), 138 (5690), 140 (5700), 142 (5710)	97 (5485), 98 (5490), 99 (5495), 100 (5500), 101 (5505), 102 (5510), 103 (5515), 104 (5520), 105 (5525), 106 (5530), 107 (5535), 108 (5540), 109 (5545), 110 (5550), 111 (5555), 112 (5560), 113 (5565), 114 (5570), 115 (5575), 116 (5580), 117 (5585), 118 (5590), 119 (5595), 120 (5600), 121 (5605), 122 (5610), 123 (5615), 124 (5620), 125 (5625), 126 (5630), 127 (5635), 128 (5640), 129 (5645), 130 (5650), 131 (5655), 132 (5660), 133 (5665), 134 (5670), 135 (5675), 136 (5680), 137 (5685), 138 (5690), 139 (5695), 140 (5700), 141 (5705), 142 (5710)
Luxembourg (LU)	5.47 - 5.725 GHz	Yes	100 (5500), 104 (5520), 108 (5540), 112 (5560), 116 (5580), 120 (5600), 124 (5620), 128 (5640), 132 (5660), 136 (5680), 140 (5700)	98 (5490), 100 (5500), 102 (5510), 104 (5520), 106 (5530), 108 (5540), 110 (5550), 112 (5560), 114 (5570), 116 (5580), 118 (5590), 120 (5600), 122 (5610), 124 (5620), 126 (5630), 128 (5640), 130 (5650), 132 (5660), 134 (5670), 136 (5680), 138 (5690), 140 (5700), 142 (5710)	97 (5485), 98 (5490), 99 (5495), 100 (5500), 101 (5505), 102 (5510), 103 (5515), 104 (5520), 105 (5525), 106 (5530), 107 (5535), 108 (5540), 109 (5545), 110 (5550), 111 (5555), 112 (5560), 113 (5565), 114 (5570), 115 (5575), 116 (5580), 117 (5585), 118 (5590), 119 (5595), 120 (5600), 121 (5605), 122 (5610), 123 (5615), 124 (5620), 125 (5625), 126 (5630), 127 (5635), 128 (5640), 129 (5645), 130 (5650), 131 (5655), 132 (5660), 133 (5665), 134 (5670), 135 (5675), 136 (5680), 137 (5685), 138 (5690), 139 (5695), 140 (5700), 141 (5705), 142 (5710)
Macau (MO)	5.725 - 5.85 GHz	No	149 (5745), 153 (5765), 157 (5785), 161 (5805), 165 (5825)	147 (5735), 149 (5745), 151 (5755), 153 (5765), 155 (5775), 157 (5785), 159 (5795), 161 (5805), 163 (5815), 165 (5825), 167 (5835)	147 (5735), 148 (5740), 149 (5745), 150 (5750), 151 (5755), 152 (5760), 153 (5765), 154 (5770), 155 (5775), 156 (5780), 157 (5785), 158 (5790), 159 (5795), 160 (5800), 161 (5805), 162 (5810), 163 (5815), 164 (5820), 165 (5825), 166 (5830), 167 (5835)
Malaysia (MY)	5.25 - 5.35 GHz and 5.725 - 5.85 GHz	No	56 (5280), 60 (5300), 64 (5320), 149 (5745), 153 (5765), 157 (5785), 161 (5805), 165 (5825)	54 (5270), 56 (5280), 58 (5290), 60 (5300), 62 (5310), 64 (5320), 66 (5330), 147 (5735), 149 (5745), 151 (5755), 153 (5765), 155 (5775), 157 (5785), 159 (5795), 161 (5805), 163 (5815), 165 (5825), 167 (5835)	53 (5265), 54 (5270), 55 (5275), 56 (5280), 57 (5285), 58 (5290), 59 (5295), 60 (5300), 61 (5305), 62 (5310), 63 (5315), 64 (5320), 65 (5325), 66 (5330), 67 (5335), 147 (5735), 148 (5740), 149 (5745), 150 (5750), 151 (5755), 152 (5760), 153 (5765), 154 (5770), 155 (5775), 156 (5780), 157 (5785), 158 (5790), 159 (5795), 160 (5800), 161 (5805), 162 (5810), 163 (5815), 164 (5820), 165 (5825), 166 (5830), 167 (5835)

Country Codes and Channels

Tsunami MP.11 5012-SUI Installation and Management

Model 5012 (5.8 GHz) Channels/Frequencies by Country

Country (Code)	Frequency Bands	DFS	Allowed Channels (Center Freq)		
			20 MHz	10 MHz (N/A to the 5012)	5 MHz (N/A to the 5012)
Malta (MT)	5.47 - 5.725 GHz	Yes	100 (5500), 104 (5520), 108 (5540), 112 (5560), 116 (5580), 120 (5600), 124 (5620), 128 (5640), 132 (5660), 136 (5680), 140 (5700)	98 (5490), 100 (5500), 102 (5510), 104 (5520), 106 (5530), 108 (5540), 110 (5550), 112 (5560), 114 (5570), 116 (5580), 118 (5590), 120 (5600), 122 (5610), 124 (5620), 126 (5630), 128 (5640), 130 (5650), 132 (5660), 134 (5670), 136 (5680), 138 (5690), 140 (5700), 142 (5710)	97 (5485), 98 (5490), 99 (5495), 100 (5500), 101 (5505), 102 (5510), 103 (5515), 104 (5520), 105 (5525), 106 (5530), 107 (5535), 108 (5540), 109 (5545), 110 (5550), 111 (5555), 112 (5560), 113 (5565), 114 (5570), 115 (5575), 116 (5580), 117 (5585), 118 (5590), 119 (5595), 120 (5600), 121 (5605), 122 (5610), 123 (5615), 124 (5620), 125 (5625), 126 (5630), 127 (5635), 128 (5640), 129 (5645), 130 (5650), 131 (5655), 132 (5660), 133 (5665), 134 (5670), 135 (5675), 136 (5680), 137 (5685), 138 (5690), 139 (5695), 140 (5700), 141 (5705), 142 (5710)
Mexico (MX)	5.725 - 5.85 GHz	No	149 (5745), 153 (5765), 157 (5785), 161 (5805), 165 (5825)	147 (5735), 149 (5745), 151 (5755), 153 (5765), 155 (5775), 157 (5785), 159 (5795), 161 (5805), 163 (5815), 165 (5825), 167 (5835)	147 (5735), 148 (5740), 149 (5745), 150 (5750), 151 (5755), 152 (5760), 153 (5765), 154 (5770), 155 (5775), 156 (5780), 157 (5785), 158 (5790), 159 (5795), 160 (5800), 161 (5805), 162 (5810), 163 (5815), 164 (5820), 165 (5825), 166 (5830), 167 (5835)
Netherlands (NL)	5.47 - 5.725 GHz	Yes	100 (5500), 104 (5520), 108 (5540), 112 (5560), 116 (5580), 120 (5600), 124 (5620), 128 (5640), 132 (5660), 136 (5680), 140 (5700)	98 (5490), 100 (5500), 102 (5510), 104 (5520), 106 (5530), 108 (5540), 110 (5550), 112 (5560), 114 (5570), 116 (5580), 118 (5590), 120 (5600), 122 (5610), 124 (5620), 126 (5630), 128 (5640), 130 (5650), 132 (5660), 134 (5670), 136 (5680), 138 (5690), 140 (5700), 142 (5710)	97 (5485), 98 (5490), 99 (5495), 100 (5500), 101 (5505), 102 (5510), 103 (5515), 104 (5520), 105 (5525), 106 (5530), 107 (5535), 108 (5540), 109 (5545), 110 (5550), 111 (5555), 112 (5560), 113 (5565), 114 (5570), 115 (5575), 116 (5580), 117 (5585), 118 (5590), 119 (5595), 120 (5600), 121 (5605), 122 (5610), 123 (5615), 124 (5620), 125 (5625), 126 (5630), 127 (5635), 128 (5640), 129 (5645), 130 (5650), 131 (5655), 132 (5660), 133 (5665), 134 (5670), 135 (5675), 136 (5680), 137 (5685), 138 (5690), 139 (5695), 140 (5700), 141 (5705), 142 (5710)
New Zealand (NZ)	5.725 - 5.85 GHz	No	149 (5745), 153 (5765), 157 (5785), 161 (5805), 165 (5825)	147 (5735), 149 (5745), 151 (5755), 153 (5765), 155 (5775), 157 (5785), 159 (5795), 161 (5805), 163 (5815), 165 (5825), 167 (5835)	147 (5735), 148 (5740), 149 (5745), 150 (5750), 151 (5755), 152 (5760), 153 (5765), 154 (5770), 155 (5775), 156 (5780), 157 (5785), 158 (5790), 159 (5795), 160 (5800), 161 (5805), 162 (5810), 163 (5815), 164 (5820), 165 (5825), 166 (5830), 167 (5835)
North Korea (KP)	5.725 - 5.825 GHz	No	149 (5745), 153 (5765), 157 (5785), 161 (5805)	147 (5735), 149 (5745), 151 (5755), 153 (5765), 155 (5775), 157 (5785), 159 (5795), 161 (5805), 163 (5815)	147 (5735), 148 (5740), 149 (5745), 150 (5750), 151 (5755), 152 (5760), 153 (5765), 154 (5770), 155 (5775), 156 (5780), 157 (5785), 158 (5790), 159 (5795), 160 (5800), 161 (5805), 162 (5810), 163 (5815)

Country (Code)	Frequency Bands	DFS	Allowed Channels (Center Freq)		
			20 MHz	10 MHz (N/A to the 5012)	5 MHz (N/A to the 5012)
Norway (NO)	5.47 - 5.725 GHz	Yes	100 (5500), 104 (5520), 108 (5540), 112 (5560), 116 (5580), 120 (5600), 124 (5620), 128 (5640), 132 (5660), 136 (5680), 140 (5700)	98 (5490), 100 (5500), 102 (5510), 104 (5520), 106 (5530), 108 (5540), 110 (5550), 112 (5560), 114 (5570), 116 (5580), 118 (5590), 120 (5600), 122 (5610), 124 (5620), 126 (5630), 128 (5640), 130 (5650), 132 (5660), 134 (5670), 136 (5680), 138 (5690), 140 (5700), 142 (5710)	97 (5485), 98 (5490), 99 (5495), 100 (5500), 101 (5505), 102 (5510), 103 (5515), 104 (5520), 105 (5525), 106 (5530), 107 (5535), 108 (5540), 109 (5545), 110 (5550), 111 (5555), 112 (5560), 113 (5565), 114 (5570), 115 (5575), 116 (5580), 117 (5585), 118 (5590), 119 (5595), 120 (5600), 121 (5605), 122 (5610), 123 (5615), 124 (5620), 125 (5625), 126 (5630), 127 (5635), 128 (5640), 129 (5645), 130 (5650), 131 (5655), 132 (5660), 133 (5665), 134 (5670), 135 (5675), 136 (5680), 137 (5685), 138 (5690), 139 (5695), 140 (5700), 141 (5705), 142 (5710)
Panama (PA)	5.25 - 5.35 GHz and 5.725 - 5.85 GHz	No	56 (5280), 60 (5300), 64 (5320), 149 (5745), 153 (5765), 157 (5785), 161 (5805), 165 (5825)	54 (5270), 56 (5280), 58 (5290), 60 (5300), 62 (5310), 64 (5320), 66 (5330), 147 (5735), 149 (5745), 151 (5755), 153 (5765), 155 (5775), 157 (5785), 159 (5795), 161 (5805), 163 (5815), 165 (5825), 167 (5835)	53 (5265), 54 (5270), 55 (5275), 56 (5280), 57 (5285), 58 (5290), 59 (5295), 60 (5300), 61 (5305), 62 (5310), 63 (5315), 64 (5320), 65 (5325), 66 (5330), 67 (5335), 147 (5735), 148 (5740), 149 (5745), 150 (5750), 151 (5755), 152 (5760), 153 (5765), 154 (5770), 155 (5775), 156 (5780), 157 (5785), 158 (5790), 159 (5795), 160 (5800), 161 (5805), 162 (5810), 163 (5815), 164 (5820), 165 (5825), 166 (5830), 167 (5835)
Philippines (PH)	5.25 - 5.35 GHz and 5.725 - 5.85 GHz	No	56 (5280), 60 (5300), 64 (5320), 149 (5745), 153 (5765), 157 (5785), 161 (5805), 165 (5825)	54 (5270), 56 (5280), 58 (5290), 60 (5300), 62 (5310), 64 (5320), 66 (5330), 147 (5735), 149 (5745), 151 (5755), 153 (5765), 155 (5775), 157 (5785), 159 (5795), 161 (5805), 163 (5815), 165 (5825), 167 (5835)	53 (5265), 54 (5270), 55 (5275), 56 (5280), 57 (5285), 58 (5290), 59 (5295), 60 (5300), 61 (5305), 62 (5310), 63 (5315), 64 (5320), 65 (5325), 66 (5330), 67 (5335), 147 (5735), 148 (5740), 149 (5745), 150 (5750), 151 (5755), 152 (5760), 153 (5765), 154 (5770), 155 (5775), 156 (5780), 157 (5785), 158 (5790), 159 (5795), 160 (5800), 161 (5805), 162 (5810), 163 (5815), 164 (5820), 165 (5825), 166 (5830), 167 (5835)

Country (Code)	Frequency Bands	DFS	Allowed Channels (Center Freq)		
			20 MHz	10 MHz (N/A to the 5012)	5 MHz (N/A to the 5012)
Poland (PL)	5.47 - 5.725 GHz	Yes	100 (5500), 104 (5520), 108 (5540), 112 (5560), 116 (5580), 120 (5600), 124 (5620), 128 (5640), 132 (5660), 136 (5680), 140 (5700)	98 (5490), 100 (5500), 102 (5510), 104 (5520), 106 (5530), 108 (5540), 110 (5550), 112 (5560), 114 (5570), 116 (5580), 118 (5590), 120 (5600), 122 (5610), 124 (5620), 126 (5630), 128 (5640), 130 (5650), 132 (5660), 134 (5670), 136 (5680), 138 (5690), 140 (5700), 142 (5710)	97 (5485), 98 (5490), 99 (5495), 100 (5500), 101 (5505), 102 (5510), 103 (5515), 104 (5520), 105 (5525), 106 (5530), 107 (5535), 108 (5540), 109 (5545), 110 (5550), 111 (5555), 112 (5560), 113 (5565), 114 (5570), 115 (5575), 116 (5580), 117 (5585), 118 (5590), 119 (5595), 120 (5600), 121 (5605), 122 (5610), 123 (5615), 124 (5620), 125 (5625), 126 (5630), 127 (5635), 128 (5640), 129 (5645), 130 (5650), 131 (5655), 132 (5660), 133 (5665), 134 (5670), 135 (5675), 136 (5680), 137 (5685), 138 (5690), 139 (5695), 140 (5700), 141 (5705), 142 (5710)
Portugal (PT)	5.47 - 5.725 GHz	Yes	100 (5500), 104 (5520), 108 (5540), 112 (5560), 116 (5580), 120 (5600), 124 (5620), 128 (5640), 132 (5660), 136 (5680), 140 (5700)	98 (5490), 100 (5500), 102 (5510), 104 (5520), 106 (5530), 108 (5540), 110 (5550), 112 (5560), 114 (5570), 116 (5580), 118 (5590), 120 (5600), 122 (5610), 124 (5620), 126 (5630), 128 (5640), 130 (5650), 132 (5660), 134 (5670), 136 (5680), 138 (5690), 140 (5700), 142 (5710)	97 (5485), 98 (5490), 99 (5495), 100 (5500), 101 (5505), 102 (5510), 103 (5515), 104 (5520), 105 (5525), 106 (5530), 107 (5535), 108 (5540), 109 (5545), 110 (5550), 111 (5555), 112 (5560), 113 (5565), 114 (5570), 115 (5575), 116 (5580), 117 (5585), 118 (5590), 119 (5595), 120 (5600), 121 (5605), 122 (5610), 123 (5615), 124 (5620), 125 (5625), 126 (5630), 127 (5635), 128 (5640), 129 (5645), 130 (5650), 131 (5655), 132 (5660), 133 (5665), 134 (5670), 135 (5675), 136 (5680), 137 (5685), 138 (5690), 139 (5695), 140 (5700), 141 (5705), 142 (5710)
Puerto Rico (PR)	5.25 - 5.35 GHz and 5.725 - 5.85 GHz	No	56 (5280), 60 (5300), 64 (5320), 149 (5745), 153 (5765), 157 (5785), 161 (5805), 165 (5825)	54 (5270), 56 (5280), 58 (5290), 60 (5300), 62 (5310), 64 (5320), 66 (5330), 147 (5735), 149 (5745), 151 (5755), 153 (5765), 155 (5775), 157 (5785), 159 (5795), 161 (5805), 163 (5815), 165 (5825), 167 (5835)	53 (5265), 54 (5270), 55 (5275), 56 (5280), 57 (5285), 58 (5290), 59 (5295), 60 (5300), 61 (5305), 62 (5310), 63 (5315), 64 (5320), 65 (5325), 66 (5330), 67 (5335), 147 (5735), 148 (5740), 149 (5745), 150 (5750), 151 (5755), 152 (5760), 153 (5765), 154 (5770), 155 (5775), 156 (5780), 157 (5785), 158 (5790), 159 (5795), 160 (5800), 161 (5805), 162 (5810), 163 (5815), 164 (5820), 165 (5825), 166 (5830), 167 (5835)

Country (Code)	Frequency Bands	DFS	Allowed Channels (Center Freq)		
			20 MHz	10 MHz (N/A to the 5012)	5 MHz (N/A to the 5012)
Russia (RU)	5.15 - 5.85 GHz	No	30 (5150), 34 (5170), 38 (5190), 42 (5210), 46 (5230), 50 (5250), 54 (5270), 58 (5290), 62 (5310), 66 (5330), 70 (5350), 74 (5370), 78 (5390), 82 (5410), 86 (5430), 90 (5450), 94 (5470), 98 (5490), 102 (5510), 106 (5530), 110 (5550), 114 (5570), 118 (5590), 122 (5610), 126 (5630), 130 (5650), 134 (5670), 138 (5690), 142 (5710), 146 (5730), 150 (5750), 154 (5770), 158 (5790), 162 (5810), 166 (5830), 170 (5850)	30 (5150), 32 (5160), 34 (5170), 36 (5180) 38 (5190), 40 (5200), 42 (5210), 44 (5220), 46 (5230), 48 (5240), 50 (5250), 52 (5260), 54 (5270), 56 (5280), 58 (5290), 60 (5300), 62 (5310), 64 (5320), 66 (5330), 68 (5340), 70 (5350), 72 (5360), 74 (5370), 76 (5380), 78 (5390), 80 (5400), 82 (5410), 84 (5420), 86 (5430), 88 (5440), 90 (5450), 92 (5460), 94 (5470), 96 (5480), 98 (5490), 100 (5500), 102 (5510), 104 (5520), 106 (5530), 108 (5540), 110 (5550), 112 (5560), 114 (5570), 116 (5580), 118 (5590), 120 (5600), 122 (5610), 124 (5620), 126 (5630), 128 (5640), 130 (5650), 132 (5660), 134 (5670), 136 (5680), 138 (5690), 140 (5700), 142 (5710), 144 (5720), 146 (5730), 148 (5740), 150 (5750), 152 (5760), 154 (5770), 156 (5780), 158 (5790), 160 (5800), 162 (5810), 164 (5820), 166 (5830), 168 (5840), 170 (5850)	30 (5150), 31 (5155), 32 (5160), 33 (5165), 34 (5170), 35 (5175), 36 (5180), 37 (5185), 38 (5190), 39 (5195), 40 (5200), 41 (5205), 42 (5210), 43 (5215), 44 (5220), 45 (5225), 46 (5230), 47 (5235), 48 (5240), 49 (5245), 50 (5250), 51 (5255), 52 (5260), 53 (5265), 54 (5270), 55 (5275), 56 (5280), 57 (5285), 58 (5290), 59 (5295), 60 (5300), 61 (5305), 62 (5310), 63 (5315), 64 (5320), 65 (5325), 66 (5330), 67 (5335), 68 (5340), 69 (5345), 70 (5350), 71 (5355), 72 (5360), 73 (5365), 74 (5370), 75 (5375), 76 (5380), 77 (5385), 78 (5390), 79 (5395), 80 (5400), 81 (5405), 82 (5410), 83 (5415), 84 (5420), 85 (5425), 86 (5430), 87 (5435), 88 (5440), 89 (5445), 90 (5450), 91 (5455), 92 (5460), 93 (5465), 94 (5470), 95 (5475), 96 (5480), 97 (5485), 98 (5490), 99 (5495), 100 (5500), 101 (5505), 102 (5510), 103 (5515), 104 (5520), 105 (5525), 106 (5530), 107 (5535), 108 (5540), 109 (5545), 110 (5550), 111 (5555), 112 (5560), 113 (5565), 114 (5570), 115 (5575), 116 (5580), 117 (5585), 118 (5590), 119 (5595), 120 (5600), 121 (5605), 122 (5610), 123 (5615), 124 (5620), 125 (5625), 126 (5630), 127 (5635), 128 (5640), 129 (5645), 130 (5650), 131 (5655), 132 (5660), 133 (5665), 134 (5670), 135 (5675), 136 (5680), 137 (5685), 138 (5690), 139 (5695), 140 (5700), 141 (5705), 142 (5710), 143 (5715), 144 (5720), 145 (5725), 146 (5730), 147 (5735), 148 (5740), 149 (5745), 150 (5750), 151 (5755), 152 (5760), 153 (5765), 154 (5770), 155 (5775), 156 (5780), 157 (5785), 158 (5790), 159 (5795), 160 (5800), 161 (5805), 162 (5810), 163 (5815), 164 (5820), 165 (5825), 166 (5830), 167 (5835), 168 (5840), 169 (5845), 170 (5850)

Country (Code)	Frequency Bands	DFS	Allowed Channels (Center Freq)		
			20 MHz	10 MHz (N/A to the 5012)	5 MHz (N/A to the 5012)
Saudi Arabia (SA)	5.15 - 5.35 GHz and 5.725 - 5.825 GHz	No	36 (5180), 40 (5200), 44 (5220), 48 (5240), 52 (5260), 56 (5280), 60 (5300), 64 (5320), 149 (5745), 153 (5765), 157 (5785), 161 (5805)	36 (5180), 38 (5190), 40 (5200), 42 (5210), 44 (5220), 46 (5230), 48 (5240), 50 (5250), 52 (5260), 54 (5270), 56 (5280), 58 (5290), 60 (5300), 62 (5310), 64 (5320), 66 (5330), 147 (5735), 149 (5745), 151 (5755), 153 (5765), 155 (5775), 157 (5785), 159 (5795), 161 (5805), 163 (5815)	36 (5180), 37 (5185), 38 (5190), 39 (5195), 40 (5200), 41 (5205), 42 (5210), 43 (5215), 44 (5220), 45 (5225), 46 (5230), 47 (5235), 48 (5240), 49 (5245), 50 (5250), 51 (5255), 52 (5260), 53 (5265), 54 (5270), 55 (5275), 56 (5280), 57 (5285), 58 (5290), 59 (5295), 60 (5300), 61 (5305), 62 (5310), 63 (5315), 64 (5320), 65 (5325), 66 (5330), 67 (5335), 147 (5735), 148 (5740), 149 (5745), 150 (5750), 151 (5755), 152 (5760), 153 (5765), 154 (5770), 155 (5775), 156 (5780), 157 (5785), 158 (5790), 159 (5795), 160 (5800), 161 (5805), 162 (5810), 163 (5815)
Singapore (SG)	5.15 - 5.25 GHz and 5.725 - 5.85 GHz	No	36 (5180), 40 (5200), 44 (5220), 48 (5240), 149 (5745), 153 (5765), 157 (5785), 161 (5805), 165 (5825)	36 (5180), 38 (5190), 40 (5200), 42 (5210), 44 (5220), 46 (5230), 48 (5240), 147 (5735), 149 (5745), 151 (5755), 153 (5765), 155 (5775), 157 (5785), 159 (5795), 161 (5805), 163 (5815), 165 (5825), 167 (5835)	36 (5180), 37 (5185), 38 (5190), 39 (5195), 40 (5200), 41 (5205), 42 (5210), 43 (5215), 44 (5220), 45 (5225), 46 (5230), 47 (5235), 48 (5240), 147 (5735), 148 (5740), 149 (5745), 150 (5750), 151 (5755), 152 (5760), 153 (5765), 154 (5770), 155 (5775), 156 (5780), 157 (5785), 158 (5790), 159 (5795), 160 (5800), 161 (5805), 162 (5810), 163 (5815), 164 (5820), 165 (5825), 166 (5830), 167 (5835)
Slovak Republic (SK)	5.47 - 5.725 GHz	Yes	100 (5500), 104 (5520), 108 (5540), 112 (5560), 116 (5580), 120 (5600), 124 (5620), 128 (5640), 132 (5660), 136 (5680), 140 (5700)	98 (5490), 100 (5500), 102 (5510), 104 (5520), 106 (5530), 108 (5540), 110 (5550), 112 (5560), 114 (5570), 116 (5580), 118 (5590), 120 (5600), 122 (5610), 124 (5620), 126 (5630), 128 (5640), 130 (5650), 132 (5660), 134 (5670), 136 (5680), 138 (5690), 140 (5700), 142 (5710)	97 (5485), 98 (5490), 99 (5495), 100 (5500), 101 (5505), 102 (5510), 103 (5515), 104 (5520), 105 (5525), 106 (5530), 107 (5535), 108 (5540), 109 (5545), 110 (5550), 111 (5555), 112 (5560), 113 (5565), 114 (5570), 115 (5575), 116 (5580), 117 (5585), 118 (5590), 119 (5595), 120 (5600), 121 (5605), 122 (5610), 123 (5615), 124 (5620), 125 (5625), 126 (5630), 127 (5635), 128 (5640), 129 (5645), 130 (5650), 131 (5655), 132 (5660), 133 (5665), 134 (5670), 135 (5675), 136 (5680), 137 (5685), 138 (5690), 139 (5695), 140 (5700), 141 (5705), 142 (5710)

Country (Code)	Frequency Bands	DFS	Allowed Channels (Center Freq)		
			20 MHz	10 MHz (N/A to the 5012)	5 MHz (N/A to the 5012)
Slovenia (SI)	5.47 - 5.725 GHz	Yes	100 (5500), 104 (5520), 108 (5540), 112 (5560), 116 (5580), 120 (5600), 124 (5620), 128 (5640), 132 (5660), 136 (5680), 140 (5700)	98 (5490), 100 (5500), 102 (5510), 104 (5520), 106 (5530), 108 (5540), 110 (5550), 112 (5560), 114 (5570), 116 (5580), 118 (5590), 120 (5600), 122 (5610), 124 (5620), 126 (5630), 128 (5640), 130 (5650), 132 (5660), 134 (5670), 136 (5680), 138 (5690), 140 (5700), 142 (5710)	97 (5485), 98 (5490), 99 (5495), 100 (5500), 101 (5505), 102 (5510), 103 (5515), 104 (5520), 105 (5525), 106 (5530), 107 (5535), 108 (5540), 109 (5545), 110 (5550), 111 (5555), 112 (5560), 113 (5565), 114 (5570), 115 (5575), 116 (5580), 117 (5585), 118 (5590), 119 (5595), 120 (5600), 121 (5605), 122 (5610), 123 (5615), 124 (5620), 125 (5625), 126 (5630), 127 (5635), 128 (5640), 129 (5645), 130 (5650), 131 (5655), 132 (5660), 133 (5665), 134 (5670), 135 (5675), 136 (5680), 137 (5685), 138 (5690), 139 (5695), 140 (5700), 141 (5705), 142 (5710)
South Africa (ZA)	5.47 - 5.725 GHz	Yes	100 (5500), 104 (5520), 108 (5540), 112 (5560), 116 (5580), 120 (5600), 124 (5620), 128 (5640), 132 (5660), 136 (5680), 140 (5700)	98 (5490), 100 (5500), 102 (5510), 104 (5520), 106 (5530), 108 (5540), 110 (5550), 112 (5560), 114 (5570), 116 (5580), 118 (5590), 120 (5600), 122 (5610), 124 (5620), 126 (5630), 128 (5640), 130 (5650), 132 (5660), 134 (5670), 136 (5680), 138 (5690), 140 (5700), 142 (5710)	97 (5485), 98 (5490), 99 (5495), 100 (5500), 101 (5505), 102 (5510), 103 (5515), 104 (5520), 105 (5525), 106 (5530), 107 (5535), 108 (5540), 109 (5545), 110 (5550), 111 (5555), 112 (5560), 113 (5565), 114 (5570), 115 (5575), 116 (5580), 117 (5585), 118 (5590), 119 (5595), 120 (5600), 121 (5605), 122 (5610), 123 (5615), 124 (5620), 125 (5625), 126 (5630), 127 (5635), 128 (5640), 129 (5645), 130 (5650), 131 (5655), 132 (5660), 133 (5665), 134 (5670), 135 (5675), 136 (5680), 137 (5685), 138 (5690), 139 (5695), 140 (5700), 141 (5705), 142 (5710)
Spain (ES)	5.47 - 5.725 GHz	Yes	100 (5500), 104 (5520), 108 (5540), 112 (5560), 116 (5580), 120 (5600), 124 (5620), 128 (5640), 132 (5660), 136 (5680), 140 (5700)	98 (5490), 100 (5500), 102 (5510), 104 (5520), 106 (5530), 108 (5540), 110 (5550), 112 (5560), 114 (5570), 116 (5580), 118 (5590), 120 (5600), 122 (5610), 124 (5620), 126 (5630), 128 (5640), 130 (5650), 132 (5660), 134 (5670), 136 (5680), 138 (5690), 140 (5700), 142 (5710)	97 (5485), 98 (5490), 99 (5495), 100 (5500), 101 (5505), 102 (5510), 103 (5515), 104 (5520), 105 (5525), 106 (5530), 107 (5535), 108 (5540), 109 (5545), 110 (5550), 111 (5555), 112 (5560), 113 (5565), 114 (5570), 115 (5575), 116 (5580), 117 (5585), 118 (5590), 119 (5595), 120 (5600), 121 (5605), 122 (5610), 123 (5615), 124 (5620), 125 (5625), 126 (5630), 127 (5635), 128 (5640), 129 (5645), 130 (5650), 131 (5655), 132 (5660), 133 (5665), 134 (5670), 135 (5675), 136 (5680), 137 (5685), 138 (5690), 139 (5695), 140 (5700), 141 (5705), 142 (5710)

Country (Code)	Frequency Bands	DFS	Allowed Channels (Center Freq)		
			20 MHz	10 MHz (N/A to the 5012)	5 MHz (N/A to the 5012)
Sweden (SE)	5.47 - 5.725 GHz	Yes	100 (5500), 104 (5520), 108 (5540), 112 (5560), 116 (5580), 120 (5600), 124 (5620), 128 (5640), 132 (5660), 136 (5680), 140 (5700)	98 (5490), 100 (5500), 102 (5510), 104 (5520), 106 (5530), 108 (5540), 110 (5550), 112 (5560), 114 (5570), 116 (5580), 118 (5590), 120 (5600), 122 (5610), 124 (5620), 126 (5630), 128 (5640), 130 (5650), 132 (5660), 134 (5670), 136 (5680), 138 (5690), 140 (5700), 142 (5710)	97 (5485), 98 (5490), 99 (5495), 100 (5500), 101 (5505), 102 (5510), 103 (5515), 104 (5520), 105 (5525), 106 (5530), 107 (5535), 108 (5540), 109 (5545), 110 (5550), 111 (5555), 112 (5560), 113 (5565), 114 (5570), 115 (5575), 116 (5580), 117 (5585), 118 (5590), 119 (5595), 120 (5600), 121 (5605), 122 (5610), 123 (5615), 124 (5620), 125 (5625), 126 (5630), 127 (5635), 128 (5640), 129 (5645), 130 (5650), 131 (5655), 132 (5660), 133 (5665), 134 (5670), 135 (5675), 136 (5680), 137 (5685), 138 (5690), 139 (5695), 140 (5700), 141 (5705), 142 (5710)
Switzerland (CH)	5.47 - 5.725 GHz	Yes	100 (5500), 104 (5520), 108 (5540), 112 (5560), 116 (5580), 120 (5600), 124 (5620), 128 (5640), 132 (5660), 136 (5680), 140 (5700)	98 (5490), 100 (5500), 102 (5510), 104 (5520), 106 (5530), 108 (5540), 110 (5550), 112 (5560), 114 (5570), 116 (5580), 118 (5590), 120 (5600), 122 (5610), 124 (5620), 126 (5630), 128 (5640), 130 (5650), 132 (5660), 134 (5670), 136 (5680), 138 (5690), 140 (5700), 142 (5710)	97 (5485), 98 (5490), 99 (5495), 100 (5500), 101 (5505), 102 (5510), 103 (5515), 104 (5520), 105 (5525), 106 (5530), 107 (5535), 108 (5540), 109 (5545), 110 (5550), 111 (5555), 112 (5560), 113 (5565), 114 (5570), 115 (5575), 116 (5580), 117 (5585), 118 (5590), 119 (5595), 120 (5600), 121 (5605), 122 (5610), 123 (5615), 124 (5620), 125 (5625), 126 (5630), 127 (5635), 128 (5640), 129 (5645), 130 (5650), 131 (5655), 132 (5660), 133 (5665), 134 (5670), 135 (5675), 136 (5680), 137 (5685), 138 (5690), 139 (5695), 140 (5700), 141 (5705), 142 (5710)
Taiwan (TW)	5.25 - 5.35 GHz and 5.725 - 5.825 GHz	No	56 (5280), 60 (5300), 64 (5320), 149 (5745), 153 (5765), 157 (5785), 161 (5805)	54 (5270), 56 (5280), 58 (5290), 60 (5300), 62 (5310), 64 (5320), 66 (5330), 147 (5735), 149 (5745), 151 (5755), 153 (5765), 155 (5775), 157 (5785), 159 (5795), 161 (5805), 163 (5815)	53 (5265), 54 (5270), 55 (5275), 56 (5280), 57 (5285), 58 (5290), 59 (5295), 60 (5300), 61 (5305), 62 (5310), 63 (5315), 64 (5320), 65 (5325), 66 (5330), 67 (5335), 147 (5735), 148 (5740), 149 (5745), 150 (5750), 151 (5755), 152 (5760), 153 (5765), 154 (5770), 155 (5775), 156 (5780), 157 (5785), 158 (5790), 159 (5795), 160 (5800), 161 (5805), 162 (5810), 163 (5815)
Thailand (TH)	5.725 - 5.825 GHz	No	149 (5745), 153 (5765), 157 (5785), 161 (5805)	147 (5735), 149 (5745), 151 (5755), 153 (5765), 155 (5775), 157 (5785), 159 (5795), 161 (5805), 163 (5815)	147 (5735), 148 (5740), 149 (5745), 150 (5750), 151 (5755), 152 (5760), 153 (5765), 154 (5770), 155 (5775), 156 (5780), 157 (5785), 158 (5790), 159 (5795), 160 (5800), 161 (5805), 162 (5810), 163 (5815)

Country Codes and Channels

Tsunami MP.11 5012-SUI Installation and Management

Model 5012 (5.8 GHz) Channels/Frequencies by Country

Country (Code)	Frequency Bands	DFS	Allowed Channels (Center Freq)		
			20 MHz	10 MHz (N/A to the 5012)	5 MHz (N/A to the 5012)
United Kingdom (GB)	5.47 - 5.725 GHz	Yes	100 (5500), 104 (5520), 108 (5540), 112 (5560), 116 (5580), 120 (5600), 124 (5620), 128 (5640), 132 (5660), 136 (5680), 140 (5700)	98 (5490), 100 (5500), 102 (5510), 104 (5520), 106 (5530), 108 (5540), 110 (5550), 112 (5560), 114 (5570), 116 (5580), 118 (5590), 120 (5600), 122 (5610), 124 (5620), 126 (5630), 128 (5640), 130 (5650), 132 (5660), 134 (5670), 136 (5680), 138 (5690), 140 (5700), 142 (5710)	97 (5485), 98 (5490), 99 (5495), 100 (5500), 101 (5505), 102 (5510), 103 (5515), 104 (5520), 105 (5525), 106 (5530), 107 (5535), 108 (5540), 109 (5545), 110 (5550), 111 (5555), 112 (5560), 113 (5565), 114 (5570), 115 (5575), 116 (5580), 117 (5585), 118 (5590), 119 (5595), 120 (5600), 121 (5605), 122 (5610), 123 (5615), 124 (5620), 125 (5625), 126 (5630), 127 (5635), 128 (5640), 129 (5645), 130 (5650), 131 (5655), 132 (5660), 133 (5665), 134 (5670), 135 (5675), 136 (5680), 137 (5685), 138 (5690), 139 (5695), 140 (5700), 141 (5705), 142 (5710)
United Kingdom 5.8 GHz (G1)	5.725 - 5.85 GHz	Yes	147 (5735), 151 (5755), 155 (5775), 167 (5835)	145 (5725), 147 (5735), 149 (5745), 151 (5755), 153 (5765), 155 (5775), 157 (5785), 163 (5815), 165 (5825), 167 (5835), 169 (5845)	145 (5725), 146 (5730), 147 (5735), 148 (5740), 149 (5745), 150 (5750), 151 (5755), 152 (5760), 153 (5765), 154 (5770), 155 (5775), 156 (5780), 157 (5785), 158 (5790), 159 (5795), 163 (5815), 164 (5820), 165 (5825), 166 (5830), 167 (5835), 168 (5840), 169 (5845), 170 (5850)
United States (US)	5.25 - 5.35 GHz and 5.725 - 5.85 GHz	No	56 (5280), 60 (5300), 64 (5320), 149 (5745), 153 (5765), 157 (5785), 161 (5805), 165 (5825)	54 (5270), 56 (5280), 58 (5290), 60 (5300), 62 (5310), 64 (5320), 66 (5330), 147 (5735), 149 (5745), 151 (5755), 153 (5765), 155 (5775), 157 (5785), 159 (5795), 161 (5805), 163 (5815), 165 (5825), 167 (5835)	53 (5265), 54 (5270), 55 (5275), 56 (5280), 57 (5285), 58 (5290), 59 (5295), 60 (5300), 61 (5305), 62 (5310), 63 (5315), 64 (5320), 65 (5325), 66 (5330), 67 (5335), 147 (5735), 148 (5740), 149 (5745), 150 (5750), 151 (5755), 152 (5760), 153 (5765), 154 (5770), 155 (5775), 156 (5780), 157 (5785), 158 (5790), 159 (5795), 160 (5800), 161 (5805), 162 (5810), 163 (5815), 164 (5820), 165 (5825), 166 (5830), 167 (5835)
Uruguay (UY)	5.725 - 5.825 GHz	No	149 (5745), 153 (5765), 157 (5785), 161 (5805)	147 (5735), 149 (5745), 151 (5755), 153 (5765), 155 (5775), 157 (5785), 159 (5795), 161 (5805), 163 (5815)	147 (5735), 148 (5740), 149 (5745), 150 (5750), 151 (5755), 152 (5760), 153 (5765), 154 (5770), 155 (5775), 156 (5780), 157 (5785), 158 (5790), 159 (5795), 160 (5800), 161 (5805), 162 (5810), 163 (5815)
Venezuela (VE)	5.725 - 5.825 GHz	No	149 (5745), 153 (5765), 157 (5785), 161 (5805)	147 (5735), 149 (5745), 151 (5755), 153 (5765), 155 (5775), 157 (5785), 159 (5795), 161 (5805), 163 (5815)	147 (5735), 148 (5740), 149 (5745), 150 (5750), 151 (5755), 152 (5760), 153 (5765), 154 (5770), 155 (5775), 156 (5780), 157 (5785), 158 (5790), 159 (5795), 160 (5800), 161 (5805), 162 (5810), 163 (5815)

B

Technical Services and Support

Obtaining Technical Services and Support

If you are having trouble utilizing your Proxim product, please review this manual and the additional documentation provided with your product.

If you require additional support and would like to use Proxim's free Technical Service to help resolve your issue, please be ready to provide the following information before you contact Proxim's Technical Services:

- **Product information:**
 - Part number of suspected faulty unit
 - Serial number of suspected faulty unit
- **Trouble/error information:**
 - Trouble/symptom being experienced
 - Activities completed to confirm fault
 - Network information (what kind of network are you using?)
 - Circumstances that preceded or led up to the error
 - Message or alarms viewed
 - Steps taken to reproduce the problem
- **Servpak information (if a Servpak customer):**
 - Servpak account number
- **Registration information:**
 - If the product is not registered, date when you purchased the product
 - If the product is not registered, location where you purchased the product

NOTE: If you would like to register your product now, visit the Proxim eService Web Site at <http://support.proxim.com> and click on **New Product Registration**.

Support Options

Proxim eService Web Site Support

The Proxim eService Web site is available 7x24x365 at <http://support.proxim.com>.

On the Proxim eService Web Site, you can access the following services:

- **New Product Registration:** Register your product for free support.
- **Open a Ticket or RMA:** Open a ticket or RMA and receive an immediate reply.
- **Search Knowledgebase:** Locate white papers, software upgrades, and technical information.
- **ServPak (Service Packages):** Receive Advanced Replacement, Extended Warranty, 7x24x365 Technical Support, Priority Queuing, and On-Site Support.
- **Your Stuff:** Track status of your tickets or RMAs and receive product update notifications.
- **Provide Feedback:** Submit suggestions or other types of feedback.
- **Customer Survey:** Submit an On-Line Customer Survey response.
- **Repair Tune-Up:** Have your existing Proxim equipment inspected, tested, and upgraded to current S/W and H/W revisions, and extend your warranty for another year.

Telephone Support

Contact technical support via telephone as follows:

- **Domestic:** 866-674-6626
- **International:** +1-408-542-5390

Hours of Operation

- **North America:** 8 a.m. to 5 p.m. PST, Monday through Friday
- **EMEA:** 8 a.m. to 5 p.m. GMT, Monday through Friday

ServPak Support

Proxim understands that service and support requirements vary from customer to customer. It is our mission to offer service and support options that go above-and-beyond normal warranties to allow you the flexibility to provide the quality of service that your networks demand.

In recognition of these varying requirements we have developed a support program called ServPak. ServPak is a program of Enhanced Service Options that can be purchased individually or in combinations to meet your needs.

- **Advanced Replacement:** This service offers customers an advance replacement of refurbished or new hardware. (Available in the U.S., Canada, and select countries. Please inquire with your authorized Proxim distributor for availability in your country.)
- **Extended Warranty:** This service provides unlimited repair of your Proxim hardware for the life of the service contract.
- **7x24x365 Technical Support:** This service provides unlimited, direct access to Proxim's world-class technical support 24 hours a day, 7 days a week, 365 days a year.
- **Priority Queuing:** This service allows your product issue to be routed to the next available Customer Service Engineer.

To purchase ServPak support services, please contact your authorized Proxim distributor. To receive more information or for questions on any of the available ServPak support options, please call Proxim Support at +1-408-542-5390 or send an email to servpak@proxim.com.



Statement of Warranty

Warranty Coverage

Proxim Wireless Corporation warrants that its Products are manufactured solely from new parts, conform substantially to specifications, and will be free of defects in material and workmanship for a Warranty Period of **1 year** from the date of purchase.

Repair or Replacement

In the event a Product fails to perform in accordance with its specification during the Warranty Period, Proxim offers return-to-factory repair or replacement, with a thirty (30) business-day turnaround from the date of receipt of the defective Product at a Proxim Wireless Corporation Repair Center. When Proxim Wireless has reasonably determined that a returned Product is defective and is still under Warranty, Proxim Wireless shall, at its option, either: (a) repair the defective Product; (b) replace the defective Product with a refurbished Product that is equivalent to the original; or (c) where repair or replacement cannot be accomplished, refund the price paid for the defective Product. The Warranty Period for repaired or replacement Products shall be ninety (90) days or the remainder of the original Warranty Period, whichever is longer. This constitutes Buyer's sole and exclusive remedy and Proxim Wireless's sole and exclusive liability under this Warranty.

Limitations of Warranty

The express warranties set forth in this Agreement will not apply to defects in a Product caused; (i) through no fault of Proxim Wireless during shipment to or from Buyer, (ii) by the use of software other than that provided with or installed in the Product, (iii) by the use or operation of the Product in an application or environment other than that intended or recommended by Proxim Wireless, (iv) by modifications, alterations, or repairs made to the Product by any party other than Proxim Wireless or Proxim Wireless's authorized repair partners, (v) by the Product being subjected to unusual physical or electrical stress, or (vii) by failure of Buyer to comply with any of the return procedures specified in this Statement of Warranty.

Support Procedures

Buyer should return defective LAN¹ Products within the first 30 days to the merchant from which the Products were purchased. Buyer can contact a Proxim Wireless Customer Service Center either by telephone or via web. Calls for support for Products that are near the end of their warranty period should be made not longer than seven (7) days after expiration of warranty. Repair of Products that are out of warranty will be subject to a repair fee. Contact information is shown below. Additional support information can be found at Proxim Wireless's web site at <http://support.proxim.com>.

- **Domestic:** 866-674-6626
- **International:** +1-408-542-5390

Hours of Operation

- **North America:** 8 a.m. to 5 p.m. PST, Monday through Friday
- **EMEA:** 8 a.m. to 5 p.m. GMT, Monday through Friday

When contacting the Customer Service for support, Buyer should be prepared to provide the Product description and serial number and a description of the problem. The serial number should be on the product.

In the event the Customer Service Center determines that the problem can be corrected with a software update, Buyer might be instructed to download the update from Proxim Wireless's web site or, if that's not possible, the update will be sent to Buyer. In the event the Customer Service Center instructs Buyer to return the Product to Proxim Wireless for

1. LAN products include: ORINOCO™

repair or replacement, the Customer Service Center will provide Buyer a Return Material Authorization ("RMA") number and shipping instructions. Buyer must return the defective Product to Proxim Wireless, properly packaged to prevent damage, shipping prepaid, with the RMA number prominently displayed on the outside of the container.

Calls to the Customer Service Center for reasons other than Product failure will not be accepted unless Buyer has purchased a Proxim Wireless Service Contract or the call is made within the first thirty (30) days of the Product's invoice date. Calls that are outside of the 30-day free support time will be charged a fee of \$25.00 (US Dollars) per Support Call.

If Proxim Wireless reasonably determines that a returned Product is not defective or is not covered by the terms of this Warranty, Buyer shall be charged a service charge and return shipping charges.

Other Information

Search Knowledgebase

Proxim Wireless stores all resolved problems in a solution database at the following URL: <http://support.proxim.com>.

Ask a Question or Open an Issue

Submit a question or open an issue to Proxim Wireless technical support staff at the following URL: <http://support.proxim.com/cgi-bin/proxim.cfg/php/enduser/ask.php>.

Other Adapter Cards

Proxim Wireless does not support internal mini-PCI devices that are built into laptop computers, even if identified as "ORiNOCO" devices. Customers having such devices should contact the laptop vendor's technical support for assistance.

For support for a PCMCIA card carrying a brand name other than Proxim, ORiNOCO, Lucent, Wavelan, or Skyline, Customer should contact the brand vendor's technical support for assistance.